



KM-2550

SERVICE MANUAL

Published in June 2005
842FT112
Version 3.0

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

CAUTION

Double-pole/neutral fusing.

Version history

Version	Date	Replaced pages	Remarks
3.0	14 June 2005	1-1-1, 1-1-2, 1-3-6, 1-3-13, 1-4-2, 1-4-3, 1-4-4, 1-4-13, 1-4-25, 1-5-36, 1-6-11, 1-6-16, 1-6-21, 1-6-25, 1-6-38, 1-6-41, 1-6-43, 1-6-44, 1-6-50, 2-1-9, 2-1-10, 2-1-11, 2-2-1, 2-2-2, 2-2-3, 2-3-10, 2-3-13, 2-3-14, 2-4-1, 2-4-2, 2-4-3, 2-4-4, 2-4-8, 2-4-11	-

This page is intentionally left blank.





Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (△) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current.
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities.



CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury.
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock.
- Do not install the copier near a radiator, heater, other heat source or near flammable material.



This may cause fire.



- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance.



- Always handle the machine by the correct locations when moving it.
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury.
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention.













- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook.







2.Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

• Do not remove the ozone filter, if any, from the copier except for routine replacement.



• Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself.



• Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item.



• Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks.



• Remove toner completely from electronic components.



• Run wire harnesses carefully so that wires will not be trapped or damaged.



• After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws.



• Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary.



• Handle greases and solvents with care by following the instructions below:



Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely. Ventilate the room well while using grease or solvents.

Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on. Always wash hands afterwards.

• Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc.



• Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately.



3.Miscellaneous

WARNING

• Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas.



This page is intentionally left blank.

CONTENTS

1-1 Specifications

1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-3
(1) MFP	1-1-3
(2) Operation panel	1-1-4
1-1-3 Machine cross section	1-1-5
1-1-4 Drive system	1-1-6

1-2 Handling Precautions

1-2-1 Drum	1-2-1
1-2-2 Toner	1-2-1
1-2-3 Installation environment	1-2-2

1-3 Installation

1-3-1 Unpacking and installation	1-3-1
(1) Installation procedure	1-3-1
1-3-2 Setting initial copy modes	1-3-6
1-3-3 Installing the paper feeder (option)	1-3-7
1-3-4 Installing the DP (option)	1-3-9
1-3-5 Installing the duplex unit (option)	1-3-13
1-3-6 Installing the drawer heater (option)	1-3-16
1-3-7 Installing the key counter (option)	1-3-19
1-3-8 Installing the finisher (option)	1-3-22
1-3-9 Installing the job separator (option)	1-3-30
1-3-10 Installing the fax system (option)	1-3-35
1-3-11 Installing the scan system (option)	1-3-43
1-3-12 Installing the hard disk (option)	1-3-45

1-4 Maintenance Mode

1-4-1 Maintenance mode	1-4-1
(1) Executing a maintenance item	1-4-1
(2) Maintenance modes item list	1-4-2
(3) Contents of the maintenance mode items	1-4-5
1-4-2 Management mode	1-4-55
(1) Using the management mode	1-4-55
(2) Setting the job accounting	1-4-56
(3) Copy default	1-4-57
(4) Machine default	1-4-59
(5) Bypass setting	1-4-61
(6) Checking the total counter and printing out the counter report	1-4-61
(7) Status report print out	1-4-61
(8) Language selection function	1-4-61

1-5 Troubleshooting

1-5-1 Paper misfeed detection	1-5-1
(1) Paper misfeed indication	1-5-1
(2) Paper misfeed detection conditions	1-5-2
(3) Paper misfeeds	1-5-7
1-5-2 Self-diagnosis	1-5-17
(1) Self-diagnostic function	1-5-17
(2) Self diagnostic codes	1-5-18
1-5-3 Image formation problems	1-5-26
(1) No image appears (entirely white)	1-5-27
(2) No image appears (entirely black)	1-5-27
(3) Image is too light	1-5-28

(4) Background is visible.....	1-5-28
(5) A white line appears longitudinally.	1-5-28
(6) A black line appears longitudinally.	1-5-29
(7) A black line appears laterally.....	1-5-29
(8) One side of the copy image is darker than the other.....	1-5-29
(9) Black dots appear on the image.....	1-5-30
(10) Image is blurred.....	1-5-30
(11) The leading edge of the image is consistently misaligned with the original.	1-5-30
(12) The leading edge of the image is sporadically misaligned with the original.	1-5-31
(13) Paper creases.	1-5-31
(14) Offset occurs.	1-5-31
(15) Image is partly missing.	1-5-32
(16) Fixing is poor.	1-5-32
(17) Image is out of focus.	1-5-32
(18) Image center does not align with the original center.	1-5-33
1-5-4 Electric problems	1-5-34
(1) The machine does not operate when the power switch is turned on.	1-5-34
(2) The drive motor does not operate (C2000).	1-5-34
(3) The registration motor does not operate.	1-5-34
(4) The exit motor does not operate.	1-5-34
(5) The scanner motor does not operate.	1-5-35
(6) Cooling fan motor 1 does not operate.	1-5-35
(7) Cooling fan motor 2 does not operate.	1-5-35
(8) Cooling fan motor 3 does not operate.	1-5-35
(9) Cooling fan motor 4 does not operate.	1-5-35
(10) Toner motor does not operate.....	1-5-35
(11) The drawer drive motor does not operate.	1-5-35
(12) The paper feed clutch does not operate.....	1-5-35
(13) The bypass paper feed solenoid does not operate.	1-5-36
(14) The drawer paper feed clutch doesnot operate.....	1-5-36
(15) The cleaning lamp does not turn on.	1-5-36
(16) The exposure lampdoes not turn on.....	1-5-36
(17) The exposure lampdoes not turn off.....	1-5-36
(18) The fixing heater does not turn on (C6000).....	1-5-36
(19) The fixing heater does not turn off.....	1-5-36
(20) Main charging is notperformed.....	1-5-37
(21) Transfer charging is not performed.	1-5-37
(22) No developing bias is output.	1-5-37
(23) The original size is not detected.....	1-5-37
(24) The original size is not detected correctly.	1-5-37
(25) The message requesting paper to be loaded is shown when paper is present in the drawer 1.....	1-5-37
(26) The message requesting paper to be loaded is shown when paper is present in the drawer 2.....	1-5-37
(27) The size of paper in the drawer 1 is not displayed correctly.	1-5-38
(28) The size of paper in the drawer 2 is not displayed correctly.	1-5-38
(29) A paper jam in the paper feed, paper conveying or fixing section is indicated when the power switch is turned on.....	1-5-38
(30) The message requesting covers to be closed is displayed when the front cover and left cover are closed.	1-5-38
(31) Others.....	1-5-38
1-5-5 Mechanical problems	1-5-39
(1) No primary paper feed.....	1-5-39
(2) No secondary paper feed.	1-5-39
(3) Skewed paper feed.	1-5-39
(4) The scanner does not travel.....	1-5-39
(5) Multiple sheets of paper are fed at one time.	1-5-39
(6) Paper jams.	1-5-39
(7) Toner drops on the paper conveying path.....	1-5-40
(8) Abnormal noise is heard.....	1-5-40

1-6 Assembly and Disassembly

1-6-1	Precautions for assembly and disassembly	1-6-1
(1)	Precautions	1-6-1
(2)	Running a maintenance item.....	1-6-2
1-6-2	Paper feed section	1-6-3
(1)	Detaching and refitting the separation pulley	1-6-3
(2)	Detaching and refitting the forwarding pulley and paper feed pulley.....	1-6-5
(3)	Detaching and refitting the feed roller	1-6-7
(4)	Detaching and refitting the drawer separation pulley	1-6-8
(5)	Detaching and refitting the drawer forwarding pulley and drawer paper feed pulley.....	1-6-9
(6)	Detaching and refitting the paper conveying unit	1-6-11
(7)	Detaching and refitting the bypass paper feed pulley and bypass separation pad	1-6-13
(8)	Detaching and refitting the registration left roller.....	1-6-15
(9)	Detaching and refitting the registration cleaner	1-6-15
(10)	Adjustment after roller and clutch replacement	1-6-16
(10-1)	Adjusting the leading edge registration of image printing.....	1-6-16
(10-2)	Adjusting the leading edge registration for memory image printing	1-6-17
(10-3)	Adjusting the center line of image printing	1-6-18
(10-4)	Adjusting the trailing edge margin of image printing	1-6-19
(10-5)	Adjusting the margins for printing.....	1-6-20
(10-6)	Adjusting the amount of slack in the paper	1-6-21
1-6-3	Optical section	1-6-22
(1)	Detaching and refitting the exposure lamp.....	1-6-22
(2)	Detaching and refitting the scanner wires	1-6-23
(2-1)	Detaching the scanner wires	1-6-23
(2-2)	Fitting the scanner wires	1-6-25
(3)	Detaching and refitting the ISU (reference).....	1-6-28
(4)	Detaching and refitting the laser scanner unit.....	1-6-29
(5)	Adjusting the longitudinal squareness (reference)	1-6-32
(6)	Adjusting magnification of the scanner in the main scanning direction	1-6-33
(7)	Adjusting magnification of the scanner in the auxiliary scanning direction.....	1-6-34
(8)	Adjusting the scanner leading edge registration	1-6-35
(9)	Adjusting the scanner center line	1-6-36
(10)	Adjusting the margins for scanning an original on the contact glass.....	1-6-37
1-6-4	Drum section.....	1-6-38
(1)	Detaching and refitting the drum unit	1-6-38
(2)	Detaching and refitting the drum separation claws	1-6-39
(3)	Detaching and refitting the main charger unit.....	1-6-40
1-6-5	Developing section.....	1-6-41
(1)	Detaching and refitting the developing unit	1-6-41
1-6-6	Transfer section	1-6-42
(1)	Detaching and refitting the transfer roller	1-6-42
1-6-7	Fixing section	1-6-43
(1)	Detaching and refitting the fixing unit	1-6-43
(2)	Detaching and refitting the press roller.....	1-6-45
(3)	Detaching and refitting the fixing heater M and S	1-6-46
(4)	Detaching and refitting the heat roller separation claws.....	1-6-47
(5)	Detaching and refitting the heat roller	1-6-48
(6)	Detaching and refitting the fixing thermostat.....	1-6-49
(7)	Detaching and refitting the fixing thermistor	1-6-49
(8)	Adjusting the fixing unit height (adjusting lateral squareness)	1-6-50

1-7 Requirements on PWB Replacement

1-7-1	Upgrading the firmware on the main PCB	1-7-1
1-7-2	Upgrading the printer board firmware	1-7-2
1-7-3	Adjustment-free variable resistors (VR)	1-7-3
1-7-4	Remarks on PCBs replacement.....	1-7-3

2-1 Mechanical construction

2-1-1 Paper feed section	2-1-1
2-1-2 Optical section	2-1-4
(1) Original scanning.....	2-1-5
(2) Image printing.....	2-1-6
2-1-3 Drum section.....	2-1-8
2-1-4 Developing section.....	2-1-10
(1) Formation of magnetic brush.....	2-1-11
(2) Single component developing system.....	2-1-12
2-1-5 Transfer and separation sections.....	2-1-13
2-1-6 Fixing section	2-1-15
(1) Fixing temperature system	2-1-16
(2) Fixing temperature control based on ambient temperature.....	2-1-16
2-1-7 Exit and switchback sections	2-1-17
2-1-8 Duplex section	2-1-18
(1) Paper conveying operation in duplex copying.....	2-1-19

2-2 Electrical Parts Layout

2-2-1 Electrical parts layout.....	2-2-1
(1) PCBs	2-2-1
(2) Switches and sensors	2-2-2
(3) Motors	2-2-4
(4) Other electrical components.....	2-2-5

2-3 Operation of the PWBs

2-3-1 Power source PCB.....	2-3-1
2-3-2 Main PCB.....	2-3-4
2-3-3 Engine PCB	2-3-8
2-3-4 Printer board PCB.....	2-3-15
2-3-5 Operation unit PCB.....	2-3-19
2-3-6 CCD PCB.....	2-3-22

2-4 Appendixes

Timing chart No.1.....	2-4-1
Timing chart No.2.....	2-4-2
Timing chart No.3.....	2-4-3
Timing chart No.4.....	2-4-4
Chart of image adjustment procedures.....	2-4-5
Maintenance parts list.....	2-4-8
Periodic maintenance procedures	2-4-9
General wiring diagram.....	2-4-11

1-1-1 Specifications

Type	Desktop
Copying system	Indirect electrostatic system
Originals	Sheets, books and 3-dimensional objects (Maximum original size: A3/11" x 17")
Original feed system	Fixed
Copy paper	Paper weights Drawer: 60 - 105 g/m ² Bypass table: 45 - 160 g/m ² Paper type Drawer: Plain paper, recycled paper and colored paper Bypass table: Plain paper, recycled paper, thin paper, thick paper and colored paper
Copying sizes	Maximum: A3/11" x 17" Minimum: A6R /5 1/2" x 8 1/2"
Magnification ratios	Manual mode: 25 - 200%, 1% increments
Copy speed	At 100% magnification in copy mode: A4: 25 copies/min. A4R: 15 copies/min. A3: 13 copies/min. A5R: 12 copies/min. A6R: 11 copies/min. B5: 25 copies/min. B5R: 15 copies/min. B4 (257 x 364 mm): 13 copies/min. 11" x 8 1/2": 25 copies/min. 8 1/2" x 11": 15 copies/min. 11" x 17": 13 copies/min. 8 1/2" x 14": 13 copies/min.
First copy time	5.0 s or less (A4/11" x 8 1/2")
Warm-up time	Less than 20 s (room temperature 23°C/73.4°F, 50% RH) Time for recovery from low power mode: 10 s Time for recovery from sleep mode: 20 s
Paper feed system	Automatic feed Capacity: Drawers: 300 sheets (80 g/m ²) 100 sheets (90 - 105 g/m ²) Manual feed Capacity: Bypass: 50 sheets (A4/11" x 8 1/2" or less) 25 sheets (A3, B4, 11" x 17", 8 1/2" x 14")
Paper ejection system	In-machine ejection (face down) Capacity: 250 sheets (80 g/m ²)
Continuous copying	1 - 999 sheets
Photoconductor	a-Si drum (drum diameter 30 mm)
Charging system	Single positive corona charging
Recording system	Semiconductor laser
Developing system	Single component developing system Toner: magnetism toner Toner replenishing: automatic from a toner container
Transfer system	Transfer roller
Separation system	Curvature separation and separation electrode
Fixing system	Heat roller Heat source: halogen heaters (120 V specifications: main 550 W, sub 400W/ 220-240 V specifications: main 600 W, sub 430 W) Control temperature: 180°C/356°F (190°C/374°F on and after 6th sheet) Abnormally high temperature protection device: 180°C/356°F thermostat Fixing pressure: 44.1 N
Charge erasing system	Exposure by cleaning lamp
Cleaning system	Cleaning blade
Scanning system	Flat bed scanning by CCD image sensor
Bitmap memory	35 MB (standard)
Image storage memory	29 MB (standard)
Additional memory	16 MB, 32 MB, 64 MB and 128 MB

Resolution	600 x 600 dpi
Light source	Inert gas lamp
Dimensions	574 (W) x 593 (D) x 650 (H) mm 22 5/8" (W) x 23 3/8" (D) x 25 9/16" (H)
Weight.....	Approx. 47 kg/103.4 lbs
Floor requirements.....	827 (W) x 593 (D) mm (at the time of using bypass table) 32 5/8" (W) x 23 3/8" (D) (at the time of using bypass table)
Functions	Automatic paper selection, Image quality selection, Automatic sizing selection function, zoom function, Duplex copy, Divided copy, Binding margin, Border width, Aggregate copy, Sort copy, Eco-copy, Copy program and Section management mode
Power source	120 V AC, 60 Hz, 9.0 A 220 - 240 V AC, 50 Hz, 5.0 A
Options	Document processor, paper feeder, duplex unit, finisher, job separator, key counter, fax system, network scanner, hard disk, additional memory and original cover

Printer functions

Printing speed	Same as copying speed
First print time	Approx. 4.9 s (A4/11" x 8 1/2")
Resolution.....	300 dpi, 600 dpi, Fast 1200 mode
Memory	64 MB (standard) Additional memory: 32 MB, 64 MB, 128 MB and 256 MB Hard disk: 340 MB, 512 MB and 1 GB
Applicable OS	Microsoft Windows 95/98/Me/NT4.x/2000/XP Apple Macintosh OS 9.x/OS X 10.x UNIX/Linux
Interface.....	Parallel interface (based on IEEE1284) Network interface USB 2.0 (USB Hi-Speed) Network interface card (option)

Duplex unit

Type	Internal type
Copy paper	Paper weights: 64 - 90 g/m ² Paper type: Plain paper, recycled paper and colored paper
Paper sizes	A3 - A5R/11" x 17" - 5 1/2" x 8 1/2"
Power source	Electrically connected to the MFP
Dimensions	368 (W) x 53 (D) x 180 (H) mm 14 1/2" (W) x 2 1/16" (D) x 7 1/16" (H)
Weight.....	Approx. 0.65 kg/1.43 lbs

1-1-2 Parts names

(1) MFP




Figure 1-1-1

- | | | |
|------------------------------|------------------------------------|----------------------------------|
| 1. Original cover (optional) | 10. Support guide | 19. Front cover |
| 2. Copy storage section | 11. Slider | 20. Power switch |
| 3. Operation panel | 12. Contact glass | 21. Power switch cover |
| 4. Drawer 1 | 13. Original size indicator plates | 22. Handles for transport |
| 5. Drawer 2 | 14. Left cover | 23. Network interface connector |
| 6. Width guide | 15. Waste toner box | 24. USB interface connector |
| 7. Length guide | 16. Toner container release lever | 25. Parallel interface connector |
| 8. Left cover handle | 17. Toner container | 26. Memory card slot |
| 9. Bypass tray | 18. Cleaner rod | |

(2) Operation panel




Figure 1-1-2

- | | |
|--|---|
| 1. System Menu/Counter key and indicator | 20. Paper Select key / Right cursor key |
| 2. Copier key and indicator | 21. Enter key |
| 3. Printer key and indicator | 22. Image quality mode select key |
| 4. Scanner key and indicator | 23. Auto Exposure key |
| 5. Fax key and indicator | 24. Lighter key / Darker key / exposure display |
| 6. Combine key and indicator | 25. Message display |
| 7. Border Erase key and indicator | 26. Ready indicator |
| 8. Duplex/Split Page key and indicator | 27. Data indicator |
| 9. Offset key and indicator | 28. Attention indicator |
| 10. Function key | 29. Job Accounting key |
| 11. Scanner Function key | 30. Interrupt key and indicator |
| 12. Auto Selection key and indicator | 31. Energy Saver key and indicator |
| 13. Margin key and indicator | 32. Power key and indicator |
| 14. Sort key and indicator | 33. Numeric keys |
| 15. Staple key and indicator | 34. Reset key |
| 16. Program key | 35. Stop/Clear key |
| 17. Zoom key / Left cursor key | 36. Start key and indicator |
| 18. Auto%/100% key / Down cursor key | 37. Main power indicator |
| 19. Original Size key / Up cursor key | |

1-1-3 Machine cross section




Figure 1-1-3 Machine cross section

1. Paper feed section
2. Optical section
3. Drum section
4. Developing section
5. Transfer and separation section
6. Fixing section
7. Exit and switchback section
8. Duplex section

1-1-4 Drive system




Figure 1-1-4

- | | |
|----------------------------|--------------------------|
| 1. Drive motor gear | 16. Developing gear 26 |
| 2. Gear 136 | 17. Gear 40 |
| 3. Registration gear 51 | 18. Fixing joint gear 29 |
| 4. Registration motor gear | 19. Gear 31 |
| 5. Gear 32 | 20. Gear 50 |
| 6. Gear 25 | 21. Gear 98/34 |
| 7. Gear 25 | 22. Gear 50 |
| 8. Gear 20 | 23. Gear 25 |
| 9. Paper feed clutch gear | 24. Gear 40 |
| 10. Gear 30 | 25. Gear 30 |
| 11. Gear 31 | 26. Gear 50 |
| 12. Gear 25 | 27. Gear 60 |
| 13. Gear 49 | 28. Gear 32/23 |
| 14. Gear 30/23 | 29. Exit motor gear |
| 15. Developing gear 25 | 30. Gear 43/20 |

1-2-1 Drum

Note the following when handling or storing the drum.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum at an ambient temperature between -20°C/-4°F and 55°C/131°F and at a relative humidity not higher than 90% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

1-2-2 Toner

Store the toner in a cool, dark place. Avoid direct light and high humidity.

1-2-3 Installation environment

1. Temperature: 10 - 32.5°C/50 - 90.5°F
2. Humidity: 15 - 80%RH
3. Power supply: 120 V AC, 9.0 A
220 - 240 V AC, 5.0 A
4. Power source frequency: 50 Hz $\pm 0.3\%$ /60 Hz $\pm 0.3\%$
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid extremes of temperature and humidity, abrupt ambient temperature changes, and hot or cold air directed onto the machine.

Avoid dust and vibration.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).


Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NO_x, SO_x gases and chlorine-based organic solvents.

Select a room with good ventilation.

6. Allow sufficient access for proper operation and maintenance of the machine.

Machine front: 1000 mm/39 3/8" Machine rear: 100 mm/3 15/16"

Machine right: 300 mm/11 13/16" Machine left: 300 mm/11 13/16"




- a: 571 mm/22 1/2"
- b: 603 mm/23 3/4"
- c: 607 mm/23 7/8"
- d: 1371.5 mm/54"
- e: 1323 mm/52 1/16"
- f: 952.5 mm/37 1/2"

Figure 1-2-1 Installation dimensions

1-3-1 Unpacking and installation

(1) Installation procedure



Unpacking.




Figure 1-3-1 Unpacking

- | | | |
|--------------------|---------------------|----------------------|
| 1. MFP | 10. Left spacer | 19. Front pad |
| 2. Power cord | 11. Rear spacer | 20. Operation guide |
| 3. Toner container | 12. Rear pad | Cassette size sheet |
| 4. Outer case | 13. Skid | Paper protection bag |
| 5. Lower left pad | 14. Belt | Error code label |
| 6. Lower right pad | 15. Eject sheet | Inspection report |
| 7. Upper left pad | 16. Machine cover | |
| 8. Upper right pad | 17. Bar code labels | |
| 9. Inner frame | 18. Top sheet | |

* Place the machine on a level surface.

Install the optional paper feeder.

1. Install the optional paper feeder as necessary (see pages 1-3-7 to 1-3-8).

Remove the tapes and pins.

1. Remove the fifteen tapes..




Figure 1-3-2

2. Remove the two pins for light source unit.




Figure 1-3-3

Install the optional original cover or DP.

1. Install the optional original cover or DP (see pages 1-3-9 to 1-3-12 when installing the DP).

Install the optional duplex unit.

1. Install the optional duplex unit as necessary (see pages 1-3-13 to 1-3-15).

Install the optional finisher or job separator.

1. Install the optional finisher or job separator as necessary (see pages 1-3-22 to 1-3-34).

Install the toner container.

1. Open the front cover.
2. Tap the top of the toner container five to six times.
3. Shake the toner container approximately 10 times in the horizontal direction to stir toner.
4. Turn the toner container release lever and gently push the toner container into the MFP.
*Push the container all the way into the MFP until it locks in place.
5. Restore the toner container release lever.
6. Close the front cover.




Figure 1-3-4-1

Connect the connector of the drawer heater.

- *Connect according to need.
1. Remove the right cover.
 2. Connect the connector of the drawer heater to YC7 of the power source PCB.
 3. Refit the right cover.




Figure 1-3-4-2

Connect the power cord.

1. Connect the power cord to the connector on the MFP.
2. Insert the power plug into the wall outlet and turn the power switch on.

Installing the toner (maintenance item U130).

1. Enter the maintenance mode by entering "10871087" using the numeric keys.
2. Enter "130" using the numeric keys and press the start key.
3. Select the "EXECUTE" using the up/down cursor keys
4. Press the start key to execute the maintenance item.
Installation of toner starts and time (minutes) is indicated until the installation ends.
5. When the installation is complete, "FINISHED" will be displayed if the installation is successful or "NG" will be displayed if it has failed.
If "NG" is displayed, check to see if the toner container contains toner and to see if the toner container sensor malfunctions and then try again.
6. Press the stop/clear key.

Load paper.

1. Load paper in the drawer.

Output an own-status report (maintenance item U000).

1. Enter "000" using the numeric keys and press the start key.
2. Select "MAINTENANCE" and press the start key to output a list of the current settings of the maintenance items.
3. Press the stop/clear key.

Exit maintenance mode.

1. Enter "001" using the numeric keys and press the start key.
The machine exits the maintenance mode.

Make test copies.

1. Place an original and make test copies.
Set A3/11" x 17" paper on drawer 2 and run the maintenance item U113 (Performing drum refresh operation) if a faulty image (black lines, etc.) occurs.

End of installation.

1-3-2 Setting initial copy modes

Factory settings are as follows:

Maintenance item No.	Contents	Factory setting
U253	Switching between double and single counts	Double count
U254	Turning auto start function on/off	ON
U258	Switching copy operation at toner empty detection	SINGLE MODE
U260	Changing the copy count timing	After ejection
U264	Setting the display order of the date	Month/Day/Year (Inch specifications) Day/Month/Year (Metric specifications)
U277	Setting auto application change time	30
U326	Setting the black line cleaning indication	ON
U342	Setting the ejection restriction	ON
U343	Switching between duplex/simplex copy mode	OFF
U344	Setting preheat/energy saver mode	ENERGY STAR

1-3-3 Installing the paper feeder (option)

<Procedure>

1. Place the MFP on the paper feeder by aligning the positioning insertion sections of the MFP with the positioning pins at the rear part of the paper feeder.
* When placing the MFP, take care not to hit the MFP against the drawer, the pins or ground plate of the paper feeder.




Figure 1-3-5

For stacking paper feeders for use:

Stack a paper feeder on another paper feeder by aligning the positioning insertion sections of the first paper feeder with the positioning pins at the rear part of the second paper feeder.
(Two paper feeders can be added.)




Figure 1-3-6

2. If a type of paper that is not included in the specifications for the standard sheet cassette size is used, replace the cassette size sheet indication with the supplied one.
3. Insert the MFP power plug into the wall outlet and turn the power switch on. Load paper in the drawer and make test copies to check the operation.




Figure 1-3-7

Adjusting the leading edge timing

1. Run maintenance mode 034.
Select ADJ, RCL ON TIMING and press the start key.
First optional cassette: Select RCL T1.
Second optional cassette: Select RCL T2.
Third optional cassette: Select RCL T3.
For models equipped with two standard cassettes, adjust only RCL T2 and RCL T3.
Press the Interrupt key to output the test pattern and check the image. If an adequate image cannot be obtained, carry out the following adjustment.
2. If a test pattern a is obtained, increase the adjustment value.
If a test pattern b is obtained, decrease the adjustment value.
Setting range: -5.0 - +10.0
Changing the value by one moves the leading edge by 0.1 mm.
3. Output the test pattern again.
4. Repeat steps 2 and 3 until an adequate image is obtained.




Figure 1-3-8

Adjusting the center line

1. Run maintenance mode 034.
Select ADJ, LSU OUT TIMING and press the start key.
First optional cassette: Select LSU T1.
Second optional cassette: Select LSU T2.
Third optional cassette: Select LSU T3.
For models equipped with two standard cassettes, adjust only LSU T2 and LSU T3.
Press the Interrupt key to output the test pattern and check the image. If an adequate image cannot be obtained, carry out the following adjustment.
2. If a test pattern a is obtained, increase the adjustment value.
If a test pattern b is obtained, decrease the adjustment value.
Setting range: -7.0 - +10.0
Changing the value by one moves the center line by 0.1 mm.
3. Output the test pattern again.
4. Repeat steps 2 and 3 until an adequate image is obtained.




Figure 1-3-9

1-3-4 Installing the DP (option)

<Procedure>

1. Remove the original holder and remove the two screws from the rear top cover.
2. Pass the two pins through the screw holes of the rear top cover and attach them to the lower frame.




Figure 1-3-10

3. Place the DP on the MFP by fitting the pins into the holes at the hinge sections of the DP and sliding them toward the front side.




Figure 1-3-11

4. Secure the DP with the two TP Taptite chromate screws M4 x 10 and the two screws that have been removed in step 1.




Figure 1-3-12

5. Close the DP, fit the fixing fitting from the rear side of the right hinge, and secure it with the two bronze TP screws M3 x 06.
6. Connect the cable of the DP to the MFP.
* Be sure to tighten the fixing screws on both side of the connector.




Figure 1-3-13

7. Clean the pasting position for the caution label with alcohol.
Paste the caution label that corresponds to the language according to the destination to the DP.




Figure 1-3-14

[Operation check]

1. Prepare an original on which 4 lines are drawn 15 mm from the edges and the center line is drawn.
2. Set the original on the DP and make a test copy to check the copy image.
At this time, set the paper guide for the original table and drawer to the paper size to be used.
3. If the copy image does not match the original image, carry out the following adjustments in maintenance mode.
Maintenance mode 070 (sub-scan line adjustment)
Maintenance mode 071 (leading edge timing adjustment)
Maintenance mode 072 (center line adjustment)




Figure 1-3-15

Maintenance mode 070 (sub-scan line adjustment)

1. Run maintenance mode 070.
Select CONVEY SPEED1.
(For adjustment of the back side in duplex copying, select CONVEY SPEED2.)
Set originals in the original tray and press the interrupt key. Make a test copy to check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
2. For copy example a: decrease the value.
For copy example b: increase the value.
Setting range: -25 - +25
Changing the value by one changes the sub-scan line by 0.1%.
A smaller setting value makes the copy image shorter. A larger value makes the image longer.




Figure 1-3-16

Maintenance mode 071 (leading edge timing adjustment)

1. Run maintenance mode 071.
Select LEAD1.
(For adjustment of the back side in duplex copying, select LEAD2.)
Set originals in the original tray and press the interrupt key. Make a test copy to check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
2. For copy example a: increase the value.
For copy example b: decrease the value.
Setting range: -32 - +22
Changing the value by one moves the leading edge by 0.2 mm.
The larger the value, the later the image scan start timing.
The smaller the value, the earlier the image scan start timing.




Figure 1-3-17

Maintenance mode 072 (center line adjustment)

- 1. Run maintenance mode 072.
Select 1sided.
(For adjustment of the front side in duplex copying, select 2sided front. For adjustment of the back side, select 2sided back.)
Set originals in the original tray and press the Interrupt key. Make a test copy to check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
- 2. For copy example a: increase the value.
For copy example b: decrease the value.
Setting range: -39 - +39
Changing the value by one moves the center line by 0.1 mm.
The larger the value, the center of the image moves toward the right.
The smaller the value, the center of the image moves toward the left.




Figure 1-3-18

1-3-5 Installing the duplex unit (option)

<Procedure>

1. Open the left cover.
2. Remove the stop ring and the strap from the rear side.
3. Restore the conveyor section.
4. Remove the pin and plate, and then remove the stopper from the front side.
5. Open the left cover until it is put horizontally.




Figure 1-3-19

6. Turn the wire guide section of the duplex unit in the direction indicated by the arrow.




Figure 1-3-20

7. Insert the axis sections of the duplex unit into the Ushape grooves of the conveyer unit.






Figure 1-3-21


8. Press the duplex unit in the direction indicated by the arrow to fit the claws into the conveyer unit.

**Figure 1-3-22-1**

9. Hang the hook of the plate lock on the conveying unit and then turn the plate lock to fit the hole to the claw of the duplex unit.

**Figure 1-3-22-2**

10. Secure the duplex unit with the two S tite screws M3 x 06.

**Figure 1-3-23**

11. Open the conveyer unit and connect the connector of the duplex unit to the MFP.
12. Reattach the removed parts to their original positions.
13. Connect the MFP power plug to the wall outlet and turn the power switch on.






Figure 1-3-24

Adjusting the leading edge timing


1. Run maintenance mode 034.
Select ADJ, RCL ON TIMING and press the start key.
Select RCL DUP.
Press the Interrupt key to output the test pattern in the duplex mode and check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
2. If a test pattern a is obtained, increase the adjustment value.
If a test pattern b is obtained, decrease the adjustment value.
Setting range: -5.0 - +10.0
Changing the value by one moves the leading edge by 0.1 mm.
3. Output the test pattern again.
4. Repeat steps 2 and 3 until an adequate image is obtained.



Adequate image



Test pattern a




Test pattern b


Figure 1-3-25

Adjusting the center line


1. Run maintenance mode 034.
Select ADJ, LSU OUT TIMING and press the start key.
Select LSU DUP.
Press the Interrupt key to output the test pattern in the duplex mode and check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
2. If a test pattern a is obtained, increase the adjustment value.
If a test pattern b is obtained, decrease the adjustment value.
Setting range: -7.0 - +10.0
Changing the value by one moves the center line by 0.1 mm.
3. Output the test pattern again.
4. Repeat steps 2 and 3 until an adequate image is obtained.



Adequate image



Test pattern a



Test pattern b

Figure 1-3-26

1-3-6 Installing the drawer heater (option)

Drawer heater installation requires the following parts:

Drawer heater (P/N 120 V specifications: 2C960030, 220-240 V specifications: 2C960040)

One (1) M4 x 10 tap-tight S binding screw (P/N B3024100)

<Procedure>

1. Remove the main body from the paper feeder (see page 1-6-7).
2. Remove the right cover. Pull out the drawer.
3. Remove the three screws and then the front right cover.




Figure 1-3-27

4. Insert the cassette heater from the bottom of the machine and attach it to the MFP.

1) Pass the connector of the cassette heater through the hole located in the right frame of the machine to pull it out.

2) Insert the projections at the rear side of the cassette heater mounting plate into the two holes in the rear frame of the machine.

3) Position the screw hole of the drawer heater to the screw hole of the front frame of the machine and secure the heater using the M4 x 10 Taptite S binding screw.




Figure 1-3-28

5. Remove the two screws and open the power source PCB in the direction indicated by the arrow.
* Take care not to open the power source PCB too much.
6. Fit the wire of the drawer heater into the groove of the frame and put it inside the power source PCB.
* Fit the wire into the groove so that the band mounted to the wire is located above the frame.




Figure 1-3-29

7. Reattach the power source PCB to its original position and connect the connector of the drawer heater to YC8 of the power source PCB.
8. Refit all the removed parts.




Figure 1-3-30

1-3-7 Installing the key counter (option)

Key counter installation requires the following parts:

Key counter cover (P/N 2A360010)

Key counter retainer (P/N 66060030)

Key counter mount (P/N 66060040)

Key counter assembly (P/N 41529210)

Four (4) M4 x 6 bronze TP-A screws (P/N B4304060)

One (1) M4 x 35 round head screw (P/N B0004350)

Two (2) M3 x 6 bronze flat-head screws (P/N B2303060)

One (1) M3 bronze nut (P/N C2303000)

Key counter mounting plate (P/N 2C960100)

Key counter wire (P/N 2C960110)

Procedure

1. Fit the key counter socket assembly to the key counter retainer using the two screws and nut.
2. Fit the key counter mount to the key counter cover using the two screws, and attach the key counter retainer to the mount using the two screws.




Figure 1-3-31

3. Remove the rear cover.
4. Cut out the aperture plate on the right cover using nippers.
5. Connect the 4-pin connector of the key counter wire (located at a longer distance from the tube) to YC13 on the engine PCB, pass the wire through the two clamps, and pull the other 4-pin connector out from the aperture of the right cover.
 * Arrange the key counter wire behind the optical system wire as shown in the illustration.
6. Fold the 7-pin connector of the key counter wire back, pass the wire through the clamp at the upper part of the controller box, and hang it.




Figure 1-3-32

7. Pass the connector of the key counter through the aperture of the key counter mounting plate, and engage the projection of key counter mounting plate with the square hole of the key counter cover.




Figure 1-3-33

8. Connect the 4-pin connector of the key counter to the key counter wire.
9. Engage the projection of the key counter mounting plate with the aperture of the right cover.
10. Secure the key counter cover and the key counter mounting plate together with the MFP using a M4 x 35 screw.
11. Refit the rear cover.




Figure 1-3-34

12. Insert the key counter into the key counter socket assembly.
13. Turn the power switch on and enter the maintenance mode.
14. Run maintenance item U204 and select "KEY COUNTER"
15. Exit the maintenance mode.
16. Check that the message requesting the key counter to be inserted is displayed on the message display when the key counter is pulled out.
17. Check that the counter counts up as copies are made.

1-3-8 Installing the finisher (option)

<Note>

When placing the transfer unit on the floor or the like, be sure to place it upside down. If not, the staple mounting plate may be deformed, resulting in a malfunction.




Figure 1-3-35

Be sure to remove the tape for the intermediate tray at Procedure 16 not removing before mounting.




Figure 1-3-36

<Procedure>**Remove the covers.**

1. Remove the two screws to remove the upper left cover.






Figure 1-3-37


2. Open the front cover.
3. Remove the inner cover.

**Figure 1-3-38**

4. Release the fitting parts using a small screw driver or the like and remove the front side cover.

**Figure 1-3-39**

5. Remove the screw and the fitting part located on the right side and then remove the left front cover.
6. Open the front cover.

**Figure 1-3-40**

7. Remove the three screws and then remove the ejection cover and inner ejection cover.




Figure 1-3-41

8. Remove the two screws and then remove the cover.







Figure 1-3-42

Attach the transfer unit.

9. Insert the transfer unit from the MFP front side and slide it to the left to install to the ejection part.
10. Place the transfer unit closer to the ejection side and then secure the front side using the TP bind screw M3 x 06 and the rear side using the pin.


**Figure 1-3-43****Release the lever securing fitting.**

11. Loosen the screw located at the rear side of the transfer unit and release the lever securing fitting in the direction of an arrow, and then retighten the screw.


**Figure 1-3-44**

Attach the intermediate tray.

12. Loosen the screw located inside of the MFP by about 3 turns.
 * Do not turn the screw too much, otherwise it may drop in the machine.
13. Hang the hook of the hook holder onto the screw and then retighten the screw.

**Figure 1-3-45**

14. Insert the intermediate tray from the front side of the MFP while pushing the hook to the back and then push the pin located at the right rear side of the intermediate tray into the hook holder until the fitting sound is heard.

**Figure 1-3-46**

15. Fit the pin located at the left rear side of the intermediate tray from the rear side of the MFP onto the hook of the transfer unit.
16. Remove the tape and pull out the 13-pin connector and 24-pin connector.




Figure 1-3-47

17. Connect the 24-pin connector of the intermediate tray to the connector of the transfer unit.
18. Connect the 13-pin connector of the intermediate tray to YC5 on the engine circuit board.




Figure 1-3-48

Attach the covers.

19. Attach the cover that has been removed by Procedure 8 to its original position using the two screws.
20. Attach the large ejection cover with the two screws that have been removed by Procedure 1.




Figure 1-3-49

21. Attach the front ejection cover and rear ejection cover using the TP bind screw M3 x 06 each.




Figure 1-3-50

22. Open the front cover.
 23. Attach the staple cover as it is fitted to the staple unit from the ejection side and then secure it using the TP bind screw M3 x 06.
 24. Attach the inner cover that has been removed by Procedure 3 to its original position.
 25. Close the front cover.




Figure 1-3-51

26. Insert the front and rear hooks of the copy tray into the front ejection cover and rear ejection cover each and then attach the copy tray.




Figure 1-3-52

27. Open the staple cover and then insert the staple cartridge into the staple unit.
 28. Close the staple cover.




Figure 1-3-53

Operation check

1. Insert the MFP power plug into an outlet and then turn the power switch on.
2. Select the staple mode and check the staple operation.

1-3-9 Installing the job separator (option)

<Procedure>

Remove the covers.

1. Open the front cover.
2. Remove the inner cover.




Figure 1-3-54

3. Release the fitting parts using a small screw driver or the like and remove the front side cover.




Figure 1-3-55

4. Remove the screw and the fitting part located on the right side and then remove the left front cover.




Figure 1-3-56

5. Remove the three screws and then remove the ejection cover and inner ejection cover.




Figure 1-3-57

6. Remove the two screws and then remove the cover.






Figure 1-3-58

Attach the job separator.

7. Insert the job separator from the MFP front side and slide it to the left to install to the ejection part.
8. Place the job separator closer to the ejection side and then secure the front side (left tapped hole) with the large pin and the rear side with the small pin.


**Figure 1-3-59**

9. Loosen the screw that secures the drive unit located at the rear side of the job separator to make it ready for starting to drive and then retighten the screw.
10. Connect the connector of the job separator to YC5 on the engine circuit board.
11. Attach the cover that has been removed by Procedure 6 to its original position using the two screws.


**Figure 1-3-60**

Attach the copy tray.

12. Insert the left part of the copy tray into the groove of the job separator. Fit the right hook into the hole located inside of MFP while pushing the copy tray to the back along the groove.

**Figure 1-3-61****Attach the left front cover JS.**

13. Pull out the connector of the job separator from the hole of the left front cover that has been removed by Procedure 4 and then attach the left front cover to its original position using the screw.

**Figure 1-3-62**

14. Connect the pulled out connector of the job separator to the LED PCB of the left front cover JS and then pass the wire through the two positions of the groove of the left front cover JS.




Figure 1-3-63

15. Fit the pawl of the left front cover JS into the hole of the left front cover to attach the left front cover JS.
* In this time, take care that the routed wire in the groove does not come off.
16. Attach the inner cover that has been removed by Procedure 2 to its original position.
17. Close the front cover.




Figure 1-3-64

Operation check

1. Insert the power plug of the MFP into an outlet and then turn the power switch on.
2. Set the "copy ejection location" of the machine default settings to job separator.
3. Make a test copy to check that a copy is ejected to the job separator tray.

1-3-10 Installing the fax system (option)

<Procedure>

Install the optional Memory module DIMM (32MB).

1. Remove the two connectors of the fax control PCB assembly.
2. Remove the three screws and remove the mounting plate and the ground wire.




Figure 1-3-65

3. Insert the memory module DIMM at an angle into the memory slot so that the notch of the memory DIMM is positioned to the projection of the memory slot on the fax control PCB assembly. (1)
4. Push the free end of the module down toward the board. (2)
5. Attach the mounting plate and the ground wire that have been removed by Procedure 2 with the three screws to their original positions.
6. Connect the two connectors that have been removed by Procedure 1.






Figure 1-3-66

Remove the shield cover.


7. Remove the six screws, lift the shield cover and then remove the cover.

**Figure 1-3-67****Remove the modular cover.**

8. Remove the screw and take off the modular cover.

**Figure 1-3-68****Attach the fax control PCB assembly.**

9. Loosen the screw on the printer board.
10. While taking care that the mounting surface of the board does not contact the frame section of the rear cover, insert the U terminal of the ground wire of the fax control PCB assembly and secure it with the screw.

**Figure 1-3-69**

11. Connect the YC1 connector on the fax control PCB assembly to the YC15 connector on the engine PCB.
12. Insert the fax control PCB assembly to the shield box so that the projection of the fax control PCB assembly is positioned to the slit of the shield box.
13. Secure the fax control PCB assembly using the three TP tap tight screws M3 x 6.
Take care that the ground wire is not put on the frame section of the rear cover.




Figure 1-3-70

Attach the NCU PCB assembly.

14. Connect the NCU wire connector on the NCU PCB assembly to the YC2 connector on the fax control PCB assembly.




Figure 1-3-71

15. Secure the NCU PCB assembly using the four TP tap tight screws M3 x 6, paying attention so that the tape section of the shield box does not contact with the PCB.






Figure 1-3-72

Attach the modular cover.


16. Attach the modular cover that has been removed by Procedure 8 with the screw to the position shown in the illustration.

**Figure 1-3-73****Install the shield cover.**

17. Insert the lower part of the shield cover that has been removed by Procedure 7 into the shield box and then attach it with the six screws and TP tap tight screw M4 x 6 to its original position.


**Figure 1-3-74****Connect the telephone line to the line terminal.**

18. Insert the modular connector cable to the line terminal to connect it to the telephone line.
For 120 V specifications, use supplied modular cord B.


**Figure 1-3-75**

Attach the operation section sheet for fax.


19. Insert the small screw driver into the two points of the opening and remove the left cover of the operation section.

**Figure 1-3-76**

20. Lift the two pawls and remove the operation section sheet cover.

**Figure 1-3-77**

21. Remove the operation section sheet and replace it with the operation section sheet for fax of the corresponding language.

**Figure 1-3-78**

22. Fit in the right-side two pawls of the operation section sheet cover that has been removed by Procedure 20 and then attach the operation section sheet cover to its original position.




Figure 1-3-79

Attach the one-touch securing sheet.

23. Remove the release paper from the one-touch securing sheet.
 24. Adhere the one-touch securing sheet on the base frame of the one-touch key so that it sticks fast to the surface while matching the top surface to the top left corner and firmly pressing the whole area down as shown in the illustration.
 25. Push all the one-touch keys to check that the onetouch securing sheet does not block any one-touch key.




Figure 1-3-80

Attach the fax label (220-240 V specifications only).

26. Adhere the fax labels (1) to (4) of the fax label sheet of the corresponding language at the positions for the cover plate shown in the illustration.






Figure 1-3-81

Attach the cover plate.

27. Incurvate the cover plate a little and then insert the upper and lower projections to the fitting parts of the operation section to attach.
28. Check that the cover plate smoothly moves on either side.


**Figure 1-3-82****Attach the one-touch sheet.**

29. Divide the one-touch sheet of the corresponding language into two parts and then mount them on the one-touch securing sheet each.
- Bring back the left cover of the operation section that has been removed by Procedure 19, operation section sheet that has been removed by Procedure 21, operation section sheet for fax that corresponds to the unused languages, and the one-touch sheet.


**Figure 1-3-83**

Attach the alphabet labels.

30. Take the alphabet labels from the one-touch label sheet, and adhere them above the corresponding numeric keys on the operation panel after wiping the panel with alcohol. In Asia and Oceania, use the PQRS TUV WXYZ label, and do not use the PRS TUV WXZ and OPER labels.

**Figure 1-3-84****Attach the certification label (120 V specifications only).**

31. Adhere the FCC68 label onto the shield cover after wiping the cover with alcohol.

**Figure 1-3-85****Execute the maintenance mode.**

After installation is complete, the fax control PCB must be initialized by executing the maintenance mode U601/U602.

(See the service manual of the fax system.)

1-3-11 Installing the scan system (option)

<Procedure>

Remove the covers.

1. Remove the six screws (a), lift the shield cover and then remove the cover.
If the fax system is installed, remove the six screws (a) and screw (b), lift the shield cover and then remove the cover.
2. Remove the two screws, and take off the cover.




Figure 1-3-86

Install the scanner board.

3. Insert the scanner board into the OPT1 opening of the shield box and firmly push the CN5 connector on the scanner board all the way into the YC12 connector on the engine circuit board.




Figure 1-3-87

4. Fasten the scanner board onto the shield box cover using the two screws that have been removed by Procedure 2.




Figure 1-3-88

Install the shield cover.

5. Insert the lower part of the shield cover that has been removed by Procedure 1 into the shield box and refit it to its original position using the six screws (a).

If the fax system is installed, refit the shield cover using the six screws (a) and screw (b) to its original position.




Figure 1-3-89

1-3-12 Installing the hard disk (option)

<Procedure>

1. Remove the two screws of the slot for OPT2 which is on the machine right back, and then remove the cover.
2. Insert the hard disk in the socket on the printer board PCB.
3. Refit the cover which is removed with step 1.
4. Turn the power switch on and initialize the hard disk at the printer menu.
5. Output the printer status report and confirm whether the hard disk is recognized.





Figure 1-3-90

1-4-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Content of maintenance item	Initial setting*
General	U000	Outputting an own-status report	-
	U001	Exiting the maintenance mode	-
	U002	Setting the factory default data	-
	U003	Setting the service telephone number	*****
	U004	Displaying the machine number	-
	U005	Copying without paper	-
	U019	Displaying the ROM version	-
Initialization	U020	Initializing all data	-
	U021	Initializing memories	-
	U022	Initializing backup memory	-
	U026	Evacuation of backup data	-
	U027	Return of backup data	-
Drive, paper feed, paper conveying and cooling system	U030	Checking motor operation	-
	U031	Checking switches for paper conveying	-
	U032	Checking clutch operation	
	U034	Adjusting the print start timing Adjusting the leading edge registration Adjusting the center line Adjusting the trailing edge margin	4.0/3.6/3.6/3.6/3.6/4.5 -1.0/0.4/-1.2/-1.2/-1.2/0.3 -2.0
	U035	Setting folio size Length Width	330 210
	U051	Adjusting the amount of slack in the paper	-10/-15/15/-20/-20/-5
	U053	Performing fine adjustment of the motor speed	-0.3/0/-0.6/0.5/-0.1/-0.1/ -0.2/-1.3/-1.5/0.6
	U055	Setting the motor periodic drive	1/30
	U059	Setting the fan mode	5
Optical	U060	Adjusting the scanner input properties	12
	U061	Turning the exposure lamp on	-
	U063	Adjusting the shading position	0
	U065	Adjusting the scanner magnification Main scanning direction/auxiliary scanning direction	0/-12
	U066	Adjusting the leading edge registration for scanning an original on the contact glass	10/0
	U067	Adjusting the center line for scanning an original on the contact glass	-4/0
	U068	Adjusting the scanning position for originals from the DP	0
	U070	Adjusting the DP magnification	0/0
	U071	Adjusting the DP scanning timing	0/0/0/0
	U072	Adjusting the DP center line	0/0/0
	U073	Checking scanner operation	-
	U074	Adjusting the DP input light luminosity	0
	U076	Executing DP automatic adjustment	-
	U087	Turning the DP scanning position adjust mode on/off	ON/35
	U089	Outputting a MIP-PG pattern	-
	U092	Adjusting the scanner automatically	-

*Initial setting for executing maintenance item U020

Section	Item No.	Content of maintenance item	Initial setting*
Optical	U093	Setting the exposure density gradient Text and photo/text/photo/text in fax mode/photo in fax mode	0/0/0/2/3
	U099	Checking the original size detection	-
High voltage	U100	Checking the operation of main high voltage	60/50/10
	U101	Setting high voltages Developing bias Transfer voltage Separation voltage	25/50/98 155/166/29/28 1/27/38/0
	U110	Checking/clearing the drum count	-
	U113	Performing drum refresh operation	-
	U117	Checking the drum number	-
	U118	Displaying the drum history	-
Developing	U130	Initial setting for the developer	-
	U135	Checking toner motor operation	3
	U144	Setting toner loading operation	OFF/5/30
	U157	Checking/clearing the developing drive time	-
	U158	Checking the developing count	-
Fixing and cleaning	U161	Setting the fixing control temperature Primary stabilization fixing temperature Secondary stabilization fixing temperature Copying operation temperature 1 Copying operation temperature 2 Number of sheets for fixing control Number of sheets for fixing control (thick paper)	152 170 180 190 5 30
	U162	Stabilizing fixing forcibly	-
	U163	Resetting the fixing problem data	-
	U167	Checking the fixing counts	-
	U199	Checking the fixing temperature	-
Operation panel and support equipment	U200	Turning all LEDs on	-
	U202	Setting the KMAS host monitoring system	-
	U203	Checking DP operation	-
	U204	Setting the presence or absence of a key card or key counter	OFF
	U207	Checking the operation panel keys	-
	U233	Setting the ejection limit of the job separator	MODE0
	U243	Checking the operation of the DP motors and solenoids	-
	U244	Checking the DP switches	-
	U245	Checking messages	-
	U246	Setting the finisher	4/4/4
Mode setting	U249	Checking the paper ejection to optional devices	-
	U250	Setting the maintenance cycle	300000
	U251	Checking/clearing the maintenance count	-
	U252	Setting the destination	Japan
	U253	Switching between double and single counts	Double count
	U254	Turning auto start function on/off	ON
	U258	Switching copy operation at toner empty detection	Single mode
	U260	Changing the copy count timing	After ejection

*Initial setting for executing maintenance item U020

Section	Item No.	Content of maintenance item	Initial setting*
Mode setting	U264	Setting the display order of the date	Inch specifications: MONTH-DATE-YEAR Metric specifications: DATE-MONTH-YEAR
	U265	Setting OEM purchaser code	-
	U277	Setting auto application change time	30
	U326	Setting the black line cleaning indication	ON
	U332	Setting the size conversion factor	1.0/1.0/1.0
	U341	Specific paper feed location setting for printing function	-
	U342	Setting the ejection restriction	ON
	U343	Switching between duplex/simplex copy mode	OFF
	U344	Setting preheat/energy saver mode	Inch specifications: ENERGY STAR Metric specifications: GEEA
	U345	Setting the value for maintenance due indication	-
Image processing	U402	Adjusting margins of image printing	3.0/3.0/4.0
	U403	Adjusting margins for scanning an original on the contact glass	2.0/3.0/2.0/2.0
	U404	Adjusting margins for scanning an original from the DP	2.0/3.0/2.0/2.0
	U407	Adjusting the leading edge registration for memory image printing	0.0
Network scanner	U504	Initializing the scanner NIC	-
	U506	Setting the time out	10
Others	U901	Checking/clearing copy counts by paper feed locations	-
	U903	Checking/clearing the paper jam counts	-
	U904	Checking/clearing the service call counts	-
	U905	Checking counts by optional devices	-
	U906	Resetting partial operation control	-
	U908	Changing the total counter value	-
	U910	Clearing the black ratio data	-
	U911	Checking/clearing copy counts by paper sizes	-
	U917	Setting backup data reading/writing	-
	U920	Checking the accounting counts	-
	U925	Checking/clearing the system error counts	-
	U926	Rewriting FAX program	-
	U927	Clearing the all accounting counts and machine life counts	-
	U928	Checking machine life counts	-
	U941	Setting the default magnification ratio of the default drawer	100 %
	U942	Adjusting the DP amount of slack in the original	0/0
	U984	Checking the developing unit number	-
	U985	Displaying the developing unit history	-
	U990	Checking/clearing the time for the exposure lamp to light	-
	U991	Checking the scanner count	-
	U993	Outputting a VTC-PG pattern	-

*Initial setting for executing maintenance item U020

(3) Contents of the maintenance mode items

Maintenance item No.	Description								
U000	<p>Outputting an own-status report</p> <p>Description Outputs lists of the current settings of the maintenance items, and paper jam and service call occurrences.</p> <p>Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be output using the up/down cursor keys. The selected item is displayed in reverse. <table border="1"> <thead> <tr> <th>Display</th><th>Output list</th></tr> </thead> <tbody> <tr> <td>MAINTENANCE</td><td>List of the current settings of the maintenance modes</td></tr> <tr> <td>JAM</td><td>List of the paper jam occurrences</td></tr> <tr> <td>SERVICE CALL</td><td>List of the service call occurrences</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The interrupt print mode is entered and a list is output. When A4/11" x 8 1/2" paper is available, a report of this size is output. If not, specify the paper feed location. When output is complete, the screen for selecting an item is displayed. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	MAINTENANCE	List of the current settings of the maintenance modes	JAM	List of the paper jam occurrences	SERVICE CALL	List of the service call occurrences
Display	Output list								
MAINTENANCE	List of the current settings of the maintenance modes								
JAM	List of the paper jam occurrences								
SERVICE CALL	List of the service call occurrences								
U001	<p>Exiting the maintenance mode</p> <p>Description Exits the maintenance mode and returns to the normal copy mode.</p> <p>Purpose To exit the maintenance mode.</p> <p>Method Press the start key. The normal copy mode is entered.</p>								
U002	<p>Setting the factory default data</p> <p>Description Restores the machine conditions to the factory default settings.</p> <p>Purpose To move the mirror frame of the scanner to the position for transport (position in which the frame can be fixed).</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. The mirror frame of the scanner returns to the position for transport. <p>Completion The power switch turns off.</p>								

Maintenance item No.	Description														
U003	<p>Setting the service telephone number</p> <p>Description Sets the telephone number to be displayed when a service call code is detected.</p> <p>Purpose To set the telephone number to call service when installing the machine.</p> <p>Method Press the start key. The currently set telephone number is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Enter a telephone number (up to 15 digits) using the numeric keys. Move the cursor using the left/right cursor keys and select a number or symbol using the up/down cursor keys. To enter symbols, press the keys shown below as required. <table border="1" data-bbox="331 622 1093 884"> <thead> <tr> <th>Key</th><th>Symbol</th></tr> </thead> <tbody> <tr> <td>* key</td><td>*</td></tr> <tr> <td># key</td><td>#</td></tr> <tr> <td>Image mode selection key</td><td>(</td></tr> <tr> <td>Aoto mode selection key</td><td>)</td></tr> <tr> <td>Lighter key</td><td>-</td></tr> <tr> <td>Darker key</td><td>Space</td></tr> </tbody> </table> <ol style="list-style-type: none"> 2. Press the start key. The phone number is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Key	Symbol	* key	*	# key	#	Image mode selection key	(Aoto mode selection key)	Lighter key	-	Darker key	Space
Key	Symbol														
* key	*														
# key	#														
Image mode selection key	(
Aoto mode selection key)														
Lighter key	-														
Darker key	Space														
U004	<p>Displaying the machine number</p> <p>Description Displays the machine number.</p> <p>Purpose To check the machine number.</p> <p>Method Press the start key. The currently machine number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>														

Maintenance item No.	Description						
U005	<p>Copying without paper</p> <p>Description Simulates the copy operation without paper feed.</p> <p>Purpose To check the overall operation of the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be operated using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="331 506 1398 620"> <thead> <tr> <th>Display</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>PPC</td><td>Only the MFP operates.</td></tr> <tr> <td>PPC + DP</td><td>Both the MFP and DP operate (continuous operation).</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the interrupt key. The copy mode screen is displayed. 4. Set the operation conditions required on the copy mode screen. Changes in the following settings can be made. Paper feed locations Magnifications Simplex or duplex copy mode Number of copies: in simplex copy mode, continuous copying is performed when set to 999; in duplex copy mode, continuous copying is performed regardless of the setting. Copy density Keys on the operation panel other than the energy saver (preheat) key 5. To control the paper feed pulley, remove all the paper in the drawers, or the drawers. With the paper present, the paper feed pulley does not operate. 6. Press the start key. The operation starts. Copy operation is simulated without paper under the set conditions. When operation is complete, the screen for selecting an item is displayed. 7. To stop continuous operation, press the stop/clear key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	PPC	Only the MFP operates.	PPC + DP	Both the MFP and DP operate (continuous operation).
Display	Operation						
PPC	Only the MFP operates.						
PPC + DP	Both the MFP and DP operate (continuous operation).						


Maintenance item No.	Description																										
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PCB.</p> <p>Purpose To check the part number or to decide if the ROM version is new from the last digit of the number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The part number indicating the ROM version are displayed. 2. Change the screen using the up/down cursor keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Main ROM IC</td></tr> <tr> <td>ENGINE</td><td>Engine ROM IC</td></tr> <tr> <td>LANG(St)</td><td>Standard language ROM IC</td></tr> <tr> <td>LANG(Op)</td><td>Optional language ROM IC</td></tr> <tr> <td>MAIN BOOT</td><td>Boot of main ROM IC</td></tr> <tr> <td>PRINTER</td><td>Printer board ROM IC</td></tr> <tr> <td>NWS</td><td>Network scanner* ROM IC</td></tr> <tr> <td>DP</td><td>DP* ROM IC</td></tr> <tr> <td>FINISHER</td><td>Finisher* ROM IC</td></tr> <tr> <td>CASS2</td><td>First paper feeder ROM IC</td></tr> <tr> <td>CASS3</td><td>Second paper feeder* ROM IC</td></tr> <tr> <td>CASS4</td><td>Third paper feeder* ROM IC</td></tr> </tbody> </table> <p>*: Optional.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main ROM IC	ENGINE	Engine ROM IC	LANG(St)	Standard language ROM IC	LANG(Op)	Optional language ROM IC	MAIN BOOT	Boot of main ROM IC	PRINTER	Printer board ROM IC	NWS	Network scanner* ROM IC	DP	DP* ROM IC	FINISHER	Finisher* ROM IC	CASS2	First paper feeder ROM IC	CASS3	Second paper feeder* ROM IC	CASS4	Third paper feeder* ROM IC
Display	Description																										
MAIN	Main ROM IC																										
ENGINE	Engine ROM IC																										
LANG(St)	Standard language ROM IC																										
LANG(Op)	Optional language ROM IC																										
MAIN BOOT	Boot of main ROM IC																										
PRINTER	Printer board ROM IC																										
NWS	Network scanner* ROM IC																										
DP	DP* ROM IC																										
FINISHER	Finisher* ROM IC																										
CASS2	First paper feeder ROM IC																										
CASS3	Second paper feeder* ROM IC																										
CASS4	Third paper feeder* ROM IC																										
U020	<p>Initializing all data</p> <p>Description Initializes all the backup RAM on the main PCB to return to the original settings.</p> <p>Purpose Run as needed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All data in the backup RAM is initialized, and the original settings for Japan specifications are set. <p>When initialization is complete, the machine automatically returns to the same status as when the main switch is turned on.</p> <p>Completion To exit this maintenance item without executing initialization, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																										
U021	<p>Initializing memories</p> <p>Description Initializes the setting data other than that for adjustments due to variations between respective machines, i.e., settings for counters, service call history and mode settings. As a result, initializes the backup RAM according to the specifications depending on the destination selected in U252.</p> <p>Purpose Used to return the machine settings to the factory settings.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting. <p>Completion To exit this maintenance item without executing initialization, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																										

Maintenance item No.	Description								
U022	<p>Initializing backup memory</p> <p>Description Initializes only the data set for the optical section or initializes various setting data when installing the optional network scanner board.</p> <p>Purpose To be executed after replacing the scanner unit or installing the network scanner board.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. The data for the optical section (U060 to 067, U092 to 099, U403, U990 and U991) is initialized. The setting data of scanner function initial settings are initialized, and the registered transmission and reception are cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U026	<p>Evacuation of backup data</p> <p>Description Transfers the backup data of the main PCB to the EEPROM.</p> <p>Purpose Used when replacing the main PCB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key to transfer the backup data. The screen displays the result. <p>EXECUTE CHECK SUM: **** CODE : XXXX (See the table below)</p> <table border="1" data-bbox="331 1099 1398 1252"> <thead> <tr> <th>Code</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0000</td><td>Processing ends correctly.</td></tr> <tr> <td>0101</td><td>Verification abnormality occurs.</td></tr> <tr> <td>0102</td><td>Verification abnormality occurs at the time of check sum entry.</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the stop/clear key. The screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Code	Description	0000	Processing ends correctly.	0101	Verification abnormality occurs.	0102	Verification abnormality occurs at the time of check sum entry.
Code	Description								
0000	Processing ends correctly.								
0101	Verification abnormality occurs.								
0102	Verification abnormality occurs at the time of check sum entry.								

Maintenance item No.	Description																
U027	<p>Return of backup data</p> <p>Description Transfers the backup data of the EEPROM which was transferred with the U026 to flash memory.</p> <p>Purpose To use after the main PCB replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key to transfer the backup data. The screen displays the result. <p>EXECUTE CHECK SUM: **** CODE : XXXX (See the table below)</p> <table border="1"> <thead> <tr> <th>Code</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0000</td><td>Processing ends correctly.</td></tr> <tr> <td>0203</td><td>Check sum does not agree when reading out from the EEPROM.</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. Disconnect and connect the power plug. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Code	Description	0000	Processing ends correctly.	0203	Check sum does not agree when reading out from the EEPROM.										
Code	Description																
0000	Processing ends correctly.																
0203	Check sum does not agree when reading out from the EEPROM.																
U030	<p>Checking motor operation</p> <p>Description Drives each motor.</p> <p>Purpose To check the operation of each motor.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the motor to be operated using the up/down cursor keys. 3. Press the start key. The operation starts. <table border="1"> <thead> <tr> <th>Display</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Drive motor (DM) operates</td></tr> <tr> <td>RES</td><td>Registration motor (RM) operates</td></tr> <tr> <td>T1</td><td>Drawer drive motor 1 (DDM1) operates</td></tr> <tr> <td>T2</td><td>Drawer drive motor 2* (DDM2) operates</td></tr> <tr> <td>T3</td><td>Drawer drive motor 3* (DDM3) operates</td></tr> <tr> <td>EJE1</td><td>Eject motor rotates forward</td></tr> <tr> <td>EJE2</td><td>Eject motor rotates in reverse</td></tr> </tbody> </table> <p>*: Optional.</p> <ol style="list-style-type: none"> 4. To stop operation, press the stop/clear key. <p>Completion Press the stop key after operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	MAIN	Drive motor (DM) operates	RES	Registration motor (RM) operates	T1	Drawer drive motor 1 (DDM1) operates	T2	Drawer drive motor 2* (DDM2) operates	T3	Drawer drive motor 3* (DDM3) operates	EJE1	Eject motor rotates forward	EJE2	Eject motor rotates in reverse
Display	Operation																
MAIN	Drive motor (DM) operates																
RES	Registration motor (RM) operates																
T1	Drawer drive motor 1 (DDM1) operates																
T2	Drawer drive motor 2* (DDM2) operates																
T3	Drawer drive motor 3* (DDM3) operates																
EJE1	Eject motor rotates forward																
EJE2	Eject motor rotates in reverse																

Maintenance item No.	Description																
U031	<p>Checking switches for paper conveying</p> <p>Description Displays the on-off status of each paper detection switch on the paper path.</p> <p>Purpose To check if the switches for paper conveying operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. A list of the switches, the on-off status of which can be checked, are displayed. 2. Turn each switch on and off manually to check the status. <p>When the on-status of a switch is detected, that switch is displayed in reverse.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Switches</th></tr> </thead> <tbody> <tr> <td>EJE</td><td>Eject switch (ESW)</td></tr> <tr> <td>RES</td><td>Registration switch (RSW)</td></tr> <tr> <td>PF2</td><td>Drawer feed switch 1 (DFSW1)</td></tr> <tr> <td>PF3</td><td>Drawer feed switch 2* (DFSW2)</td></tr> <tr> <td>BRA</td><td>Feedshift switch (FSSW)</td></tr> <tr> <td>DUP</td><td>Duplex paper conveying switch* (DUPPCSW)</td></tr> <tr> <td>JOB</td><td>Job separator eject switch* (JBESW)</td></tr> </tbody> </table> <p>*: Optional.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	EJE	Eject switch (ESW)	RES	Registration switch (RSW)	PF2	Drawer feed switch 1 (DFSW1)	PF3	Drawer feed switch 2* (DFSW2)	BRA	Feedshift switch (FSSW)	DUP	Duplex paper conveying switch* (DUPPCSW)	JOB	Job separator eject switch* (JBESW)
Display	Switches																
EJE	Eject switch (ESW)																
RES	Registration switch (RSW)																
PF2	Drawer feed switch 1 (DFSW1)																
PF3	Drawer feed switch 2* (DFSW2)																
BRA	Feedshift switch (FSSW)																
DUP	Duplex paper conveying switch* (DUPPCSW)																
JOB	Job separator eject switch* (JBESW)																
U032	<p>Checking clutch operation</p> <p>Description Turns each clutch on.</p> <p>Purpose To check the operation of each clutch.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the clutch to be operated using the up/down cursor keys. 3. Press the start key. The clutch turns on for 1 s. <table border="1"> <thead> <tr> <th>Display</th><th>Clutches</th></tr> </thead> <tbody> <tr> <td>PF1</td><td>Paper feed clutch (PFCL)</td></tr> <tr> <td>PFBYP</td><td>Bypass paper feed solenoid (BYPPFSOL)</td></tr> <tr> <td>FEED1</td><td>Drawer paper feed clutch 1 (DPFCL1)</td></tr> <tr> <td>FEED2</td><td>Drawer paper feed clutch 2* (DPFCL2)</td></tr> <tr> <td>FEED3</td><td>Drawer paper feed clutch 3* (DPFCL3)</td></tr> </tbody> </table> <p>*: Optional.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Clutches	PF1	Paper feed clutch (PFCL)	PFBYP	Bypass paper feed solenoid (BYPPFSOL)	FEED1	Drawer paper feed clutch 1 (DPFCL1)	FEED2	Drawer paper feed clutch 2* (DPFCL2)	FEED3	Drawer paper feed clutch 3* (DPFCL3)				
Display	Clutches																
PF1	Paper feed clutch (PFCL)																
PFBYP	Bypass paper feed solenoid (BYPPFSOL)																
FEED1	Drawer paper feed clutch 1 (DPFCL1)																
FEED2	Drawer paper feed clutch 2* (DPFCL2)																
FEED3	Drawer paper feed clutch 3* (DPFCL3)																
U034	<p>Adjusting the print start timing</p> <p>Adjustment See pages 1-6-16 and 18.</p>																




Maintenance item No.	Description																																												
U035	<p>Setting folio size</p> <p>Description Changes the image area for copying onto folio size paper.</p> <p>Purpose To prevent the image at the trailing edge, or right or left side of the paper from not being copied by setting the actual size of the folio paper used.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Setting</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>LENGTH DATA</td><td>Length</td><td>330 to 356 mm</td><td>330</td></tr><tr><td>WIDTH DATA</td><td>Width</td><td>200 to 220 mm</td><td>210</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Setting	Setting range	Initial setting	LENGTH DATA	Length	330 to 356 mm	330	WIDTH DATA	Width	200 to 220 mm	210																																
Display	Setting	Setting range	Initial setting																																										
LENGTH DATA	Length	330 to 356 mm	330																																										
WIDTH DATA	Width	200 to 220 mm	210																																										
U051	<p>Adjusting the amount of slack in the paper</p> <p>Adjustment See page 1-6-21.</p>																																												
U053	<p>Performing fine adjustment of the motor speed</p> <p>Description Performs fine adjustment of the speeds of the motors.</p> <p>Purpose Used to adjust the speed of the respective motors when the magnification is not correct. Also speed adjustment for each paper source.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MAIN</td><td>Drive motor speed adjustment</td><td>-5.0 to +5.0</td><td>-0.3</td></tr><tr><td>POLY</td><td>Polygon motor speed adjustment</td><td>-5.0 to +4.0</td><td>0</td></tr><tr><td>EJE</td><td>Eject motor speed adjustment</td><td>-5.0 to +5.0</td><td>-0.6</td></tr><tr><td>RES</td><td>Registration motor speed adjustment</td><td>-5.0 to +5.0</td><td>0.5</td></tr><tr><td>BYP</td><td>Motor speed adjustment (for paper feed from bypass tray)</td><td>-5.0 to +5.0</td><td>-0.1</td></tr><tr><td>CAS</td><td>Motor speed adjustment (for paper feed from paper feeder)</td><td>-5.0 to +5.0</td><td>-0.1</td></tr><tr><td>DUP</td><td>Motor speed adjustment (in duplex mode)</td><td>-5.0 to +5.0</td><td>-0.2</td></tr><tr><td>EJE2</td><td>Eject motor speed (optional ejection correction value in the case of paper size of A3, B4, and 11" x 17")</td><td>-5.0 to +5.0</td><td>-1.3</td></tr><tr><td>EJE3</td><td>Eject motor speed (optional ejection correction value in the case of paper size other than those above)</td><td>-5.0 to +5.0</td><td>-1.5</td></tr><tr><td>EJE4</td><td>Eject motor speed (ejection motor correction value at the time of duplex inner ejection)</td><td>0 to +5.0</td><td>0.6</td></tr></table>	Display	Description	Setting range	Initial setting	MAIN	Drive motor speed adjustment	-5.0 to +5.0	-0.3	POLY	Polygon motor speed adjustment	-5.0 to +4.0	0	EJE	Eject motor speed adjustment	-5.0 to +5.0	-0.6	RES	Registration motor speed adjustment	-5.0 to +5.0	0.5	BYP	Motor speed adjustment (for paper feed from bypass tray)	-5.0 to +5.0	-0.1	CAS	Motor speed adjustment (for paper feed from paper feeder)	-5.0 to +5.0	-0.1	DUP	Motor speed adjustment (in duplex mode)	-5.0 to +5.0	-0.2	EJE2	Eject motor speed (optional ejection correction value in the case of paper size of A3, B4, and 11" x 17")	-5.0 to +5.0	-1.3	EJE3	Eject motor speed (optional ejection correction value in the case of paper size other than those above)	-5.0 to +5.0	-1.5	EJE4	Eject motor speed (ejection motor correction value at the time of duplex inner ejection)	0 to +5.0	0.6
Display	Description	Setting range	Initial setting																																										
MAIN	Drive motor speed adjustment	-5.0 to +5.0	-0.3																																										
POLY	Polygon motor speed adjustment	-5.0 to +4.0	0																																										
EJE	Eject motor speed adjustment	-5.0 to +5.0	-0.6																																										
RES	Registration motor speed adjustment	-5.0 to +5.0	0.5																																										
BYP	Motor speed adjustment (for paper feed from bypass tray)	-5.0 to +5.0	-0.1																																										
CAS	Motor speed adjustment (for paper feed from paper feeder)	-5.0 to +5.0	-0.1																																										
DUP	Motor speed adjustment (in duplex mode)	-5.0 to +5.0	-0.2																																										
EJE2	Eject motor speed (optional ejection correction value in the case of paper size of A3, B4, and 11" x 17")	-5.0 to +5.0	-1.3																																										
EJE3	Eject motor speed (optional ejection correction value in the case of paper size other than those above)	-5.0 to +5.0	-1.5																																										
EJE4	Eject motor speed (ejection motor correction value at the time of duplex inner ejection)	0 to +5.0	0.6																																										


Maintenance item No.	Description												
U053	<p>MAIN MOTOR Increasing the setting makes the image longer in the auxiliary scanning direction, and decreasing it makes the image shorter in the auxiliary scanning direction.</p> <p>POLYGON MOTOR Increasing the setting makes the image longer in the main scanning direction and shorter in the auxiliary scanning direction; decreasing the setting makes the image shorter in the main scanning direction and longer in the auxiliary scanning direction.</p> <p>3. Press the start key. The value is set.</p> <p>Interrupt copy mode While this maintenance item is being performed, a VTC pattern shown below is output in interrupt copy mode.</p> <p>1. Press the interrupt key. The machine enters the interrupt copy mode.</p> <p>2. Press the start key. A VTC pattern is output.</p> <p>To return to the screen for setting, press the interrupt key.</p> <p>Correct values for an A3/11" x 17" output are: A = 300 ± 1.5 mm B = 270 ± 1.35 mm</p> <div></div> <p>Figure 1-4-1</p> <p>Adjustment</p> <p>1. Output an A3/11" x 17" VTC pattern in interrupt copy mode.</p> <p>2. Measure A and B on the VTC pattern (Figure 1-4-1), and perform the following adjustments if they are different from the correct sizes: A: Drive motor speed adjustment B: Polygon motor speed adjustment</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>												
U055	<p>Setting the motor periodic drive</p> <p>Description Specifies ON/OFF the drum small rotation mode. Also changes the drum drive overtime after displaying Ready and/or returning from the sleep mode.</p> <p>Purpose To be set according to user request.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <p>1. Select the item to be set using the up/down cursor keys.</p> <p>2. Change the setting using the left/right cursor keys.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>DRIVE</td><td>Drum small rotation mode ON/OFF</td><td>0 (OFF)/1 (ON)</td><td>1</td></tr><tr><td>TIME</td><td>Drum drive overtime</td><td>10 to 60 (s)</td><td>30</td></tr></table> <p>3. Press the start key. The value is set.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	DRIVE	Drum small rotation mode ON/OFF	0 (OFF)/1 (ON)	1	TIME	Drum drive overtime	10 to 60 (s)	30
Display	Description	Setting range	Initial setting										
DRIVE	Drum small rotation mode ON/OFF	0 (OFF)/1 (ON)	1										
TIME	Drum drive overtime	10 to 60 (s)	30										

Maintenance item No.	Description						
U059	<p>Setting the fan mode</p> <p>Description Setting the rotation time of a cooling fan motor 2.</p> <p>Purpose Change the value when the image flow occurs.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <p>1. Change the setting using the left/right cursor keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Rotation time of cooling fan motor 2</td><td>0 to +30 (s)</td><td>5</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Rotation time of cooling fan motor 2	0 to +30 (s)	5
Description	Setting range	Initial setting					
Rotation time of cooling fan motor 2	0 to +30 (s)	5					
U060	<p>Adjusting the scanner input properties</p> <p>Description Adjusts the image scanning density in text, text and photo, or photo mode.</p> <p>Purpose Used when the entire image appears too dark or light.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <p>1. Change the setting using the left/right cursor keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Image scannnig density</td><td>1 to +23</td><td>12</td></tr></table> <p>Increasing the setting makes the density lower, and decreasing it makes the density higher.</p> <p>2. Press the start key. The value is set.</p> <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <p>1. Press the interrupt key. The machine enters the interrupt copy mode.</p> <p>2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key.</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Image scannnig density	1 to +23	12
Description	Setting range	Initial setting					
Image scannnig density	1 to +23	12					
U061	<p>Turning the exposure lamp on</p> <p>Description Turns the exposure lamp on.</p> <p>Purpose To check the exposure lamp.</p> <p>Method</p> <p>1. Press the start key. The screen for executing is displayed.</p> <p>2. Press the start key. The exposure lamp lights.</p> <p>3. To turn the exposure lamp off, press the stop/clear key.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						

Maintenance item No.	Description								
U063	<p>Adjusting the shading position</p> <p>Description Changes the shading position.</p> <p>Purpose Used when white lines continue to appear longitudinally on the image after the shading plate is cleaned. This is due to flaws or stains inside the shading plate. To prevent this problem, the shading position should be changed so that shading is possible without being affected by the flaws or stains.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for setting is displayed.2. Change the setting using the left/right cursor keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Shading position</td><td>-8 to +8</td><td>0</td><td>0.17 mm</td></tr></table> <p>Increasing the setting moves the shading position toward the machine right, and decreasing it moves the position toward the machine left.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the start key. <p>To return to the screen for setting, press the interrupt key.</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Shading position	-8 to +8	0	0.17 mm
Description	Setting range	Initial setting	Change in value per step						
Shading position	-8 to +8	0	0.17 mm						
U065	<p>Adjusting the scanner magnification</p> <p>Adjustment See pages 1-6-33 and 34.</p>								
U066	<p>Adjusting the leading edge registration for scanning an original on the contact glass</p> <p>Adjustment See page 1-6-35.</p>								
U067	<p>Adjusting the center line for scanning an original on the contact glass</p> <p>Adjustment See page 1-6-36.</p>								
U068	<p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP.</p> <p>Purpose Used when there is a regular error between the leading edges of the original and the copy image when the DP is used.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Change the setting using the left/right cursor keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Scanning position</td><td>-17 to +17</td><td>0</td><td>0.17 mm</td></tr></table> <p>Increasing the setting moves the image backward, and decreasing it moves the image forward.</p> <ol style="list-style-type: none">2. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Scanning position	-17 to +17	0	0.17 mm
Description	Setting range	Initial setting	Change in value per step						
Scanning position	-17 to +17	0	0.17 mm						

Maintenance item No.	Description															
U070	<p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose To be executed if the correct magnification is not obtained in the auxiliary scanning direction when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <p>U053 → U065 → U070</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>CONVEY SPEED1</td><td>Original conveying motor speed (simplex original)</td><td>-25 to +25</td><td>0</td><td>0.1%</td></tr><tr><td>CONVEY SPEED2</td><td>Original conveying motor speed (duplex original)</td><td>-25 to +25</td><td>0</td><td>0.1%</td></tr></table> <p>Increasing the setting makes the image longer, and decreasing it makes the image shorter.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	CONVEY SPEED1	Original conveying motor speed (simplex original)	-25 to +25	0	0.1%	CONVEY SPEED2	Original conveying motor speed (duplex original)	-25 to +25	0	0.1%
Display	Description	Setting range	Initial setting	Change in value per step												
CONVEY SPEED1	Original conveying motor speed (simplex original)	-25 to +25	0	0.1%												
CONVEY SPEED2	Original conveying motor speed (duplex original)	-25 to +25	0	0.1%												













Maintenance item No.	Description																									
U071	<p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose To be executed if there is a regular error between the leading or trailing edges of the original and the copy image when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <p>U034 → U066 → U071</p> <p>Method Press the start key. The screen for setting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>LEAD1</td><td>DP leading edge registration (simplex original)</td><td>-32 to +22</td><td>0</td><td>0.2 mm</td></tr><tr><td>TRAIL1</td><td>DP trailing edge registration (simplex original)</td><td>-22 to +32</td><td>0</td><td>0.2 mm</td></tr><tr><td>LEAD2</td><td>DP leading edge registration (duplex original)</td><td>-32 to +22</td><td>0</td><td>0.2 mm</td></tr><tr><td>TRAIL2</td><td>DP trailing edge registration (duplex original)</td><td>-22 to +32</td><td>0</td><td>0.2 mm</td></tr></table> <p>Increasing the setting moves the copy image backward, and decreasing it moves the copy image forward.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Adjustment</p> <ol style="list-style-type: none">1. In interrupt copy mode, make a copy using the DP.2. Check the copy image and adjust the registration as follows. For copy example 1, decrease the setting of LEAD1 or LEAD2. For copy example 2, increase the setting of LEAD1 or LEAD2. <div><div><p>Original</p></div><div><p>Copy example 1</p></div><div><p>Copy example 2</p></div></div> <p>Figure 1-4-2</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	LEAD1	DP leading edge registration (simplex original)	-32 to +22	0	0.2 mm	TRAIL1	DP trailing edge registration (simplex original)	-22 to +32	0	0.2 mm	LEAD2	DP leading edge registration (duplex original)	-32 to +22	0	0.2 mm	TRAIL2	DP trailing edge registration (duplex original)	-22 to +32	0	0.2 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
LEAD1	DP leading edge registration (simplex original)	-32 to +22	0	0.2 mm																						
TRAIL1	DP trailing edge registration (simplex original)	-22 to +32	0	0.2 mm																						
LEAD2	DP leading edge registration (duplex original)	-32 to +22	0	0.2 mm																						
TRAIL2	DP trailing edge registration (duplex original)	-22 to +32	0	0.2 mm																						

Maintenance item No.	Description																				
U072	<p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose To be executed if there is a regular error between the centers of the original and the copy image when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <p>U034 → U067 → U072</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>1 sided</td><td>Simplex copy mode</td><td>-39 to +39</td><td>0</td><td>0.1 mm</td></tr><tr><td>2 sided front</td><td>Front face in duplex copy mode</td><td>-39 to +39</td><td>0</td><td>0.1 mm</td></tr><tr><td>2 sided back</td><td>Reverse face in duplex copy mode</td><td>-39 to +39</td><td>0</td><td>0.1 mm</td></tr></table> <p>Increasing the setting moves the image to the right, and decreasing it moves the image to the left.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Adjustment</p> <ol style="list-style-type: none">1. In interrupt copy mode, make a copy using the DP.2. Check the copy image and adjust the center line as follows. For copy example 1, increase the setting. For copy example 2, decrease the setting. <div><p>Reference</p><p>Original Copy example 1 Copy example 2</p></div> <p>Figure 1-4-3</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	1 sided	Simplex copy mode	-39 to +39	0	0.1 mm	2 sided front	Front face in duplex copy mode	-39 to +39	0	0.1 mm	2 sided back	Reverse face in duplex copy mode	-39 to +39	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
1 sided	Simplex copy mode	-39 to +39	0	0.1 mm																	
2 sided front	Front face in duplex copy mode	-39 to +39	0	0.1 mm																	
2 sided back	Reverse face in duplex copy mode	-39 to +39	0	0.1 mm																	

Maintenance item No.	Description																																												
U073	<p>Checking scanner operation</p> <p>Description Simulates the scanner operation under arbitrary conditions.</p> <p>Purpose To check scanner operation.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the item to be changed using the up/down cursor keys. The selected item is displayed in reverse.3. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Operating conditions</th><th>Setting range</th></tr><tr><td>ZOOM</td><td>Magnification</td><td>100 to 400%</td></tr><tr><td>SIZE</td><td>Original size</td><td>See below.</td></tr><tr><td>LAMP</td><td>On and off of the exposure lamp</td><td>0 (off) or 1 (on)</td></tr></table> <p>Original sizes for each setting in SIZE</p> <table><tr><th>Setting</th><th>Paper size</th><th>Setting</th><th>Paper size</th></tr><tr><td>8</td><td>A4</td><td>42</td><td>A5R</td></tr><tr><td>9</td><td>B5</td><td>47</td><td>Folio</td></tr><tr><td>24</td><td>11" x 8 1/2"</td><td>52</td><td>11" x 17"</td></tr><tr><td>36</td><td>A3</td><td>53</td><td>11" x 15"</td></tr><tr><td>39</td><td>B4</td><td>55</td><td>8 1/2" x 14"</td></tr><tr><td>40</td><td>A4R</td><td>56</td><td>8 1/2" x 11"</td></tr><tr><td>41</td><td>B5R</td><td>58</td><td>5 1/2" x 8 1/2"</td></tr></table> <ol style="list-style-type: none">4. Press the start key. Scanning starts under the selected conditions.5. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key when scanning stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operating conditions	Setting range	ZOOM	Magnification	100 to 400%	SIZE	Original size	See below.	LAMP	On and off of the exposure lamp	0 (off) or 1 (on)	Setting	Paper size	Setting	Paper size	8	A4	42	A5R	9	B5	47	Folio	24	11" x 8 1/2"	52	11" x 17"	36	A3	53	11" x 15"	39	B4	55	8 1/2" x 14"	40	A4R	56	8 1/2" x 11"	41	B5R	58	5 1/2" x 8 1/2"
Display	Operating conditions	Setting range																																											
ZOOM	Magnification	100 to 400%																																											
SIZE	Original size	See below.																																											
LAMP	On and off of the exposure lamp	0 (off) or 1 (on)																																											
Setting	Paper size	Setting	Paper size																																										
8	A4	42	A5R																																										
9	B5	47	Folio																																										
24	11" x 8 1/2"	52	11" x 17"																																										
36	A3	53	11" x 15"																																										
39	B4	55	8 1/2" x 14"																																										
40	A4R	56	8 1/2" x 11"																																										
41	B5R	58	5 1/2" x 8 1/2"																																										
U074	<p>Adjusting the DP input light luminosity</p> <p>Description Adjusts the luminosity of the exposure lamp for scanning originals from the DP.</p> <p>Purpose Used if the exposure amount differs significantly between when scanning an original on the contact glass and when scanning an original from the DP.</p> <p>Method Press the start key.</p> <p>Setting</p> <ol style="list-style-type: none">1. Change the setting using the left/right cursor keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>DP input light luminosity</td><td>0 to 8</td><td>0</td></tr></table> <p>Increasing the setting makes the luminosity higher, and decreasing it makes the luminosity lower.</p> <ol style="list-style-type: none">2. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	DP input light luminosity	0 to 8	0																																						
Description	Setting range	Initial setting																																											
DP input light luminosity	0 to 8	0																																											

Maintenance item No.	Description								
U076	<p>Executing DP automatic adjustment</p> <p>Description Uses a specified original and automatically adjusts the following items in the DP scanning section. Adjusting the DP magnification (U070) Adjusting the DP scanning timing (U071) Adjusting the DP center line (U072) When you run this maintenance mode, the preset values of U070, U071 and U072 will also be updated.</p> <p>Purpose To perform automatic adjustment of various items in the DP scanning section.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Set a specified original (part number: 2A068021) in the DP. 2. Press the start key. The screen for executing is displayed. 3. Press the start key. Auto adjustment starts. When adjustment is complete, each adjusted value is displayed. <table border="1" data-bbox="331 680 1399 833"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>CONVEY SPEED</td><td>DP magnification in the auxiliary scanning direction</td></tr> <tr> <td>LEAD EDGE ADJ</td><td>DP leading edge registration</td></tr> <tr> <td>DP CENTER</td><td>DP original center line</td></tr> </tbody> </table> <p>If a problem occurs during auto adjustment, DATA: XX (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>Completion Press the stop/clear key after auto adjustment is complete. The screen for selecting a maintenance item is displayed. If the stop/clear key is pressed during auto adjustment, adjustment stops and no settings are changed.</p>	Display	Description	CONVEY SPEED	DP magnification in the auxiliary scanning direction	LEAD EDGE ADJ	DP leading edge registration	DP CENTER	DP original center line
Display	Description								
CONVEY SPEED	DP magnification in the auxiliary scanning direction								
LEAD EDGE ADJ	DP leading edge registration								
DP CENTER	DP original center line								

Maintenance item No.	Description												
U087	<p>Turning the DP scanning position adjust mode on/off</p> <p>Description Turns on or off the DP scanning position adjust mode, in which the DP original scanning position is adjusted automatically by determining the presence or absence of dust on the slit glass. Also changes the reference data for identifying dust.</p> <p>Reference In the DP original scanning position adjust mode, the presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose Used to prevent appearance of black lines due to dust adhering in the original scanning position on the slit glass when the DP is used.</p> <p>Setting</p> <div><div><div>1. Press the start key. The screen for selecting an item is displayed.</div><div>2. Select ON or OFF using the up/down cursor keys. The selected item is displayed in reverse.</div></div><table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>DP scanning position adjust mode on</td></tr><tr><td>OFF</td><td>DP scanning position adjust mode off</td></tr></table><p>Initial setting: ON</p><p>Available only when the mode is turned on.</p><div><div>3. Change the setting using the left/right cursor keys.</div><table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Minimum density to be regarded as dust</td><td>10 to 95</td><td>35</td></tr></table><p>Example</p><p>The figure indicates the density in 256 levels of gray (0: white, 255: black). When the setting is 35, data of the level of 35 or higher is regarded as dust and data of lower level is regarded as the background (scan data taken when there is no original).</p><div><div>4. Press the start key. The value is set.</div></div></div><p>Completion Press the stop/clear key. The indication for selecting a maintenance item No. appears.</p></div>	Display	Description	ON	DP scanning position adjust mode on	OFF	DP scanning position adjust mode off	Description	Setting range	Initial setting	Minimum density to be regarded as dust	10 to 95	35
Display	Description												
ON	DP scanning position adjust mode on												
OFF	DP scanning position adjust mode off												
Description	Setting range	Initial setting											
Minimum density to be regarded as dust	10 to 95	35											

Maintenance item No.	Description																								
U089	<p>Outputting a MIP-PG pattern</p> <p>Description Selects and outputs the MIP-PG pattern created in the machine.</p> <p>Purpose When performing respective image printing adjustments, used to check the machine status apart from that of the scanner with a non-scanned output MIP-PG pattern.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the MIP-PG pattern to be output using the up/down cursor keys. <table><tr><th>Display</th><th>PG pattern to be output</th><th>Purpose</th></tr><tr><td>GRAYSCALE</td><td></td><td>To check the laser scanner unit engine output characteristics.</td></tr><tr><td>MONO-LEVEL</td><td></td><td>To check the drum quality.</td></tr><tr><td>256-LEVEL</td><td></td><td>To check resolution reproducibility in printing.</td></tr><tr><td>1 DOT-LEVEL</td><td></td><td>To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)</td></tr></table> <ol style="list-style-type: none">3. To change the output conditions of MONO-LEVEL and 1dot-LEVEL, use the left/right cursor keys to change the preset values and press the start key to register the setting. <table><tr><th>Display</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Output density of MONO-LEVEL</td><td>0 or 35</td><td>0</td></tr><tr><td>1dot-LEVEL</td><td>0 to 21</td><td>0</td></tr></table> <ol style="list-style-type: none">4. Press the interrupt key. The copy mode screen is displayed.5. Press the start key. A MIP-PG pattern is output. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for maintenance item No. is displayed.</p>	Display	PG pattern to be output	Purpose	GRAYSCALE		To check the laser scanner unit engine output characteristics.	MONO-LEVEL		To check the drum quality.	256-LEVEL		To check resolution reproducibility in printing.	1 DOT-LEVEL		To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)	Display	Setting range	Initial setting	Output density of MONO-LEVEL	0 or 35	0	1dot-LEVEL	0 to 21	0
Display	PG pattern to be output	Purpose																							
GRAYSCALE		To check the laser scanner unit engine output characteristics.																							
MONO-LEVEL		To check the drum quality.																							
256-LEVEL		To check resolution reproducibility in printing.																							
1 DOT-LEVEL		To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)																							
Display	Setting range	Initial setting																							
Output density of MONO-LEVEL	0 or 35	0																							
1dot-LEVEL	0 to 21	0																							

Maintenance item No.	Description										
U092	<p>Adjusting the scanner automatically</p> <p>Description Makes auto scanner adjustments in the order below using the specified original. Adjusting the scanner center line (U067) Adjusting the scanner leading edge registration (U066) Adjusting scanner magnification in the auxiliary direction (U065) When this maintenance item is performed, the settings in U065, U066 and U067 are also changed.</p> <p>Purpose Used to make respective auto adjustments for the scanner.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Place the specified original (P/N: 2A068021) on the contact glass. 2. Press the start key. The screen for executing is displayed. 3. Press the start key. Auto adjustment starts. When adjustment is complete, each adjusted value is displayed. <table border="1" data-bbox="331 680 1398 869"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SCN CENTER</td><td>Scanner center line</td></tr> <tr> <td>SCN TIMING</td><td>Scanner leading registration</td></tr> <tr> <td>SUB SCAN</td><td>Scanner magnification in the auxiliary scanning direction</td></tr> <tr> <td>MAIN SCAN</td><td>Scanner magnification in the main scanning direction</td></tr> </tbody> </table> <p>If a problem occurs during auto adjustment, DATA: XX (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>Completion Press the stop/clear key after auto adjustment is complete. The screen for selecting a maintenance item No. is displayed. If the stop/clear key is pressed during auto adjustment, adjustment stops and no settings are changed.</p>	Display	Description	SCN CENTER	Scanner center line	SCN TIMING	Scanner leading registration	SUB SCAN	Scanner magnification in the auxiliary scanning direction	MAIN SCAN	Scanner magnification in the main scanning direction
Display	Description										
SCN CENTER	Scanner center line										
SCN TIMING	Scanner leading registration										
SUB SCAN	Scanner magnification in the auxiliary scanning direction										
MAIN SCAN	Scanner magnification in the main scanning direction										

Maintenance item No.	Description																																				
U093	<p>Setting the exposure density gradient</p> <p>Description Changes the exposure density gradient in manual density mode, depending on respective image modes (text, text and photo, photo, text in fax mode, photo in fax mode).</p> <p>Purpose To set how the image density is altered by a change of one step in the manual density adjustment. Also used to make copy image darker or lighter.</p> <p>Start</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the image mode to be adjusted using the up/down cursor keys and press the start key. The screen for the selected item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>MIXED</td><td>Density in text and photo mode</td></tr><tr><td>TEXT</td><td>Density in text mode</td></tr><tr><td>PHOTO</td><td>Density in photo mode</td></tr><tr><td>FAX TEXT</td><td>Density in the text in fax mode</td></tr><tr><td>FAX PHOTO</td><td>Density in the photo in fax mode</td></tr></table> <p>Setting: Density in text and photo mode</p> <ol style="list-style-type: none">1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse.2. Adjust the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MIXED DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 3</td><td>0</td></tr><tr><td>MIXED LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 3</td><td>0</td></tr></table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <div><p>Figure 1-4-4 Exposure density gradient</p></div> <ol style="list-style-type: none">3. Press the start key. The value is set.4. To return to the screen for selecting an item, press the stop/clear key. <p>Setting: Density in text mode</p> <ol style="list-style-type: none">1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse.2. Adjust the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>TEXT DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 3</td><td>0</td></tr><tr><td>TEXT LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 3</td><td>0</td></tr></table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none">3. Press the start key. The value is set.4. To return to the screen for selecting an item, press the stop/clear key.	Display	Description	MIXED	Density in text and photo mode	TEXT	Density in text mode	PHOTO	Density in photo mode	FAX TEXT	Density in the text in fax mode	FAX PHOTO	Density in the photo in fax mode	Display	Description	Setting range	Initial setting	MIXED DARKER	Change in density when manual density is set dark	0 to 3	0	MIXED LIGHTER	Change in density when manual density is set light	0 to 3	0	Display	Description	Setting range	Initial setting	TEXT DARKER	Change in density when manual density is set dark	0 to 3	0	TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0
Display	Description																																				
MIXED	Density in text and photo mode																																				
TEXT	Density in text mode																																				
PHOTO	Density in photo mode																																				
FAX TEXT	Density in the text in fax mode																																				
FAX PHOTO	Density in the photo in fax mode																																				
Display	Description	Setting range	Initial setting																																		
MIXED DARKER	Change in density when manual density is set dark	0 to 3	0																																		
MIXED LIGHTER	Change in density when manual density is set light	0 to 3	0																																		
Display	Description	Setting range	Initial setting																																		
TEXT DARKER	Change in density when manual density is set dark	0 to 3	0																																		
TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0																																		

Maintenance item No.	Description												
U093	Setting: Density in photo mode 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys.												
	<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>PHOTO DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 3</td><td>0</td></tr><tr><td>PHOTO LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 3</td><td>0</td></tr></table>	Display	Description	Setting range	Initial setting	PHOTO DARKER	Change in density when manual density is set dark	0 to 3	0	PHOTO LIGHTER	Change in density when manual density is set light	0 to 3	0
	Display	Description	Setting range	Initial setting									
	PHOTO DARKER	Change in density when manual density is set dark	0 to 3	0									
	PHOTO LIGHTER	Change in density when manual density is set light	0 to 3	0									
	Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.												
	3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key.												
	Setting: Density in the text in fax mode 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys.												
	<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>FAX TEXT DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 4</td><td>0</td></tr><tr><td>FAX TEXT LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 4</td><td>2</td></tr></table>	Display	Description	Setting range	Initial setting	FAX TEXT DARKER	Change in density when manual density is set dark	0 to 4	0	FAX TEXT LIGHTER	Change in density when manual density is set light	0 to 4	2
	Display	Description	Setting range	Initial setting									
	FAX TEXT DARKER	Change in density when manual density is set dark	0 to 4	0									
	FAX TEXT LIGHTER	Change in density when manual density is set light	0 to 4	2									
Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.													
3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key.													
Setting: Density in the photo in fax mode 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys.													
<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>FAX PHOTO DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 6</td><td>3</td></tr><tr><td>FAX PHOTO LIGHT</td><td>Change in density when manual density is set light</td><td>0 to 6</td><td>3</td></tr></table>	Display	Description	Setting range	Initial setting	FAX PHOTO DARKER	Change in density when manual density is set dark	0 to 6	3	FAX PHOTO LIGHT	Change in density when manual density is set light	0 to 6	3	
Display	Description	Setting range	Initial setting										
FAX PHOTO DARKER	Change in density when manual density is set dark	0 to 6	3										
FAX PHOTO LIGHT	Change in density when manual density is set light	0 to 6	3										
*Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.													
3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key.													
Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode. 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key.													
Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.													

Maintenance item No.	Description																														
U099	<p>Checking the original size detection</p> <p>Description Checks the operation of the original size detection sensor and sets the sensing threshold value.</p> <p>Purpose To adjust the sensitiveness of the sensor and size judgement time if the original size detection sensor malfunctions frequently due to incident light or the like.</p> <p>Start</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select an item using the up/down cursor keys.3. Press the start key. The screen for executing each item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>DATA</td><td>Displaying detection sensor transmission data</td></tr><tr><td>B/W LEVEL</td><td>Setting detection sensor threshold value Setting original size judgment time</td></tr></table> <p>Method to display the data for the sensor</p> <ol style="list-style-type: none">1. Press the start key. The detection sensor transmission data is displayed. <div><div>Rear of machine Center of machine Front of machine</div><div><div>: 123 123 123</div><div>: 123 123 123</div><div>: 255 255 255</div></div></div> <p>Figure 1-4-5</p> <ol style="list-style-type: none">2. To return to the screen for selecting an item, press the stop/clear key. <p>Setting</p> <ol style="list-style-type: none">1. Select an item to be set using the up/down cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>LEVEL</td><td>Detection sensor threshold value</td><td>0 to 255</td><td>170</td></tr><tr><td>WAIT TIME</td><td>Original size judgment time*</td><td>0 to 100</td><td>30</td></tr><tr><td>A4R AREA</td><td>Threshold value in the main scan direction for A4R detection</td><td>220 (mm)/ 240 (mm)</td><td>240</td></tr><tr><td>ORG AREA</td><td>Original size detection position display (mm)</td><td>0 to 350</td><td>-</td></tr><tr><td>SIZE</td><td>Detected original size display</td><td>0 to 63</td><td>-</td></tr></table> <p>Time from activation of the original detection switch (ODSW) to original size judgment</p> <p>Method to set the detection threshold value</p> <ol style="list-style-type: none">1. Adjust the preset value using the left/right cursor keys. A larger value increases the sensor sensitivity, and a smaller value decreases it.2. Press the start key. The value is set.3. To return to the screen for selecting an item, press the stop/clear key. <p>Method to set the original size judgment time</p> <ol style="list-style-type: none">1. Adjust the preset value using the left/right cursor keys. A larger value increases the original size judgment time, and a smaller value decreases it.2. Press the start key. The value is set.3. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for maintenance item No. is displayed.</p>	Display	Description	DATA	Displaying detection sensor transmission data	B/W LEVEL	Setting detection sensor threshold value Setting original size judgment time	Display	Description	Setting range	Initial setting	LEVEL	Detection sensor threshold value	0 to 255	170	WAIT TIME	Original size judgment time*	0 to 100	30	A4R AREA	Threshold value in the main scan direction for A4R detection	220 (mm)/ 240 (mm)	240	ORG AREA	Original size detection position display (mm)	0 to 350	-	SIZE	Detected original size display	0 to 63	-
Display	Description																														
DATA	Displaying detection sensor transmission data																														
B/W LEVEL	Setting detection sensor threshold value Setting original size judgment time																														
Display	Description	Setting range	Initial setting																												
LEVEL	Detection sensor threshold value	0 to 255	170																												
WAIT TIME	Original size judgment time*	0 to 100	30																												
A4R AREA	Threshold value in the main scan direction for A4R detection	220 (mm)/ 240 (mm)	240																												
ORG AREA	Original size detection position display (mm)	0 to 350	-																												
SIZE	Detected original size display	0 to 63	-																												

Maintenance item No.	Description																												
U100	<p>Setting the main high voltage</p> <p>Description Performs the main charging. Also changes the setting of main charging copy quantity correction.</p> <p>Purpose To check main charging. Also used when reentering data after initializing the set data.</p> <p>Start</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the item using the up/down cursor keys. <table><tr><th>Display</th><th>Description</th></tr><tr><td>MC ON</td><td>Turning the main charger on</td></tr><tr><td>LASER ON/OFF</td><td>Turning the main charger on and the laser scanner unit on and off</td></tr><tr><td>INTERVAL</td><td>Main charging copy quantity correction, copy interval</td></tr><tr><td>COPY CNT</td><td>Main charging copy quantity correction, copy quantity</td></tr><tr><td>MC ADJUST</td><td>Main charging copy quantity correction, correction amount</td></tr></table> <p>Method for main charger output</p> <ol style="list-style-type: none">1. Press the start key. The selected operation starts.2. To stop operation, press the stop/clear key. <p>Setting the main charging copy quantity correction</p> <ol style="list-style-type: none">1. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Setting</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>INTERVAL</td><td>Copy interval</td><td>1 to 255 (minute)</td><td>60</td></tr><tr><td>COPY CNT</td><td>Copy quantity</td><td>1 to 255 (10 sheets)</td><td>50</td></tr><tr><td>MC ADJUST</td><td>Correction amount</td><td>0 to 50 (bit)</td><td>10</td></tr></table> <p>Copy interval: Sets the time interval from the previous copying. If the time from the previous copying exceeds this preset value, the copy quantity counter will be reset.</p> <p>Copy quantity: Sets the copy quantity from which copy quantity correction starts. When the copy quantity counter reaches this preset value, correction will start.</p> <p>Correction amount: Sets the correction amount for copy quantity correction.</p> <p>Set the values in the range from 5 to 120 minutes for copy interval, from 10 to 2,000 sheets for copy quantity, and from 5 to 50 bits for correction amount.</p> <ol style="list-style-type: none">2. Press the start key. The value is set. <p>Completion Press the stop/clear key when main charger output stops while a selection item is displayed. The indication for selecting a maintenance item No. appears.</p>	Display	Description	MC ON	Turning the main charger on	LASER ON/OFF	Turning the main charger on and the laser scanner unit on and off	INTERVAL	Main charging copy quantity correction, copy interval	COPY CNT	Main charging copy quantity correction, copy quantity	MC ADJUST	Main charging copy quantity correction, correction amount	Display	Setting	Setting range	Initial setting	INTERVAL	Copy interval	1 to 255 (minute)	60	COPY CNT	Copy quantity	1 to 255 (10 sheets)	50	MC ADJUST	Correction amount	0 to 50 (bit)	10
Display	Description																												
MC ON	Turning the main charger on																												
LASER ON/OFF	Turning the main charger on and the laser scanner unit on and off																												
INTERVAL	Main charging copy quantity correction, copy interval																												
COPY CNT	Main charging copy quantity correction, copy quantity																												
MC ADJUST	Main charging copy quantity correction, correction amount																												
Display	Setting	Setting range	Initial setting																										
INTERVAL	Copy interval	1 to 255 (minute)	60																										
COPY CNT	Copy quantity	1 to 255 (10 sheets)	50																										
MC ADJUST	Correction amount	0 to 50 (bit)	10																										
U101	<p>Setting the other high voltages</p> <p>Description Changes the developing bias voltage and transfer/separation voltage.</p> <p>Purpose To check the developing bias and the transfer/separation voltage or to take measures against drop of image density or background fog.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the item to be set using the up/down cursor keys.3. Press the start key. The screen for executing each item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>DEV</td><td>Setting the developing bias</td></tr><tr><td>TC</td><td>Setting the transfer voltage</td></tr><tr><td>SC</td><td>Setting the separation voltage</td></tr></table>	Display	Description	DEV	Setting the developing bias	TC	Setting the transfer voltage	SC	Setting the separation voltage																				
Display	Description																												
DEV	Setting the developing bias																												
TC	Setting the transfer voltage																												
SC	Setting the separation voltage																												

Maintenance item No.	Description																			
U101	Setting the developing bias 1. Select the item to be set using the up/down cursor keys. 2. Change the setting using the left/right cursor keys.																			
	<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>BIAS</td><td>Developing bias clock frequency</td><td>2 to 255</td><td>25</td></tr><tr><td>DUTY</td><td>Developing bias clock duty</td><td>1 to 99</td><td>50</td></tr><tr><td>DEV DATA</td><td>Developing bias control voltage</td><td>0 to 255</td><td>98</td></tr></table>	Display	Description	Setting range	Initial setting	BIAS	Developing bias clock frequency	2 to 255	25	DUTY	Developing bias clock duty	1 to 99	50	DEV DATA	Developing bias control voltage	0 to 255	98			
	Display	Description	Setting range	Initial setting																
	BIAS	Developing bias clock frequency	2 to 255	25																
	DUTY	Developing bias clock duty	1 to 99	50																
	DEV DATA	Developing bias control voltage	0 to 255	98																
	Increasing the BIAS setting makes the image lighter; decreasing it makes the image darker. Increasing the DUTY setting makes the image lighter; decreasing it makes the image darker.																			
	3. Press the start key. The value is set.																			
	Setting the transfer voltage 1. Select the item to be set using the up/down cursor keys. 2. Change the setting using the left/right cursor keys.																			
	<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>TC DATA1</td><td>Transfer control voltage (large size)</td><td>0 to 255</td><td>155</td></tr><tr><td>TC DATA2</td><td>Transfer control voltage (small size)</td><td>0 to 255</td><td>166</td></tr><tr><td>OFF TIMING</td><td>Transfer charging output OFF timing</td><td>0 to 255</td><td>29</td></tr><tr><td>ON TIMING</td><td>Transfer charging output ON timing</td><td>0 to 255</td><td>28</td></tr></table>	Display	Description	Setting range	Initial setting	TC DATA1	Transfer control voltage (large size)	0 to 255	155	TC DATA2	Transfer control voltage (small size)	0 to 255	166	OFF TIMING	Transfer charging output OFF timing	0 to 255	29	ON TIMING	Transfer charging output ON timing	0 to 255
Display	Description	Setting range	Initial setting																	
TC DATA1	Transfer control voltage (large size)	0 to 255	155																	
TC DATA2	Transfer control voltage (small size)	0 to 255	166																	
OFF TIMING	Transfer charging output OFF timing	0 to 255	29																	
ON TIMING	Transfer charging output ON timing	0 to 255	28																	
3. Press the start key. The value is set.																				
Setting the separation voltage 1. Select the item to be set using the up/down cursor keys. 2. Change the setting using the left/right cursor keys.																				
<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>SC SEL</td><td>Separation control voltage</td><td>0 to 2</td><td>1</td></tr><tr><td>ON TIMING</td><td>Separation charging output ON timing</td><td>0 to 255</td><td>27</td></tr><tr><td>OFF TIMING</td><td>Separation charging output OFF timing</td><td>0 to 255</td><td>38</td></tr><tr><td>SC MODE</td><td>0: Separation charging output is all over a paper 1: Separation charging output is only for the leading edge and trailing edge of a paper.</td><td>0 / 1</td><td>0</td></tr></table>	Display	Description	Setting range	Initial setting	SC SEL	Separation control voltage	0 to 2	1	ON TIMING	Separation charging output ON timing	0 to 255	27	OFF TIMING	Separation charging output OFF timing	0 to 255	38	SC MODE	0: Separation charging output is all over a paper 1: Separation charging output is only for the leading edge and trailing edge of a paper.	0 / 1	0
Display	Description	Setting range	Initial setting																	
SC SEL	Separation control voltage	0 to 2	1																	
ON TIMING	Separation charging output ON timing	0 to 255	27																	
OFF TIMING	Separation charging output OFF timing	0 to 255	38																	
SC MODE	0: Separation charging output is all over a paper 1: Separation charging output is only for the leading edge and trailing edge of a paper.	0 / 1	0																	
3. Press the start key. The value is set.																				
Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode. 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the start key. To return to the screen for setting, press the interrupt key.																				
Completion Press the stop/clear key at the screen for selecting an item. The screen for maintenance item No. is displayed.																				
U110	Checking/clearing the drum count																			
	Description Displays the drum counts for checking, clearing the figure.																			
	Purpose To check the drum status. Also used to clear the count after replacing the drum during regular maintenance. Since the count was cleared before shipping, do not clear it when installing. A drum count value less than 150K, however, cannot be cleared.																			
	Method 1. Press the start key. The drum counter count is displayed. 2. Select the CLEAR using the up/down cursor keys. If the counter value is 150K or less, CLEAR is not displayed. 3. Press the start key. The count is cleared, and the screen for selecting a maintenance item No. is displayed.																			
	Completion To exit the maintenance mode without changing the count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.																			

Maintenance item No.	Description
U113	<p>Performing drum refresh operation</p> <p>Description Executes drum refresh operation.</p> <p>Purpose To operate when a faulty image (black line, etc.) occurs.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Set A3/11" x 17" paper on drawer 2. 2. Press the start key. The screen for executing is displayed. 3. Press the start key. Drum refresh operation starts. 4. To stop the operation, press the stop/clear key. <p>Completion Press the stop/clear key when the operation stops. The screen for selecting a maintenance item No. is displayed.</p>
U117	<p>Checking the drum number</p> <p>Description Displays the drum number.</p> <p>Purpose To check the drum number.</p> <p>Method Press the start key. The drum number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>
U118	<p>Displaying the drum history</p> <p>Description Displays the past record of machine number and the drum counter.</p> <p>Purpose To check the count value of machine number and the drum counter.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The count value of machine number and the drum counter is displayed. 2. Change the screen using the left/right cursor keys. Past record of 5 cases is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>
U130	<p>Initial setting for the developer</p> <p>Description Replenishes toner to the developer unit to a certain level from the toner container that has been installed.</p> <p>Purpose To operate when installing the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. 3. Press the start key. Installation of toner starts and time (minutes) is indicated until the installation ends. 4. When the installation is complete, FINISHED will be displayed if the installation is successful or NG will be displayed if it has failed. If NG is displayed, check to see if the toner container contains toner and to see if the toner container sensor malfunctions and then try again. <p>Completion Press the stop/clear key after operation is complete. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description													
U135	Checking toner motor operation													
	Description Drives toner motor.													
	Purpose To check the operation of toner motor.													
	Start													
	1. Press the start key. The screen for selecting an item is displayed.													
	2. Select the item using the up/down cursor keys.													
	<table><tr><th>Display</th><th>Description</th></tr><tr><td>MOTOR MOVING</td><td>Turning the toner motor on</td></tr><tr><td>ON TIME</td><td>Toner motor on time</td></tr></table>			Display	Description	MOTOR MOVING	Turning the toner motor on	ON TIME	Toner motor on time					
	Display	Description												
	MOTOR MOVING	Turning the toner motor on												
	ON TIME	Toner motor on time												
Method for toner motor on														
1. Press the start key. The operation starts.														
2. To stop operation, press the stop/clear key.														
U144	Setting toner motor on time													
	1. Change the setting using the left/right cursor keys.													
	<table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Toner motor on time</td><td>1 to +10 (s)</td><td>3</td></tr></table>			Description	Setting range	Initial setting	Toner motor on time	1 to +10 (s)	3					
	Description	Setting range	Initial setting											
	Toner motor on time	1 to +10 (s)	3											
	2. Press the start key. The value is set.													
	Completion Press the stop key after operation stops. The screen for selecting a maintenance item No. is displayed.													
	Setting toner loading operation													
	Description Sets toner loading operation after completion of copying.													
	Purpose To set whether or not toner is loaded on the drum after low density copying. Normally no change is necessary from the initial setting.													
Method Press the start key. The screen for selecting an item is displayed.														
Setting														
U144	1. Select either ON or OFF using the up/down cursor keys. The selected item is displayed in reverse.													
	<table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Toner loaded</td></tr><tr><td>OFF</td><td>Toner not loaded</td></tr></table>			Display	Description	ON	Toner loaded	OFF	Toner not loaded					
	Display	Description												
	ON	Toner loaded												
	OFF	Toner not loaded												
	Initial setting: OFF													
	2. Press the start key. The value is set.													
	Available only when the mode is turned on.													
	3. Select the item using the up/down cursor keys.													
	4. Change the setting using the left/right cursor keys.													
<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>COUNT</td><td>Count number of sheets</td><td>1 to 50</td><td>5</td></tr><tr><td>PERCENT</td><td>Printing ratio</td><td>10 to 40</td><td>30</td></tr></table>			Display	Description	Setting range	Initial setting	COUNT	Count number of sheets	1 to 50	5	PERCENT	Printing ratio	10 to 40	30
Display	Description	Setting range	Initial setting											
COUNT	Count number of sheets	1 to 50	5											
PERCENT	Printing ratio	10 to 40	30											
Example When COUNT is 5 and PERCENT is 30, take the average in every five sheets, and perform the toner loading operation when the printing ratio is 3% or less.														
5. Press the start key. The value is set.														
Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.														

Maintenance item No.	Description																												
U157	<p>Checking/clearing the developing drive time</p> <p>Description Displays the developing drive time for checking, clearing or changing a figure.</p> <p>Purpose To check the developing drive time. Also used to clear the count after replacing the developing unit.</p> <p>Method Press the start key. The developing drive time is displayed in minutes.</p> <p>Clearing</p> <ol style="list-style-type: none">1. Select the CLEAR using the up/down cursor keys.2. Press the start key. The time is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Setting</p> <ol style="list-style-type: none">1. Enter a seven-digit drive time (in minutes) using the numeric keys.2. Press the start key. The time is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the time, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																												
U158	<p>Checking the developing count</p> <p>Description Displays the developing count for checking a figure.</p> <p>Purpose To check the developing count.</p> <p>Method Press the start key. The developing count is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																												
U161	<p>Setting the fixing control temperature</p> <p>Description Changes the fixing control temperature.</p> <p>Purpose Normally no change is necessary. However, can be used to prevent curling or creasing of paper, or solve a fixing problem on thick paper.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the item to be set using the up/down cursor keys. The screen for executing each item is displayed.3. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>1ST TEMP</td><td>Primary stabilization fixing temperature</td><td>120 to 185 (°C)</td><td>152</td></tr><tr><td>2ND TEMP</td><td>Secondary stabilization fixing temperature</td><td>120 to 185 (°C)</td><td>170</td></tr><tr><td>COPY TEMP1</td><td>Copying operation temperature 1</td><td>160 to 220 (°C)</td><td>180</td></tr><tr><td>COPY TEMP2</td><td>Copying operation temperature 2</td><td>160 to 220 (°C)</td><td>190</td></tr><tr><td>COPY CNT</td><td>Number of sheets for fixing control</td><td>1 to 99</td><td>5</td></tr><tr><td>THICK CNT</td><td>Number of sheets for fixing control (thick paper)</td><td>1 to 99</td><td>30</td></tr></table> <p>Copying operation temperature 1: Temperature in copying operation at the start of copying Copying operation temperature 2: Temperature in copying operation after the specified number of sheets for fixing control have passed Number of sheets for fixing control: The number of sheets to be counted for switching from copying operation temperature 1 to copying operation temperature 2 The temperatures are to be set such that Secondary stabilization ≥ Primary stabilization.</p> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	1ST TEMP	Primary stabilization fixing temperature	120 to 185 (°C)	152	2ND TEMP	Secondary stabilization fixing temperature	120 to 185 (°C)	170	COPY TEMP1	Copying operation temperature 1	160 to 220 (°C)	180	COPY TEMP2	Copying operation temperature 2	160 to 220 (°C)	190	COPY CNT	Number of sheets for fixing control	1 to 99	5	THICK CNT	Number of sheets for fixing control (thick paper)	1 to 99	30
Display	Description	Setting range	Initial setting																										
1ST TEMP	Primary stabilization fixing temperature	120 to 185 (°C)	152																										
2ND TEMP	Secondary stabilization fixing temperature	120 to 185 (°C)	170																										
COPY TEMP1	Copying operation temperature 1	160 to 220 (°C)	180																										
COPY TEMP2	Copying operation temperature 2	160 to 220 (°C)	190																										
COPY CNT	Number of sheets for fixing control	1 to 99	5																										
THICK CNT	Number of sheets for fixing control (thick paper)	1 to 99	30																										

Maintenance item No.	Description								
U162	<p>Stabilizing fixing forcibly</p> <p>Description Stops the stabilization fixing drive forcibly, regardless of fixing temperature.</p> <p>Purpose To forcibly stabilize the machine before the fixing section reaches stabilization temperature.</p> <p>Method <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Press the start key. The forced stabilization mode is entered, and stabilization operation stops regardless of fixing temperature. The screen for selecting a maintenance item No. is displayed. To exit the forced stabilization mode, turn the power off and on. </p> <p>Completion To exit this maintenance item without executing forced fixing stabilization, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U163	<p>Resetting the fixing problem data</p> <p>Description Resets the detection of a service call code indicating a problem in the fixing section.</p> <p>Purpose To prevent accidents due to an abnormally high fixing temperature.</p> <p>Method <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. The selected item is displayed in reverse. 3. Press the start key. The fixing problem data is initialized. </p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U167	<p>Checking the fixing counts</p> <p>Description Displays the fixing counts.</p> <p>Purpose To check fixing counts.</p> <p>Method Press the start key. The fixing counts are displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U199	<p>Checking the fixing temperature</p> <p>Description Displays the fixing temperature, the ambient temperature and the absolute humidity.</p> <p>Purpose To check the fixing temperature, the ambient temperature and the absolute humidity.</p> <p>Method Press the start key. The fixing temperature and ambient temperature are displayed in centigrade (°C) and the absolute humidity is displayed in percentage (%).</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FIX TEMP</td><td>Fixing temperature (°C)</td></tr> <tr> <td>SURROUND TEMP</td><td>Ambient temperature (°C)</td></tr> <tr> <td>HUMIDITY</td><td>Absolute humidity (%)</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FIX TEMP	Fixing temperature (°C)	SURROUND TEMP	Ambient temperature (°C)	HUMIDITY	Absolute humidity (%)
Display	Description								
FIX TEMP	Fixing temperature (°C)								
SURROUND TEMP	Ambient temperature (°C)								
HUMIDITY	Absolute humidity (%)								

Maintenance item No.	Description										
U200	<p>Turning all LEDs on</p> <p>Description Turns all the LEDs on the operation panel on.</p> <p>Purpose To check if all the LEDs on the operation panel light.</p> <p>Method Press the start key. All the LEDs on the operation panel light. Press the stop/clear key or wait for 10 s. The LEDs turns off, and the screen for selecting a maintenance item No. is displayed.</p>										
U202	<p>Setting the KMAS host monitoring system</p> <p>Description Initializes or operates the KMAS host monitoring system. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p>										
U203	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the optional DP.</p> <p>Purpose To check the DP.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Place an original in the DP if running this simulation with paper. 3. Select the item to be operated using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="331 965 1399 1155"> <thead> <tr> <th>Display</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>ADP</td><td>With paper, single-sided original</td></tr> <tr> <td>RADP</td><td>With paper, double-sided original</td></tr> <tr> <td>ADP (NON-P)</td><td>Without paper, single-sided original (continuous operation)</td></tr> <tr> <td>RADP (NON-P)</td><td>Without paper, double-sided original (continuous operation)</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The operation starts. 5. To stop continuous operation, press the stop/clear key. <p>Completion Press the stop/clear key when the operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	ADP	With paper, single-sided original	RADP	With paper, double-sided original	ADP (NON-P)	Without paper, single-sided original (continuous operation)	RADP (NON-P)	Without paper, double-sided original (continuous operation)
Display	Operation										
ADP	With paper, single-sided original										
RADP	With paper, double-sided original										
ADP (NON-P)	Without paper, single-sided original (continuous operation)										
RADP (NON-P)	Without paper, double-sided original (continuous operation)										

Maintenance item No.	Description								
U204	<p>Setting the presence or absence of a key card or key counter</p> <p>Description Sets the presence or absence of the optional key card or key counter.</p> <p>Purpose To run this maintenance item if a key card or key counter is installed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the optional counter to be installed using the up/down cursor keys. The selected counter is displayed in reverse. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>OFF</td><td>None</td></tr> <tr> <td>KEY-CARD</td><td>The key card is installed</td></tr> <tr> <td>KEY-COUNTER</td><td>The key counter is installed</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set and the screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	OFF	None	KEY-CARD	The key card is installed	KEY-COUNTER	The key counter is installed
Display	Description								
OFF	None								
KEY-CARD	The key card is installed								
KEY-COUNTER	The key counter is installed								
U207	<p>Checking the operation panel keys</p> <p>Description Checks operation of the operation panel keys.</p> <p>Purpose To check operation of all the keys and LEDs on the operation panel.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. COUNT1 is displayed and the leftmost LED on the operation panel lights. 3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light. 4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds. 5. When the LEDs go off, press the start key. All the LEDs light for 10 seconds again. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U233	<p>Setting the ejection limit of the job separator</p> <p>Description When an optional job separator is installed, whether the limit of ejection to the job separator is 50 sheets for A3/11" x 17" and 100 sheets for other sizes or 100 sheets for all sizes is set.</p> <p>Purpose To be set according to user request.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item using the up/down cursor keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MODE0</td><td>All size is limited to 100 sheets.</td></tr> <tr> <td>MODE1</td><td>A3/11" x 17" is limited to 50 sheets</td></tr> </tbody> </table> <p>Initial setting: MODE0</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MODE0	All size is limited to 100 sheets.	MODE1	A3/11" x 17" is limited to 50 sheets		
Display	Description								
MODE0	All size is limited to 100 sheets.								
MODE1	A3/11" x 17" is limited to 50 sheets								

Maintenance item No.	Description															
U243	<p>Checking the operation of the DP motors and solenoids</p> <p>Description Turns the motors or solenoids in the optional DP on.</p> <p>Purpose To check the operation of the DP motors and solenoids.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the item to be operated using the up/down cursor keys.3. Press the start key. The operation starts. <table><tr><th>Display</th><th>Motors, solenoids and clutch</th><th>Operation In operation</th></tr><tr><td>F MOT</td><td>Original feed motor (OFM)</td><td>In operation</td></tr><tr><td>C MOT</td><td>Original paper conveying motor (OCM)</td><td>In operation</td></tr><tr><td>RJ SL</td><td>Switchback feedshift solenoid (SBFSSOL)</td><td>On for 0.5 s</td></tr><tr><td>RP SL</td><td>Switchback pressure solenoid (SBPSOL)</td><td>On for 0.5 s</td></tr></table> <ol style="list-style-type: none">4. To turn each motor off, press the stop/clear key. <p>Completion Press the stop/clear key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motors, solenoids and clutch	Operation In operation	F MOT	Original feed motor (OFM)	In operation	C MOT	Original paper conveying motor (OCM)	In operation	RJ SL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s	RP SL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s
Display	Motors, solenoids and clutch	Operation In operation														
F MOT	Original feed motor (OFM)	In operation														
C MOT	Original paper conveying motor (OCM)	In operation														
RJ SL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s														
RP SL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s														
U244	<p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the optional DP.</p> <p>Purpose To check if respective switches in the optional DP operate correctly.</p> <p>Start</p> <ol style="list-style-type: none">1. Press the start key.2. Turn the respective switches on and off manually to check the status. <p>If the on-status of a switch is detected, the corresponding switch is displayed in reverse.</p> <table><tr><th>Display</th><th>Switches</th></tr><tr><td>SET SW</td><td>Original set switch (OSSW)</td></tr><tr><td>TMG SW</td><td>DP timing switch (DPTSW)</td></tr><tr><td>MAT SW</td><td>DP open/close switch (DPOCSW)</td></tr><tr><td>COV SW</td><td>DP original cover switch (DPOCSW)</td></tr><tr><td>REV SW</td><td>Original switchback switch (OSBSW)</td></tr><tr><td>SZ A SW</td><td>Original size length switch (OSLSW)</td></tr></table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	SET SW	Original set switch (OSSW)	TMG SW	DP timing switch (DPTSW)	MAT SW	DP open/close switch (DPOCSW)	COV SW	DP original cover switch (DPOCSW)	REV SW	Original switchback switch (OSBSW)	SZ A SW	Original size length switch (OSLSW)	
Display	Switches															
SET SW	Original set switch (OSSW)															
TMG SW	DP timing switch (DPTSW)															
MAT SW	DP open/close switch (DPOCSW)															
COV SW	DP original cover switch (DPOCSW)															
REV SW	Original switchback switch (OSBSW)															
SZ A SW	Original size length switch (OSLSW)															

Maintenance item No.	Description																
U245	<p>Checking messages</p> <p>Description Displays a list of messages or graphics on the operation panel.</p> <p>Purpose To check the messages or graphics to be displayed.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the item to be displayed using the up/down cursor keys.3. Press the start key. The selected item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>Check display messages</td><td>Check the messages</td></tr><tr><td>Check display graphics</td><td>Check the graphics</td></tr></table> <p>Method to display the messages</p> <ol style="list-style-type: none">1. Change the screen using the up/down cursor keys to display each message one at a time. You can select the language using the left/right cursor keys.2. To return to the screen for selecting an item, press the stop/clear key. <p>Method to display the graphics</p> <ol style="list-style-type: none">1. Change the screen using the up/down cursor keys to display each graphic one at a time. You can select the background (black or white) using the left/right cursor keys.2. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Check display messages	Check the messages	Check display graphics	Check the graphics										
Display	Description																
Check display messages	Check the messages																
Check display graphics	Check the graphics																
U246	<p>Setting the finisher</p> <p>Description Adjusts the side registration cursor stop position in the staple sort mode.</p> <p>Purpose To adjust when registration is not proper or staple position is shifted in the staple sort mode.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the desired cursor position using the up/down cursor keys. The selected item is displayed in reverse.3. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>FRONT</td><td>Front side registration cursor stop position</td><td>0 to +8</td><td>4</td></tr><tr><td>REAR</td><td>Rear side registration cursor stop position</td><td>0 to +8</td><td>4</td></tr><tr><td>END</td><td>Trailing edge registration cursor stop position</td><td>0 to +8</td><td>4</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	FRONT	Front side registration cursor stop position	0 to +8	4	REAR	Rear side registration cursor stop position	0 to +8	4	END	Trailing edge registration cursor stop position	0 to +8	4
Display	Description	Setting range	Initial setting														
FRONT	Front side registration cursor stop position	0 to +8	4														
REAR	Rear side registration cursor stop position	0 to +8	4														
END	Trailing edge registration cursor stop position	0 to +8	4														

Maintenance item No.	Description						
U249	<p>Checking the paper ejection to optional devices</p> <p>Description Ejects paper to an optional job separator.</p> <p>Purpose To check paper conveying operation to optional job separator.</p> <p>Method While pressing the feedshift switch by your hand, press the start key. Paper transfer operation starts.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U250	<p>Setting the maintenance cycle</p> <p>Description Displays and changes the maintenance cycle.</p> <p>Purpose To check and change the maintenance cycle.</p> <p>Method Press the start key. The current setting is displayed.</p> <p>Setting</p> <p>1. Change the setting using the numeric keys. To clear, press the reset key.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Maintenance cycle</td><td>0 to 9999999</td><td>300000</td></tr></table> <p>2. Press the start key. The value is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance cycle	0 to 9999999	300000
Description	Setting range	Initial setting					
Maintenance cycle	0 to 9999999	300000					

Maintenance item No.	Description																						
U251	<p>Checking/clearing the maintenance count</p> <p>Description Displays, clears and changes the maintenance count.</p> <p>Purpose To check the maintenance count. Also to clear the count during maintenance service.</p> <p>Method Press the start key. The maintenance count is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none">1. Select the CLEAR using the up/down cursor keys.2. Press the start key. The count is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Setting</p> <ol style="list-style-type: none">1. Select the COUNT using the up/down cursor keys.2. Enter a seven-digit count using the numeric keys.3. Press the start key. The count is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																						
U252	<p>Setting the destination</p> <p>Description Switches the operations and screens of the machine according to the destination.</p> <p>Purpose To be executed after replacing the backup RAM on the main PCB or initializing the backup RAM by running maintenance item U020, in order to return the setting to the value before replacement or initialization.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the destination using the up/down cursor keys. The selected item is displayed in reverse. <table><tr><th>Display</th><th>Description</th></tr><tr><td>JAPAN METRIC</td><td>Metric (Japan) specifications</td></tr><tr><td>INCH</td><td>Inch (North America) specifications</td></tr><tr><td>EUROPE METRIC</td><td>Metric (Europe) specifications</td></tr><tr><td>ASIA PACIFIC</td><td>Metric (Asia Pacific) specifications</td></tr><tr><td>CHINA</td><td>China specifications</td></tr></table> <ol style="list-style-type: none">2. Press the start key. The setting is set, and the machine automatically returns to the same status as when the power is turned on. <p>Completion To exit this maintenance item without changing the current count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> <p>Supplement The specified initial settings are provided according to the destinations in the maintenance items below. To change the initial settings in those items, be sure to run maintenance item U021 after changing the destination.</p> <p>Initial setting according to the destinations</p> <table><tr><th>Maintenance item No.</th><th>Title</th><th>Japan</th><th>Inch</th><th>Europe Metric, Asia Pacific, China</th></tr><tr><td>253</td><td>Switching between double and single counts</td><td>Single</td><td>Double</td><td>Double</td></tr></table>	Display	Description	JAPAN METRIC	Metric (Japan) specifications	INCH	Inch (North America) specifications	EUROPE METRIC	Metric (Europe) specifications	ASIA PACIFIC	Metric (Asia Pacific) specifications	CHINA	China specifications	Maintenance item No.	Title	Japan	Inch	Europe Metric, Asia Pacific, China	253	Switching between double and single counts	Single	Double	Double
Display	Description																						
JAPAN METRIC	Metric (Japan) specifications																						
INCH	Inch (North America) specifications																						
EUROPE METRIC	Metric (Europe) specifications																						
ASIA PACIFIC	Metric (Asia Pacific) specifications																						
CHINA	China specifications																						
Maintenance item No.	Title	Japan	Inch	Europe Metric, Asia Pacific, China																			
253	Switching between double and single counts	Single	Double	Double																			

Maintenance item No.	Description								
U253	<p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose According to user (copy service provider) request, select if A3/11" x 17" paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select double or single count using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="331 564 1399 716"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SINGLE COUNT</td><td>Single count for all size paper</td></tr> <tr> <td>DOUBLE COUNT (A3/LEDGER)</td><td>Double count for A3/11" x 17" paper only</td></tr> <tr> <td>DOUBLE COUNT (B4)</td><td>Double count for B4 size or larger</td></tr> </tbody> </table> <p>Initial setting: DOUBLE COUNT</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SINGLE COUNT	Single count for all size paper	DOUBLE COUNT (A3/LEDGER)	Double count for A3/11" x 17" paper only	DOUBLE COUNT (B4)	Double count for B4 size or larger
Display	Description								
SINGLE COUNT	Single count for all size paper								
DOUBLE COUNT (A3/LEDGER)	Double count for A3/11" x 17" paper only								
DOUBLE COUNT (B4)	Double count for B4 size or larger								
U254	<p>Turning auto start function on/off</p> <p>Description Selects if the auto start function is turned on.</p> <p>Purpose Normally no change is necessary. If incorrect operation occurs, turn the function off: this may solve the problem.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select either ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="331 1184 1399 1299"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Auto start function on</td></tr> <tr> <td>OFF</td><td>OFF Auto start function off</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Auto start function on	OFF	OFF Auto start function off		
Display	Description								
ON	Auto start function on								
OFF	OFF Auto start function off								

Maintenance item No.	Description						
U258	<p>Switching copy operation at toner empty detection</p> <p>Description Selects if continuous copying is enabled after toner empty is detected, and sets the number of copies that can be made after the detection.</p> <p>Purpose To be set according to user request.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting 1. Select single or continuous copying using the up/down cursor keys. The selected item is displayed in reverse.</p> <table border="1" data-bbox="331 593 1399 707"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SINGLE</td><td>Enables only single copying.</td></tr> <tr> <td>CONTINUE</td><td>Enables single and continuous copying.</td></tr> </tbody> </table> <p>Initial setting: SINGLE</p> <p>2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SINGLE	Enables only single copying.	CONTINUE	Enables single and continuous copying.
Display	Description						
SINGLE	Enables only single copying.						
CONTINUE	Enables single and continuous copying.						
U260	<p>Changing the copy count timing</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user (copy service provider) request. If a paper jam occurs frequently in the finisher when the number of copies is counted at the time of paper ejection, copies are provided without copy counts. The copy service provider cannot charge for such copying. To prevent this, the copy timing should be made earlier. If a paper jam occurs frequently in the paper conveying or fixing sections when the number of copies is counted before the paper reaches those sections, copying is charged without a copy being made. To prevent this, the copy timing should be made later.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting 1. Select the copy count timing using the up/down cursor keys. The selected item is displayed in reverse.</p> <table border="1" data-bbox="331 1294 1399 1408"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FEED</td><td>When secondary paper feed starts</td></tr> <tr> <td>EJECT</td><td>When the paper is ejected</td></tr> </tbody> </table> <p>Initial setting: EJECT</p> <p>2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FEED	When secondary paper feed starts	EJECT	When the paper is ejected
Display	Description						
FEED	When secondary paper feed starts						
EJECT	When the paper is ejected						

Maintenance item No.	Description								
U264	<p>Setting the display order of the date</p> <p>Description Selects year, month and day as the order of that appears on lists, etc.</p> <p>Purpose Set according to the user preference.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <div><div><div>1. Press the start key. The screen for selecting an item is displayed.</div><div>2. Select the desired order using the up/down cursor keys.</div></div><table><tr><th>Display</th><th>Setting</th></tr><tr><td>YEAR-MONTH-DATE</td><td>Year/Month/Day</td></tr><tr><td>MONTH-DATE-YEAR</td><td>Month/Day/Year</td></tr><tr><td>DATE-MONTH-YEAR</td><td>Day/Month/Year</td></tr></table><p>Initial setting: "MONTH-DATE-YEAR" (for the inch specifications) "DATE-MONTH-YEAR" (for the metric specifications)</p><div><div>3. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</div></div><p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p></div>	Display	Setting	YEAR-MONTH-DATE	Year/Month/Day	MONTH-DATE-YEAR	Month/Day/Year	DATE-MONTH-YEAR	Day/Month/Year
Display	Setting								
YEAR-MONTH-DATE	Year/Month/Day								
MONTH-DATE-YEAR	Month/Day/Year								
DATE-MONTH-YEAR	Day/Month/Year								
U265	<p>Setting OEM purchaser code</p> <p>Description Sets the OEM purchaser code.</p> <p>Purpose Sets the code when replacing the main PCB and the like.</p> <p>Method Press the start key.</p> <p>Setting</p> <div><div><div>1. Use the numeric keys or left/right cursor keys to adjust the preset value.</div><div>2. Press the start key. The count is set, and the screen for selecting a maintenance item is displayed.</div></div><p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p></div>								
U277	<p>Setting auto application change time</p> <p>Description Sets the time that passes until the machine starts automatically printing after completing copying or operation when the machine is used as a printer or fax.</p> <p>Purpose According to user request, changes the setting.</p> <p>Method Press the start key. The current setting is displayed.</p> <p>Setting</p> <div><div><div>1. Change the setting using the left/right cursor keys.</div></div><table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Switching time</td><td>30 to 270 (s)</td><td>30</td></tr></table><p>The setting can be changed by 30 s per step.</p><div><div>2. Press the start key. The value is set, and the screen for selecting a maintenance item No. is displayed.</div></div><p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p></div>	Description	Setting range	Initial setting	Switching time	30 to 270 (s)	30		
Description	Setting range	Initial setting							
Switching time	30 to 270 (s)	30							

Maintenance item No.	Description																
U326	<p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the contact glass when scanning from the optional DP.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <p>1. Select ON or OFF using the up/down cursor keys.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Displays the cleaning guidance</td></tr><tr><td>OFF</td><td>Not to display the cleaning guidance</td></tr></table> <p>Initial setting: ON</p> <p>2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Displays the cleaning guidance	OFF	Not to display the cleaning guidance										
Display	Description																
ON	Displays the cleaning guidance																
OFF	Not to display the cleaning guidance																
U332	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/11" x 8 1/2" size. The coefficient set here is used to convert the black ratio in relation to the A4/11" x 8 1/2" size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/11" x 8 1/2" size for copy mode, printer mode and fax mode respectively.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <p>1. Select copier mode (COPY), printer mode (PRT) or fax mode (FAX) using the up/down cursor keys.</p> <p>2. Change the setting using the cursor left/right keys.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>COPY</td><td>Size parameter for copier mode</td><td>0.1 to 3.0</td><td>1.0</td></tr><tr><td>PRINTER</td><td>Size parameter for printer mode</td><td>0.1 to 3.0</td><td>1.0</td></tr><tr><td>FAX</td><td>Size parameter for fax mode</td><td>0.1 to 3.0</td><td>1.0</td></tr></table> <p>3. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>	Display	Description	Setting range	Initial setting	COPY	Size parameter for copier mode	0.1 to 3.0	1.0	PRINTER	Size parameter for printer mode	0.1 to 3.0	1.0	FAX	Size parameter for fax mode	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting														
COPY	Size parameter for copier mode	0.1 to 3.0	1.0														
PRINTER	Size parameter for printer mode	0.1 to 3.0	1.0														
FAX	Size parameter for fax mode	0.1 to 3.0	1.0														

Maintenance item No.	Description										
U341	<p>Specific paper feed location setting for printing function</p> <p>Description Sets a paper feed location specified for printer output.</p> <p>Purpose To use a paper feed location only for printer output.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the paper feed location for the printer using the up/down cursor keys. The selected item is displayed in reverse. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>PF1</td><td>Drawer</td></tr> <tr> <td>PF2</td><td>First paper feeder</td></tr> <tr> <td>PF3</td><td>Second paper feeder*</td></tr> <tr> <td>PF4</td><td>Third paper feeder*</td></tr> </tbody> </table> <p>*: Optional.</p> <ol style="list-style-type: none"> 3. Change the setting using the left/right cursor keys. 0: OFF 1: ON 4. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>	Display	Description	PF1	Drawer	PF2	First paper feeder	PF3	Second paper feeder*	PF4	Third paper feeder*
Display	Description										
PF1	Drawer										
PF2	First paper feeder										
PF3	Second paper feeder*										
PF4	Third paper feeder*										
U342	<p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously. When the restriction is set, the number of sheets that can be ejected continuously to the internal eject tray will be limited to 250.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select either ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Sets restriction on the number of sheets</td></tr> <tr> <td>OFF</td><td>Cancels restriction on the number of sheets</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Sets restriction on the number of sheets	OFF	Cancels restriction on the number of sheets				
Display	Description										
ON	Sets restriction on the number of sheets										
OFF	Cancels restriction on the number of sheets										

Maintenance item No.	Description						
U343	<p>Switching between duplex/simplex copy mode</p> <p>Description Switches the initial setting between duplex and simplex copy.</p> <p>Purpose To be set according to frequency of use: set to the more frequently used mode.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting 1. Select ON or OFF using the up/down cursor keys. The selected item is displayed in reverse.</p> <table border="1"> <tr> <th>Display</th><th>Description</th></tr> <tr> <td>ON</td><td>Duplex copy</td></tr> <tr> <td>OFF</td><td>Simplex copy</td></tr> </table> <p>Initial setting: OFF</p> <p>2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Duplex copy	OFF	Simplex copy
Display	Description						
ON	Duplex copy						
OFF	Simplex copy						
U344	<p>Setting preheat/energy saver mode</p> <p>Description Changes the control for preheat/energy saver mode.</p> <p>Purpose According to user request, selects which has priority, the recovery time from preheat or energy saver.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting 1. Select control mode using the up/down cursor keys. The selected item is displayed in reverse.</p> <table border="1"> <tr> <th>Display</th><th>Control in preheat mode</th></tr> <tr> <td>ENERGY STAR</td><td>STAR The fixing control temperature is lowered by 20°C/68°F and forced stabilization is performed 10 seconds after exiting preheat.</td></tr> <tr> <td>GEEA</td><td>The fixing control temperature is lowered by 15°C/59°F and forced stabilization is performed 10 seconds after exiting preheat.</td></tr> </table> <p>Initial setting: ENERGY STAR</p> <p>2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Control in preheat mode	ENERGY STAR	STAR The fixing control temperature is lowered by 20°C/68°F and forced stabilization is performed 10 seconds after exiting preheat.	GEEA	The fixing control temperature is lowered by 15°C/59°F and forced stabilization is performed 10 seconds after exiting preheat.
Display	Control in preheat mode						
ENERGY STAR	STAR The fixing control temperature is lowered by 20°C/68°F and forced stabilization is performed 10 seconds after exiting preheat.						
GEEA	The fixing control temperature is lowered by 15°C/59°F and forced stabilization is performed 10 seconds after exiting preheat.						
U345	<p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed. This maintenance mode is effective for only Japanese specification.</p>						
U402	<p>Adjusting margins of image printing</p> <p>Adjustment See page 1-6-20.</p>						
U403	<p>Adjusting margins for scanning an original on the contact glass</p> <p>Adjustment See page 1-6-37.</p>						

Maintenance item No.	Description																									
U404	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Used if margins are not correct when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <p>U402 → U403 → U404</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>A MARGIN</td><td>Left margin</td><td>0 to 10.0</td><td>2.0</td><td>0.1 mm</td></tr><tr><td>B MARGIN</td><td>Leading edge margin</td><td>0 to 10.0</td><td>3.0</td><td>0.1 mm</td></tr><tr><td>C MARGIN</td><td>Right margin</td><td>0 to 10.0</td><td>2.0</td><td>0.1 mm</td></tr><tr><td>D MARGIN</td><td>Trailing edge margin</td><td>0 to 10.0</td><td>2.0</td><td>0.1 mm</td></tr></table> <p>Increasing the setting makes the margin wider, and decreasing it makes the margin narrower.</p> <div><div><p>Ejection direction (reference)</p></div><div></div></div> <p>Figure 1-4-6 Correct margin amount</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Left margin	0 to 10.0	2.0	0.1 mm	B MARGIN	Leading edge margin	0 to 10.0	3.0	0.1 mm	C MARGIN	Right margin	0 to 10.0	2.0	0.1 mm	D MARGIN	Trailing edge margin	0 to 10.0	2.0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A MARGIN	Left margin	0 to 10.0	2.0	0.1 mm																						
B MARGIN	Leading edge margin	0 to 10.0	3.0	0.1 mm																						
C MARGIN	Right margin	0 to 10.0	2.0	0.1 mm																						
D MARGIN	Trailing edge margin	0 to 10.0	2.0	0.1 mm																						
U407	<p>Adjusting the leading edge registration for memory image printing</p> <p>Adjustment See page 1-6-17.</p>																									

Maintenance item No.	Description						
U504	<p>Initializing the scanner NIC</p> <p>Description Initializing the optional scanner NIC to its factory default.</p> <p>Purpose To return to a setup at the time of factory shipments.</p> <p>Method 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All data in the scanner NIC is initialized.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U506	<p>Setting the time out</p> <p>Description Sets the communication timeout time for connection to a computer.</p> <p>Purpose To change the preset value if a communication error occurs after connection to a computer continues for a long time. By delaying the error detection timing, the error may be cleared. If the error is not cleared after the preset value is changed, however, return the preset value to the initial value.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting 1. Select ON or OFF using the left/right cursor keys. The selected item is displayed in reverse.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>timeout time</td><td>10 to 120 (s)</td><td>10</td></tr></table> <p>The setting can be changed by 10 s per step.</p> <p>2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	timeout time	10 to 120 (s)	10
Description	Setting range	Initial setting					
timeout time	10 to 120 (s)	10					

Maintenance item No.	Description														
U901	<p>Checking/clearing copy counts by paper feed locations</p> <p>Description Displays or clears copy counts by paper feed locations.</p> <p>Purpose To check the time to replace consumable parts. Also to clear the counts after replacing the consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The counts by paper feed locations are displayed. 2. Change the screen using the left/right cursor keys. <table border="1" data-bbox="331 504 1396 772"> <thead> <tr> <th>Display</th><th>Paper feed locations</th></tr> </thead> <tbody> <tr> <td>BYP</td><td>Bypass tray</td></tr> <tr> <td>PF1</td><td>Drawer</td></tr> <tr> <td>PF2</td><td>First paper feeder</td></tr> <tr> <td>PF3</td><td>Second paper feeder*</td></tr> <tr> <td>PF4</td><td>Third paper feeder*</td></tr> <tr> <td>DUP</td><td>Duplex section*</td></tr> </tbody> </table> <p>*: Optional.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the count to be cleared using the up/down cursor keys. The selected item is displayed in reverse. However, PF2, 3, and 4 are displayed only and cannot be cleared. 2. Press the start key. The count is cleared. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Paper feed locations	BYP	Bypass tray	PF1	Drawer	PF2	First paper feeder	PF3	Second paper feeder*	PF4	Third paper feeder*	DUP	Duplex section*
Display	Paper feed locations														
BYP	Bypass tray														
PF1	Drawer														
PF2	First paper feeder														
PF3	Second paper feeder*														
PF4	Third paper feeder*														
DUP	Duplex section*														
U903	<p>Checking/clearing the paper jam counts</p> <p>Description Displays or clears the jam counts by jam locations.</p> <p>Purpose To check the paper jam status. Also to clear the jam counts after replacing consumable parts.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item using the up/down cursor keys. 3. Press the start key. The code by type is displayed. <table border="1" data-bbox="331 1294 1396 1411"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>COUNT</td><td>Displays/clears the jam counts</td></tr> <tr> <td>TOTAL COUNT</td><td>Displays the total jam counts</td></tr> </tbody> </table> <p>Method: Displays/clears the jam counts</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. 2. Select the counts for all jam codes and select the ALL. Jam counts cannot be cleared individually. 3. Press the start key. The counts are cleared. <p>Method: Displays the total jam counts</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. The total number of jam count cannot be cleared. 2. To return to the screen for selecting an item, press the stop/clear key. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Description	COUNT	Displays/clears the jam counts	TOTAL COUNT	Displays the total jam counts								
Display	Description														
COUNT	Displays/clears the jam counts														
TOTAL COUNT	Displays the total jam counts														

Maintenance item No.	Description														
U904	<p>Checking/clearing the service call counts</p> <p>Description Displays or clears the service call code counts by types.</p> <p>Purpose To check the service call code status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item using the up/down cursor keys. 3. Press the start key. The code by type is displayed. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>COUNT</td><td>Displays/clears the service call code counts</td></tr> <tr> <td>TOTAL COUNT</td><td>Displays the total service call code counts</td></tr> </tbody> </table> <p>Method: Displays/clears the service call code counts</p> <ol style="list-style-type: none"> 1. Select the code to be cleared using the up/down cursor keys. Change the screen using the left/right cursor keys. Select the counts for all service call codes and select the ALL. 2. Press the start key. The count is cleared. <p>Method: Displays the total service call code counts</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. The total number of service call code count cannot be cleared. 2. To return to the screen for selecting an item, press the stop/clear key. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Description	COUNT	Displays/clears the service call code counts	TOTAL COUNT	Displays the total service call code counts								
Display	Description														
COUNT	Displays/clears the service call code counts														
TOTAL COUNT	Displays the total service call code counts														
U905	<p>Checking counts by optional devices</p> <p>Description Displays the counts of the optional DP or finisher.</p> <p>Purpose To check the use of the DP and finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the device using the up/down cursor keys, the count of which is to be checked and press the start key. The count of the selected device is displayed. <p>DP</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ADP</td><td>No. of single-sided originals that has passed through the DP in ADP mode</td></tr> <tr> <td>RADP</td><td>No. of double-sided originals that has passed through the DP in RADP mode</td></tr> </tbody> </table> <p>Finisher</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>CP CNT</td><td>No. of copies that has passed</td></tr> <tr> <td>STAPLE</td><td>Frequency the stapler has been activated</td></tr> <tr> <td>BUNDLE EJECT</td><td>Frequency the bundle discharge has been activated</td></tr> </tbody> </table> <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ADP	No. of single-sided originals that has passed through the DP in ADP mode	RADP	No. of double-sided originals that has passed through the DP in RADP mode	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated	BUNDLE EJECT	Frequency the bundle discharge has been activated
Display	Description														
ADP	No. of single-sided originals that has passed through the DP in ADP mode														
RADP	No. of double-sided originals that has passed through the DP in RADP mode														
Display	Description														
CP CNT	No. of copies that has passed														
STAPLE	Frequency the stapler has been activated														
BUNDLE EJECT	Frequency the bundle discharge has been activated														

Maintenance item No.	Description
U906	<p>Resetting partial operation control</p> <p>Description Resets the service call code for partial operation control.</p> <p>Purpose To be reset after partial operation is performed due to problems in the drawers or other sections, and the related parts are serviced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key to reset partial operation control. The maintenance mode is exited, and the machine returns to the same status as when the power switch is turned on.
U908	<p>Changing the total counter value</p> <p>Description Displays the total counter value.</p> <p>Purpose To check the total counter value.</p> <p>Method Press the start key. The current total counter value is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>
U910	<p>Clearing the black ratio data</p> <p>Description Clears the accumulated black ratio data for A4 sheets.</p> <p>Purpose To clear data as required at times such as during maintenance service.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. The accumulated black ratio data is cleared, and the screen for selecting a maintenance item is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>
U911	<p>Checking/clearing copy counts by paper sizes</p> <p>Description Displays and clears the paper feed counts by paper sizes.</p> <p>Purpose To check or clear the counts after replacing consumable parts.</p> <p>Method Press the start key. The screen for the paper feed counts by paper size is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the paper size to be cleared using the up/down cursor keys. The selected item is displayed in reverse. To clear all counts, select the ALL. 2. Press the start key. The count is cleared. When clearing all counts, the screen for selecting a maintenance item is displayed. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>










Maintenance item No.	Description																																		
U917	<p>Setting backup data reading/writing</p> <p>Description Stores backup data from the fax control PCB (when an optional fax kit is installed) into Compact Flash or reads the data from Compact Flash.</p> <p>Purpose To store and write data when replacing the PCB.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Turn the power switch off and disconnect the power plug. 2. Remove the rear cover. 3. Insert Compact Flash in a notch hole of the machine. 4. While pressing the Copier key, turn on the power switch and connect the power plug. Press and hold on the Copier key until the message "Please wait." disappears. 5. Enter the maintenance item. 6. Press the start key. The screen for selecting an item is displayed. 7. Select the item using the up/down cursor keys. The selected item is displayed in reverse. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SRAM→CF:BKUP</td><td>Writing the backup data of fax control PCB</td></tr> <tr> <td>CF→SRAM:BKUP</td><td>Reading the backup data of fax control PCB</td></tr> <tr> <td>SRAM→CF:DIAL</td><td>Writing the backup data of fax dial information</td></tr> <tr> <td>CF→SRAM:DIAL</td><td>Reading the backup data of fax dial information</td></tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Reading or writing is executed, and the screen displays the result. <p>If the operation was successful: EXECUTE 0100 CHECK SUM **** CODE 0000</p> <p>If the operation failed: EXECUTE 0100 CHECK SUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. See "Error Codes for Operation U917 and U926" below.</p> <ol style="list-style-type: none"> 9. Turn the power switch off and disconnect the power plug. 10. Remove the Compact Flash from the machine. <p>Error Codes for Operation U917 and U926</p> <table border="1"> <thead> <tr> <th>Code</th><th>Meaning</th></tr> </thead> <tbody> <tr> <td>0102</td><td>Detects call for service on fax control PCB.</td></tr> <tr> <td>0104</td><td>Communication error.</td></tr> <tr> <td>0105</td><td>Detects call for service on main PCB.</td></tr> <tr> <td>01FF</td><td>CF error.</td></tr> <tr> <td>0202</td><td>No CF card.</td></tr> <tr> <td>0203</td><td>No data in CF card.</td></tr> <tr> <td>0204</td><td>CF data is incompatible.</td></tr> <tr> <td>0205</td><td>Bad CF data (Checksum error)</td></tr> <tr> <td>0206</td><td>CF read error.</td></tr> <tr> <td>0207</td><td>CF write error.</td></tr> <tr> <td>0212</td><td>Fax control PCB flash memory error.</td></tr> </tbody> </table>	Display	Description	SRAM→CF:BKUP	Writing the backup data of fax control PCB	CF→SRAM:BKUP	Reading the backup data of fax control PCB	SRAM→CF:DIAL	Writing the backup data of fax dial information	CF→SRAM:DIAL	Reading the backup data of fax dial information	Code	Meaning	0102	Detects call for service on fax control PCB.	0104	Communication error.	0105	Detects call for service on main PCB.	01FF	CF error.	0202	No CF card.	0203	No data in CF card.	0204	CF data is incompatible.	0205	Bad CF data (Checksum error)	0206	CF read error.	0207	CF write error.	0212	Fax control PCB flash memory error.
Display	Description																																		
SRAM→CF:BKUP	Writing the backup data of fax control PCB																																		
CF→SRAM:BKUP	Reading the backup data of fax control PCB																																		
SRAM→CF:DIAL	Writing the backup data of fax dial information																																		
CF→SRAM:DIAL	Reading the backup data of fax dial information																																		
Code	Meaning																																		
0102	Detects call for service on fax control PCB.																																		
0104	Communication error.																																		
0105	Detects call for service on main PCB.																																		
01FF	CF error.																																		
0202	No CF card.																																		
0203	No data in CF card.																																		
0204	CF data is incompatible.																																		
0205	Bad CF data (Checksum error)																																		
0206	CF read error.																																		
0207	CF write error.																																		
0212	Fax control PCB flash memory error.																																		

Maintenance item No.	Description
U920	<p>Checking the accounting counts</p> <p>Description Checks the accounting counts.</p> <p>Purpose To check the accounting counts.</p> <p>Method Press the start key. The current counts of copy counter, printer counter and fax counter are displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>
U925	<p>Checking/clearing the system error counts</p> <p>Description Displays and clears the count value of system error.</p> <p>Purpose To check the system error status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Method Press the start key. The count for system error detection by type is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. 2. Select the counts for system error and select the ALL. System error counts cannot be cleared individually. 3. Press the start key. The counts are cleared. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>
U926	<p>Rewriting FAX program</p> <p>Description Downloads the fax program and fax fonts when installing an optional fax kit.</p> <p>Purpose To run when upgrading the fax program and fax fonts.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Turn the power switch off and disconnect the power plug. 2. Remove the rear cover. 3. Insert Compact Flash in a notch hole of the machine. 4. While pressing the Copier key, turn on the power switch and connect the power plug. Press and hold on the Copier key until the message "Please wait." disappears. 5. Enter the maintenance item. 6. Press the start key. Downloading of the fax program starts and the result shown below is displayed. <p style="margin-left: 40px;">If the operation was successful: EXECUTE 0100 CHECKSUM **** CODE 0000</p> <p style="margin-left: 40px;">If the operation failed: EXECUTE 0100 CHECKSUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure.</p> <p>7. Then, downloading of the fax fonts starts and the result shown below is displayed.</p>

Maintenance item No.	Description						
U926	<p>If the operation was successful: EXECUTE 0100 CHECKSUM **** CODE 0000</p> <p>If the operation failed: EXECUTE 0100 CHECKSUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. See "Error Codes for Operation U917 and U926" on page 1-4-50.</p> <p>8. Turn the power switch off and disconnect the power plug. 9. Remove the Compact Flash from the machine.</p>						
U927	<p>Clearing the all accounting counts and machine life counts Description Clears the all accounting counts and machine life counts. Purpose To start the counters with value 0 when installing the machine. Supplement The all accounting counts and the machine life counter can be cleared only once only if the count values are 1000 or less. Method 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All accounting counts and machine life counts are cleared. If the counts cannot be cleared, CANNOT EXECUTE is displayed. Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U928	<p>Checking machine life counts Description Displays the machine life counts. Purpose To check the machine life counts. Method Press the start key. The current machine life counts is displayed. Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U941	<p>Setting the default magnification ratio of the default drawer Description Sets the default magnification ratio when paper selection of copy default setting is set to the default drawer. Purpose Accounting to user request, changes the setting. Method Press the start key. The screen for selecting an item is displayed. Setting 1. Select 100% or AMS using the up/down cursor keys. The selected item is displayed in reverse.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>100%</td><td>100 % magnification ratio</td></tr> <tr> <td>AMS</td><td>Automatical magnification ratio</td></tr> </tbody> </table> <p>Initial setting: 100 % magnification ratio 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	100%	100 % magnification ratio	AMS	Automatical magnification ratio
Display	Description						
100%	100 % magnification ratio						
AMS	Automatical magnification ratio						

Maintenance item No.	Description												
U942	<p>Adjusting the DP amount of slack in the original</p> <p>Description Adjusts the DP amount of slack in the original.</p> <p>Purpose To run this mode if original jams or Z folds occur when copying from the DP.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse.2. Change the setting using the left/right cursor keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CONVEY</td><td>Original conveying motor (OCM)</td><td>-10 to +20</td><td>0</td></tr><tr><td>FEED</td><td>Original feed motor (OFM)</td><td>-10 to +20</td><td>0</td></tr></table> <p>Increasing the setting, the larger the amount of slack; decreasing the setting, the smaller the amount of slack.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none">1. Press the interrupt key. The machine enters the interrupt copy mode.2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CONVEY	Original conveying motor (OCM)	-10 to +20	0	FEED	Original feed motor (OFM)	-10 to +20	0
Display	Description	Setting range	Initial setting										
CONVEY	Original conveying motor (OCM)	-10 to +20	0										
FEED	Original feed motor (OFM)	-10 to +20	0										
U984	<p>Checking the developing unit number</p> <p>Description Displays the developing unit number.</p> <p>Purpose To check the developing unit number.</p> <p>Method Press the start key. The developing unit number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>												
U985	<p>Displaying the developing unit history</p> <p>Description Displays the past record of machine number and the developing unit counter.</p> <p>Purpose To check the count value of machine number and the developing unit counter.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The count value of machine number and the developing unit counter is displayed.2. Change the screen using the left/right cursor keys. Past record of 5 cases is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>												

Maintenance item No.	Description								
U990	<p>Checking/clearing the time for the exposure lamp to light</p> <p>Description Displays, clears or changes the accumulated time for the exposure lamp to light.</p> <p>Purpose To check duration of use of the exposure lamp. Also to clear the accumulated time for the lamp after replacement.</p> <p>Method Press the start key. The accumulated time of illumination for the exposure lamp is displayed in minutes.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the CLEAR using the up/down cursor keys. 2. Press the start key. The accumulated time is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Setting</p> <ol style="list-style-type: none"> 1. Enter a seven-digit accumulated time using the numeric keys. 2. Press the start key. The time is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the accumulated time, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U991	<p>Checking the scanner count</p> <p>Description Displays the scanner operation count.</p> <p>Purpose To check the status of use of the scanner.</p> <p>Method Press the start key. The screen for the scanner operation count is displayed.</p> <table border="1" data-bbox="331 1014 1399 1167"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>COPY</td><td>Scanner operation count for copying</td></tr> <tr> <td>FAX</td><td>Scanner operation count for fax</td></tr> <tr> <td>NWS</td><td>Network scanner operation count</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	COPY	Scanner operation count for copying	FAX	Scanner operation count for fax	NWS	Network scanner operation count
Display	Description								
COPY	Scanner operation count for copying								
FAX	Scanner operation count for fax								
NWS	Network scanner operation count								


Maintenance item No.	Description												
U993	<p>Outputting a VTC-PG pattern</p> <p>Description Selects and outputs a VTC-PG pattern created in the machine.</p> <p>Purpose When performing respective image printing adjustments, used to check the machine status apart from that of the scanner with a non-scanned output VTC-PG pattern.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key. The screen for selecting an item is displayed.2. Select the VTC-PG pattern to be output using the up/down cursor keys. <table><tr><th>Display</th><th>PG pattern to be output</th><th>Purpose</th></tr><tr><td>PG1</td><td></td><td>Center line adjustment</td></tr><tr><td>PG2</td><td></td><td>Lateral squareness adjustment Magnification adjustment</td></tr><tr><td>PG3</td><td></td><td>-</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key. The copy mode screen is displayed.4. Press the start key. A VTC-PG pattern is output. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	PG pattern to be output	Purpose	PG1		Center line adjustment	PG2		Lateral squareness adjustment Magnification adjustment	PG3		-
Display	PG pattern to be output	Purpose											
PG1		Center line adjustment											
PG2		Lateral squareness adjustment Magnification adjustment											
PG3		-											

This page is intentionally left blank.

1-4-2 Management mode

In addition to a maintenance function for service, the machine is equipped with a management function which can be operated by users (mainly by the machine administrator). In this management mode, settings such as default settings can be changed.

(1) Using the management mode



(2) Setting the job accounting

Registering a new account

Registers ID-codes and the limit of use for each account.

1. Select [Edit Job Accounting] and then press the enter key.
2. Select [New registration] and then press the enter key.
3. Enter the ID-code (up to 8 digits) using the numeric keys.
4. Press the enter key.
5. Set the limit of use.
6. Select [End] and then press the enter key.

Deleting an account

1. Select [Edit Job Accounting] and then press the enter key.
2. Select [Delete] and then press the enter key.
3. Select the ID-code to delete and then press the enter key.
4. Select [Yes] or [No] and then press the enter key.

Changing limit of use

1. Select [Edit Job Accounting] and then press the enter key.
2. Select [Change limit in use] and then press the enter key.
3. Select the ID-code to change and then press the enter key.
4. Change the limit of use.
5. Select [End] and then press the enter key.

All account management

You can browse the total output count, output the job accounting report, and clear the counter for all accounts.

1. Select [Job Accounting Total] and then press the enter key.
2. Select [Print report] and then press the enter key. The management report is printed out.
3. Select [Counter clear] and then press the enter key.
4. Select [Yes] or [No] and then press the enter key.

Individual account management

Checks the output count and/or clears the counter for individual accounts.

1. Select [Each Job Accounting TL] and then press the enter key. The output counts of individual accounts are displayed.
2. Select the ID-code to clear and then press the enter key.
3. Select [Yes] or [No] and then press the enter key.

Job accounting ON/OFF

1. Select [Job Accounting On/Off] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Copier job accounting ON/OFF

1. Select [Job Accounting Def. Set.] and then press the enter key.
2. Select [Copy Job Account.] and then press the enter key.
3. Select [On] or [Off] and then press the enter key.

Printer job accounting ON/OFF

1. Select [Job Accounting Def. Set.] and then press the enter key.
2. Select [Prnt Job Account.] and then press the enter key.
3. Select [On] or [Off] and then press the enter key.

Scanner job accounting ON/OFF

Note: This setting is only available when the optional network scanner board is installed in the machine.

1. Select [Job Accounting Def. Set.] and then press the enter key.
2. Select [Scanner Job Accnt] and then press the enter key.
3. Select [On] or [Off] and then press the enter key.

Fax job accounting ON/OFF

Note: This setting is only available when the optional fax kit is installed in the machine.

1. Select [Job Accounting Def. Set.] and then press the enter key.
2. Select [Fax Job Accountng] and then press the enter key.
3. Select [On] or [Off] and then press the enter key.

Operation against excess over limit

Determines whether to stop output by prohibiting immediately use of the machine, to stop the operation from the next job or to display a warning message onle, when the limit of count that has been set with the function of the limit of use is exceeded.

1. Select [Job Accounting Def. Set.] and then press the enter key.
2. Select [Excess limit Set.] and then press the enter key.
3. Select [Stop job immediately], [Stop after job done] or [Only warning] and then press the enter key.

(3) Copy default

Exposure mode

Selects the exposure mode at power-on.

1. Select [Exposure Mode] and then press the enter key.
2. Select [Manual] or [Auto] and then press the enter key.

Original quality

Selects the image quality at power-on.

1. Select [Orig Quality] and then press the enter key.
2. Select [Text+Photo], [Photo] or [Text] and then press the enter key.

Eco print mode ON/OFF

Determines whether or not the eco print mode will be the default setting in the initial mode.

1. Select [EcoPrint] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Background color adjustment

Adjust the ground color of the copied paper.

1. Select [Background adjst] and then press the enter key.
2. Adjust the exposure and then press the enter key.
Setting range: 1 to 5

Paper selection

Sets whether the copier will automatically select the same size of copy paper as the original once an original is set, or whether the designated default drawer will be automatically selected.

1. Select [Paper Select] and then press the enter key.
2. Select [Auto] or [Default cassette] and then press the enter key.

Paper type (Auto paper selection mode)

Selects the types of paper that will be available for selection under the APS (Auto Paper Selection) mode.

1. Select [Paper type(Auto)] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.
3. If selected [On], select the desired paper type and then press the enter key.

Default drawer

Sets one drawer that will be selected automatically regardless of the size of paper loaded in that drawer.

1. Select [Default cassette] and then press the enter key.
2. Select the drawer that will be used with priority.
Settings: Cassette 1/Cassette 2/Cassette 3/ Cassette 4

*For 16 ppm model, the setting for drawer 2, 3 and 4 will only be available when the optional paper feeder is installed.

* For 20 ppm model, the setting for drawer 3 and 4 will only be available when the optional paper feeder is installed.

Default magnification ratio

Sets whether or not the appropriate magnification ratio to be calculated automatically when selecting the size of copy paper.

1. Select [Default magnif.] and then press the enter key.
2. Select [100%] or [Auto %] and then press the enter key.

Auto exposure adjustment

Adjusts the overall exposure level for the auto exposure mode.

1. Select [Adj.Auto expos.] and then press the enter key.
2. Adjust the exposure and then press the enter key.
Setting range: 1 to 7

Auto exposure adjustment (OCR)

Adjusts the overall exposure level for scanning with OCR (Optical Character Recognition) software when using the optional scanner functions of this machine.

1. Select [Auto expos.(OCR)] and then press the enter key.
2. Adjust the exposure and then press the enter key.
Setting range: 1 to 7

Manual exposure adjustment (text+photo mode)

Adjusts the median exposure value when the text+photo mode is selected for the image quality.

1. Select [Txt+Photo Dens.] and then press the enter key.
2. Adjust the exposure and then press the enter key.
Setting range: 1 to 7

Manual exposure adjustment (text mode)

Adjusts the median exposure value when the text mode is selected for the image quality.

1. Select [Txt Ori Density] and then press the enter key.
2. Adjust the exposure and then press the enter key.
Setting range: 1 to 7

Manual exposure adjustment (photo mode)

Adjusts the median exposure value when the photo mode is selected for the image quality.

1. Select [Photo Ori Dnsity] and then press the enter key.
2. Adjust the exposure and then press the enter key.
Setting range: 1 to 7

Sort mode ON/OFF

Determines whether or not the Sort mode will be the default setting in the initial mode.

1. Select [Sort] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Offset copying

Determines whether or not the offset copy will be the default setting in the initial mode.

1. Select [Offset] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Auto Rotation mode ON/OFF

Determines whether or not the Auto Rotation mode will be the default setting in the initial mode.

1. Select [Auto Rotation] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Margin width

Determines the default value of the location and width of the margins in the margin mode.

1. Select [Margin Width] and then press the enter key.
2. Sets the margin widths and then press the enter key.
Setting range: 1/8" to 3/4" in 1/8" increments (inch specifications) 1 to 18 mm in 1mm increments (metric specifications)

Erased border width

Determines the default value for the width of the border to be erased in the two border erase modes.

1. Select [BorderEraseWidth] and then press the enter key.
2. Sets the widths and then press the enter key.
Setting range: 1/8" to 3/4" in 1/8" increments (inch specifications) 1 to 18 mm in 1mm increments (metric specifications)

Copy limit

Sets the limit for the number of copies (or copy sets) that can be made at a time.

1. Select [Copy Limit] and then press the enter key.
2. Sets the copy limit and then press the enter key.
Setting range: 1 to 999

Black-line correction

Reduces black lines that may be caused when the DP is used.

1. Select [Corr. Black line] and then press the enter key.
2. Select [None], [Weak] or [Strong] and then press the enter key.

(4) Machine default

Auto drawer switching ON/OFF

Turns automatic drawer switching ON or OFF.

1. Select [Auto Cassette SW] and then press the enter key.
2. Select [On/All types of paper], [On/Only same paper type] or [Off] and then press the enter key.

Paper size (drawer 1 to 4)

Sets the size of paper that is loaded in drawer 1 through 4.

1. Select one of the [Paper Size (1st) to (4th)] and then press the enter key.
2. Select [Auto Detection Metric], [Auto Detection Inch] or a paper size and then press the enter key.
 - * For 16 ppm model, the setting for drawer 2, 3 and 4 will only be available when the optional paper feeder is installed.
 - * For 20 ppm model, the setting for drawer 3 and 4 will only be available when the optional paper feeder is installed.

Paper type (drawer 1 to 4)

Sets the type of paper that is loaded in drawers 1 through 4.

1. Select one of the [Paper Type (1st) to (4th)] and then press the enter key.
2. Select the paper type and then press the enter key.
 - * For 16 ppm model, the setting for drawer 2, 3 and 4 will only be available when the optional paper feeder is installed.
 - * For 20 ppm model, the setting for drawer 3 and 4 will only be available when the optional paper feeder is installed.

Bypass tray settings display ON/OFF

1. Select one of the [Check Bypass] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Paper weight for paper type

Sets the paper weight for each paper type.

1. Select [P. type (Weight)] and then press the enter key.
2. Select paper type and then press the enter key.
3. Select paper weight and then press the enter key.

Duplex print for paper type

Sets whether or not each custom type of paper (custom 1 to custom 8) will be available for use in duplex printing.

1. Select [P. type (Duplex)] and then press the enter key.
2. Select one of the [Custom 1 to 8] and then press the enter key.
3. Select [On] or [Off] and then press the enter key.

Custom paper type

Sets whether or not to match the orientation in one-sided printing and two-sided printing.

1. Select [Special P. type] and then press the enter key.
2. Select [Match Print Direction] or [Fast Mode] and then press the enter key.

Original orientation

Sets the default original orientation.

1. Select [Orig. direction] and then press the enter key.
2. Select [Rear] or [Left top] and then press the enter key.

Auto sleep time

Sets the time that elapses before the auto sleep function.

1. Select [Sleep mode time] and then press the enter key.
2. Sets sleep mode type and then press the enter key.
Setting range:
1 to 240 min (Inch specifications)
1 to 120 min (metric specifications)

Auto low power time

Sets the time that elapses before the low power mode is automatically activated.

1. Select [Low power time] and then press the enter key.
2. Sets low power time and then press the enter key.
Setting range:
1 to 240 min (Inch specifications)
1 to 120 min (metric specifications)

Copy eject location

Sets the paper output location with priority for copying. This setting is only available when the optional finisher or job separator are installed in the machine.

1. Select [Copy Output Destn] and then press the enter key.
2. Select output location and then press the enter key.

Fax eject location

Sets where incoming faxes will be ejected. This setting is only available when the optional fax kit, finisher or job separator are installed in the machine.

1. Select [Fax Output Destn] and then press the enter key.
2. Select output location and then press the enter key.

Default operation mode

Sets whether the display that appears after power is turned on to the machine will be the one for the copy operation mode or for the fax operation mode. This setting is only available when the optional fax kit is installed.

1. Select [Main mode] and then press the enter key.
2. Select [Copy mode] or [Fax mode] and then press the enter key.

Key sound ON/OFF

Sets whether or not the operation panel will emit a beep sound each time a key is pressed.

1. Select [Key sound On/Off] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Day and time

Sets the current date and time.

1. Select [Date/Time] and then press the enter key.
2. Sets the current date and time.
3. Select [End] and then press the enter key.

Display contrast adjustment

Adjust the display contrast.

1. Select [Display Contrast] and then press the enter key.
2. Adjust the contrast and then press the enter key.
Setting range: 1 to 7

Changing the management code

Changes the management code.

1. Select [PIN # Change] and then press the enter key.
2. Enter a new 4-digit management code using the numeric keys.

Auto sleep ON/OFF

Sets whether or not to have the auto sleep function.

This setting is displayed only on the inch specification model.

1. Select [Auto Sleep] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Auto clear ON/OFF

Sets whether or not to have the auto clear function.

1. Select [Auto Clear] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

Auto clear time

Sets the time that elapses from completion of copying to activation of the auto clear function.

1. Select [Auto Clear Time] and then press the enter key.
2. Sets the time and then press the enter key. Setting range: 10 to 270 s

Silent mode ON/OFF

Sets whether or not to use the silent mode which shortens the length of time that the laser data writing motor continues to spin after each copy job is finished.

1. Select [Silent Mode] and then press the enter key.
2. Select [On] or [Off] and then press the enter key.

(5) Bypass setting**Paper size and type**

Sets the paper size and paper type for the bypass settings.

When using special papers such as transparency, cards, and postcards, be sure to set the paper type to prevent faulty transfer and faulty fixing.

1. Select paper size.

If the paper size is unknown or no particular paper size setting is required, select [Universal Size].

When setting a size, turn on the size input and use the left/right cursor key to select the paper size.

Setting range:

(Inch specifications)

Width: 3 7/8" to 11 5/8"

Length: 5 7/8" to 17"

(Metric specifications)

Width: 98 to 297 mm

Length: 148 to 432 mm

2. Press the enter key.
3. Select paper type and then press the enter key.

Selecting other standard sizes

Sets a special standard size.

1. Select [Other Regular Size] and then press the enter key.
2. Select paper size and then press the enter key.
3. Select paper type and then press the enter key.

(6) Checking the total counter and printing out the counter report

Checks the total count of copies, etc., and prints out the information as a counter report.

1. Select [Counter check] and then press the enter key.
2. Select [Output count] or [Scan count] and then press the enter key.
3. Select [End] and then press the enter key.
4. Select [Print counter report] and then press the enter key to print out a counter report.

(7) Status report print out

Prints out one of the status report.

1. Select [Print Report] and then press the enter key.
2. Select the report to print out and then press the enter key.

[Copy report]

[Machine report]

[Coverage report]

The selected status report will be printed out.

(8) Language selection function

Switches the language to be displayed on the operation panel.

1. Select [Language] and then press the enter key.
2. Select the language to use and then press the enter key.

Available languages:

Inch specifications

Japanese, English, French and Spanish

Metric specifications

English, German, French, Spanish and Italian

1-5-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops operating and displays the jam location on the operation panel.

Paper misfeed counts sorted by the detection condition can be checked in maintenance item U903.

To remove paper jammed in the machine, open the front cover, left cover, or pull the drawer out.

To remove original jammed in the DP, open the DP original cover.

Paper misfeed detection can be reset by opening and closing the respective covers to turn safety switch off and on.




Figure 1-5-1

- (1) Misfeed in the drawer 1
- (2) Misfeed in the drawer 2
- (3) Misfeed in the drawer 3*
- (4) Misfeed in the drawer 4*
- (5) Misfeed in the bypass tray
- (6) Misfeed in the paper conveying section
- (7) Misfeed in the exit section
(Misfeed in the job separator*or finisher*)
- (8) Misfeed in the DP*

*: Optional.

(2) Paper misfeed detection conditions




Figure 1-5-2

Section	Jam code	Description	Conditions
System	00	No paper feed	When the power switch is turned on, the machine detects activation of the registration switch (RSW), the exit switch (ESW) or the feedshift switch (FSSW).
	04	Cover open JAM	A cover open state is detected during copying.
	05	Secondary paper feed timeout	When the machine waits for secondary paper feed, 30 s or more have elapsed.
Paper feed section	10	No paper feed from the bypass tray	The registration switch (RSW) does not turn on within 1323 ms of the bypass paper feed solenoid (BYPPFSOL) turning on; the solenoid is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 1323 ms.
	11	No paper feed from the drawer 1 (drawer)	The registration switch (RSW) does not turn on within 1126 ms of the paper feed clutch (PFCL) turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 1126 ms.
	12	No paper feed from the drawer 2 (first paper feeder)	The registration switch (RSW) does not turn on within 2189 ms of the drawer paper feed clutch 1 (DPFCL1) turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 2189 ms.
	13	No paper feed from the drawer 3* (second paper feeder)	The drawer feed switch 1 (DFSW1) does not turn on within 1961 ms of the drawer paper feed clutch 2 (DPFCL2)* turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 1961 ms.
	14	No paper feed from the drawer 4* (third paper feeder)	The drawer feed switch 2 (DFSW2)* does not turn on within 1961 ms of the drawer paper feed clutch 3 (DPFCL3)* turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 1961 ms.
	15	Misfeed in vertical paper conveying 1	The registration switch (RSW) does not turn on within 1843 ms of drawer feed switch 1 (DFSW1) turning on. The drawer feed switch 1 (DFSW1) does not turn off within 1614 ms of drawer feed switch 2 (DFSW2)* turning on. The drawer feed switch 1 (DFSW1) does not turn off within 1614 ms of drawer feed switch 2 (DFSW2)* turning off.
	16	Misfeed in vertical paper conveying 2	The drawer feed switch 1 (DFSW1) does not turn on within 1614 ms of drawer feed switch 2 (DFSW2)* turning on.
Paper conveying section	20	Multiple sheets in the bypass tray	The registration switch (RSW) does not turn off within 4976 ms of registration switch (RSW) turning on. The registration switch (RSW) does not turn off within 1323 ms of bypass paper feed solenoid (BYPPFSOL) turning on.
	21	Multiple sheets in the drawer 1 (drawer)	The registration switch (RSW) does not turn off within 4976 ms of registration switch (RSW) turning on. The registration switch (RSW) does not turn off within 1126 ms of paper feed clutch (PFCL) turning on.

*: Optional.

Section	Jam code	Description	Conditions
Paper conveying section	22	Multiple sheets in the drawer 2 (first paper feeder)	The registration switch (RSW) does not turn off within 4976 ms of registration switch (RSW) turning on. The registration switch (RSW) does not turn off within 2189 ms of drawer paper feed clutch 1 (DPFCL1) turning on.
	23	Multiple sheets in the drawer 3* (second paper feeder)	The drawer feed switch 1 (DFSW1) does not turn off within 4976 ms of drawer feed switch 1 (DFSW1) turning on. The drawer feed switch 1 (DFSW1) does not turn off within 1961 ms of drawer paper feed clutch 2 (DPFCL2)* turning on.
	24	Multiple sheets in the drawer 4* (third paper feeder)	The drawer feed switch 2 (DFSW2)* does not turn off within 4976 ms of drawer feed switch 2 (DFSW2)* turning on. The drawer feed switch 2 (DFSW2)* does not turn off within 1961 ms of drawer paper feed clutch 3 (DPFCL3)* turning on.
Transfer section	30	Misfeed in registration/ transfer section	The registration switch (RSW) does not turn off within 1843 ms of drawer feed switch 1 (DFSW1) turning on. The registration switch (RSW) does not turn off within 1843 ms of drawer feed switch 1 (DFSW1) turning off. The registration switch (RSW) does not turn off within 1386 ms of duplex paper conveying switch (DUPPCSW1)* turning on.
Fixing section	40	Misfeed in the fixing section (paper feed from bypass tray)	The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
	41	Misfeed in the fixing section (paper feed from drawer)	The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
	42	Misfeed in the fixing section (paper feed from first paper feeder)	The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
	43	Misfeed in the fixing section (paper feed from second paper feeder*)	The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
	44	Misfeed in the fixing section (paper feed from third paper feeder*)	The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
	45	Misfeed in the fixing section (paper feed from duplex section*)	The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
Exit section	50	Misfeed in the exit section	The exit switch (ESW) does not turn off within 2378 ms of the registration switch (RSW) turning off. The exit switch (ESW) does not turn on within 2378 ms of the registration motor (RM) turning on.
	51	Misfeed in the job separator*	The job separator eject switch (JBESW)* does not turn on within 1614 ms of feedshift switch (FSSW) turning on. The job separator eject switch (JBESW)* does not turn off within 1614 ms of feedshift switch (FSSW) turning off. The job separator eject switch (JBESW)* does not turn off within 1614 ms of feedshift switch (FSSW) turning off.

*: Optional.

Section	Jam code	Description	Conditions
Feedshift section	52	Misfeed in the feedshift section (paper feed from bypass tray)	The feedshift switch (FSSW) does not turn on within 4976 ms of feedshift switch (FSSW) turning on. The feedshift switch (FSSW) does not turn off within 1205 ms of paper switchback. The feedshift switch (FSSW) does not turn on within 1205 ms of paper switchback.
	53	Misfeed in the feedshift section (paper feed from drawer)	The feedshift switch (FSSW) does not turn on within 4976 ms of feedshift switch (FSSW) turning on. The feedshift switch (FSSW) does not turn off within 1205 ms of paper switchback. The feedshift switch (FSSW) does not turn on within 1205 ms of paper switchback.
	54	Misfeed in the feedshift section (paper feed from first paper feeder)	The feedshift switch (FSSW) does not turn on within 4976 ms of feedshift switch (FSSW) turning on. The feedshift switch (FSSW) does not turn off within 1205 ms of paper switchback. The feedshift switch (FSSW) does not turn on within 1205 ms of paper switchback.
	55	Misfeed in the feedshift section (paper feed from second paper feeder*)	The feedshift switch (FSSW) does not turn on within 4976 ms of feedshift switch (FSSW) turning on. The feedshift switch (FSSW) does not turn off within 1205 ms of paper switchback. The feedshift switch (FSSW) does not turn on within 1205 ms of paper switchback.
	56	Misfeed in the feedshift section (paper feed from third paper feeder*)	The feedshift switch (FSSW) does not turn on within 4976 ms of feedshift switch (FSSW) turning on. The feedshift switch (FSSW) does not turn off within 1205 ms of paper switchback. The feedshift switch (FSSW) does not turn on within 1205 ms of paper switchback.
	57	Misfeed in the feedshift section (paper feed from duplex section*)	The feedshift switch (FSSW) does not turn on within 4976 ms of feedshift switch (FSSW) turning on. The feedshift switch (FSSW) does not turn off within 1205 ms of paper switchback. The feedshift switch (FSSW) does not turn on within 1205 ms of paper switchback.
Duplex section	60	Misfeed in duplex paper conveying section*	The duplex paper conveying switch (DUPPCSW)* does not turn off within 2583 ms of the feedshift switch (FSSW) turning on. The duplex paper conveying switch (DUPPCSW)* does not turn on within 2583 ms of the feedshift switch (FSSW) turning on. The duplex paper conveying switch (DUPPCSW)* does not turn off within 2583 ms of the feedshift switch (FSSW) turning off.
	61	Misfeed in duplex exit section*	The registration switch (RSW) does not turn on within 1386 ms of the duplex paper conveying switch (DUPPCSW)* turning on. The registration switch (RSW) does not turn off within 1386 ms of the duplex paper conveying switch (DUPPCSW)* turning off.

*: Optional.

Section	Jam code	Description	Conditions
DP	70	No original feed*	During the primary feed of the second original in the single-sided or double-sided original mode, even if retry operation is performed five times, primary original feed is not performed.
	71	An original jam in the original conveying section 1*	During the secondary original feed in the single-sided or double-sided original mode, the DP timing switch (DPTSW)* does not turn off within 6500 ms of the original conveying motor (OCM)* turning on.
	72	An original size error jam*	During the secondary original feed in the single-sided or double-sided original mode, the DP timing switch (DPTSW)* does turn off within 750 ms of the original conveying motor (OCM)* turning on.
	73	An original jam in the original conveying section 2*	During scanning of the second side or reversing of the original for ejection in the double-sided original mode, the DP timing switch (DPTSW)* does not turn off within 6500 ms of the original conveying motor (OCM)* turning on.
	74	An original jam in the original conveying section 3*	During scanning of the second side or reversing of the original for ejection in the double-sided original mode, the DP timing switch (DPTSW)* does not turn on within 750 ms of the original conveying motor (OCM)* turning on.
	75	An original jam in the original switchback section*	During the switchback operation of an original in the double-sided original mode, the original switchback switch (OSBSW)* does not turn on within 1300 ms of the original conveying motor (OCM)* turning on.
Finisher	80	Jam between the finisher and MFP*	The paper conveying switch (PCSW)* does not turn on within 1220 ms of the signal requesting paper ejection is output from the MFP.
	81	Intake jam*	During paper intake from the MFP, the paper conveying switch (PCSW)* does not turn off within 1543 to 2740 ms (depending on paper size) of paper conveying switch (PCSW)* turning on.
	83	Jam during paper conveying for batch ejection 1*	When ejection a stack of paper, the paper conveying switch (PCSW)* does not turn on within 1252 ms of the paper conveying motor (PCM)* turning on.
	84	Jam during paper conveying for batch ejection 2*	When ejection a stack of paper, the paper conveying switch (PCSW)* does not turn off within 1780 to 2512 ms (varies depending on the paper size) of the paper conveying motor (PCM)* turning on.

*: Optional.

(3) Paper misfeeds

Problem	Causes/check procedures	Corrective measures
(1) A paper jam in the paper feed, paper conveying or exit section is indicated as soon as the power switch is turned on. Jam code 00	A piece of paper torn from copy paper is caught around registration switch, exit sensor or feedshift switch.	Check visually and remove it, if any.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding switch is not light.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
(2) A paper jam in the paper feed section is indicated during copying (no paper feed from the bypass tray). Jam code 10	Paper on the bypass tray is extremely curled.	Change the paper.
	Check if the bypass paper feed pulley is deformed.	Check visually and replace any deformed pulley.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the bypass paper feed solenoid malfunctions.	Run maintenance item U032 and select the bypass paper feed solenoid to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the bypass paper feed solenoid.	Check (see page 1-5-36).
(3) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 1). Jam code 11	Paper in the drawer is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley is deformed.	Check visually and replace any deformed pulley.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the paper feed clutch malfunctions.	Run maintenance item U032 and select the paper feed clutch to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the paper feed clutch.	Check (see page 1-5-35).

Problem	Causes/check procedures	Corrective measures
(4) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 2). Jam code 12	Paper in the first paper feeder is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley in the first paper feeder is deformed.	Check visually and replace any deformed pulley.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1.	Check.
(5) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 3). Jam code 13	Paper in the second paper feeder* is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley in the second paper feeder* is deformed.	Check visually and replace any deformed pulley.
	Broken drawer feed switch 1 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 2* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*.	Check.
(6) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 4). Jam code 14	Paper in the third paper feeder* is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley in the third paper feeder* is deformed.	Check visually and replace any deformed pulley.
	Broken drawer feed switch 2* actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(6) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 4). Jam code 14	Check if the drawer paper feed clutch 3* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 3 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 3*.	Check.
(7) A paper jam in the paper feed section is indicated during copying (misfeed in vertical paper conveying 1). Jam code 15	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Broken drawer feed switch 1 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Broken drawer feed switch 2* actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the paper feed clutch malfunctions.	Run maintenance item U032 and select the paper feed clutch to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the paper feed clutch.	Check (see page 1-5-35).
	Check if the drawer paper feed clutch 1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1.	Check.
	Check if the drawer paper feed clutch 2* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*.	Check.
	Check if the drawer paper feed clutch 3* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 3 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 3*.	Check.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(8) A paper jam in the paper feed section is indicated during copying (misfeed in vertical paper conveying 2). Jam code 16	Broken drawer feed switch 1 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Broken drawer feed switch 2* actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1.	Check.
	Check if the drawer paper feed clutch 2* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*.	Check.
(9) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the bypass tray). Jam code 20	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the bypass paper feed solenoid malfunctions.	Run maintenance item U032 and select the bypass paper feed solenoid to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the bypass paper feed solenoid.	Check (see page 1-5-36).
	Check if the right and left registration rollers contact each other.	Check visually and remedy if necessary.
(10) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 1). Jam code 21	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the paper feed clutch malfunctions.	Run maintenance item U032 and select the paper feed clutch to be turned on and off. Check the status and remedy if necessary.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(10) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 1). Jam code 21	Electrical problem with the paper feed clutch.	Check (see page 1-5-35).
	Check if the right and left registration rollers contact each other.	Check visually and remedy if necessary.
(11) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 2). Jam code 22	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1.	Check.
	Check if the right and left registration rollers contact each other.	Check visually and remedy if necessary.
(12) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 3). Jam code 23	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken drawer feed switch 1 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 2* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*.	Check.
(13) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 4). Jam code 24	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken drawer feed switch 2* actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 3* malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 3 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 3*.	Check.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(14) A paper jam in the transfer section is indicated during copying (misfeed in registration/transfer section). Jam code 30	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Broken drawer feed switch 1 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Broken duplex paper conveying switch* actuator.	Check visually and replace the duplex paper conveying switch if its actuator is broken.
	Defective duplex paper conveying switch*.	Run maintenance item U031 and turn duplex paper conveying switch on and off manually. Replace duplex paper conveying switch if indication of the corresponding switch is not light.
(15) A paper jam in the fixing section is indicated during copying (misfeed in the fixing section). Jam code 40, 41, 42, 43, 44, 45	Check if the fixing unit front guide is deformed.	Repair or replace if necessary.
	Check if the press roller is extremely dirty or deformed.	Clean or replace if necessary.
	Check if the heat roller separation claws are dirty or deformed.	Clean or replace if necessary.
	Check if the heat roller and its separation claws contact each other.	Remedy if the separation claw springs are out of place.
	Broken exit switch actuator.	Check visually and replace the exit switch if its actuator is broken.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding switch is not light.
	Check if the registration motor malfunctions.	Run maintenance item U030 and select the registration motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration motor.	Check (see page 1-5-34).
(16) A paper jam in the exit section is indicated during copying (misfeed in the exit section). Jam code 50	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Broken exit switch actuator.	Check visually and replace the exit switch if its actuator is broken.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding switch is not light.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(16) A paper jam in the exit section is indicated during copying (misfeed in the exit section). Jam code 50	Check if the registration motor malfunctions.	Run maintenance item U030 and select the registration motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration motor.	Check (see page 1-5-34).
(17) A paper jam in the exit section is indicated during copying (misfeed in the job separator). Jam code 51	Broken feedshift switch actuator.	Check visually and replace the feedshift switch if its actuator is broken.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
	Broken Job separator eject switch* actuator.	Check visually and replace the Job separator eject switch if its actuator is broken.
	Defective Job separator eject switch*.	Run maintenance item U031 and turn Job separator eject switch on and off manually. Replace Job separator eject switch if indication of the corresponding switch is not light.
(18) A paper jam in the feedshift section is indicated during copying (misfeed in the feedshift section). Jam code 52, 53, 54, 55, 56, 57	Broken feedshift switch actuator.	Check visually and replace the feedshift switch if its actuator is broken.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
	Check if the exit motor malfunctions.	Run maintenance item U030 and select the exit motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the exit motor.	Check (see page 1-5-34).
(19) A paper jam in the duplex section is indicated during copying (misfeed in duplex paper conveying section). Jam code 60	Broken feedshift switch actuator.	Check visually and replace the feedshift switch if its actuator is broken.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
	Broken duplex paper conveying switch* actuator.	Check visually and replace the duplex paper conveying switch if its actuator is broken.
	Defective duplex paper conveying switch*.	Run maintenance item U031 and turn duplex paper conveying switch on and off manually. Replace duplex paper conveying switch if indication of the corresponding switch is not light.
	Check if the exit motor malfunctions.	Run maintenance item U030 and select the exit motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the exit motor.	Check (see page 1-5-34).
	Check if the duplex feed clutch* malfunctions.	Check visually and remedy if necessary.
	Electrical problem with the duplex feed clutch*.	Check.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(20) A paper jam in the duplex section is indicated during copying (misfeed in duplex paper conveying section). Jam code 61	Broken duplex paper conveying switch* actuator.	Check visually and replace the duplex paper conveying switch if its actuator is broken.
	Defective duplex paper conveying switch*.	Run maintenance item U031 and turn duplex paper conveying switch on and off manually. Replace duplex paper conveying switch if indication of the corresponding switch is not light.
	Broken registration switch actuator.	Check visually and replace the registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the duplex feed clutch* malfunctions.	Check visually and remedy if necessary.
	Electrical problem with the duplex feed clutch*.	Check.
(21) An original jams when the power switch is turned on.	A piece of paper torn from an original is caught around the DP timing switch* or original switchback switch*.	Check visually and remove it, if any.
	Defective DP timing switch*.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Defective original switchback switch*.	Run maintenance item U244 and turn original switchback switch on and off manually. Replace original switchback switch if indication of the corresponding switch is not light.
(22) An original jams in the original feed section is indicated during copying (no original feed). Jam code 70	Defective original set switch*.	Run maintenance item U244 and turn original set switch on and off manually. Replace original set switch if indication of the corresponding switch is not light.
	Check if the original feed motor* malfunctions.	Run maintenance item U243 and select the original feed motor to be turned on and off. Check the status and remedy if necessary.
	Check if the DP paper feed pulley or DP separation pad is deformed.	Check visually and replace the deformed pulley.
(23) An original jams in the original conveying section is indicated during copying (An original jam in the original conveying section 1). Jam code 71	Broken DP timing switch* actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch*.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(24) An original jams in the original conveying section is indicated during copying (An original size error jam). Jam code 72	Broken DP timing switch* actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch*.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
(25) An original jams in the original conveying section is indicated during copying (An original jam in the original conveying section 2). Jam code 73	Broken DP timing switch* actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch*.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
	Check if the switchback feedshift solenoid* malfunctions.	Run maintenance item U243 and select the switchback feedshift solenoid to be turned on and off. Check the status and remedy if necessary.
(26) An original jams in the original conveying section is indicated during copying (An original jam in the original conveying section 3). Jam code 74	Broken DP timing switch* actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch*.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
	Check if the switchback feedshift solenoid malfunctions*.	Run maintenance item U243 and select the switchback feedshift solenoid to be turned on and off. Check the status and remedy if necessary.
(27) An original jams in the original switchback section is indicated during copying (An original jam in the original switchback section). Jam code 75	Defective original switchback switch*.	Run maintenance item U244 and turn original switchback switch on and off manually. Replace original switchback switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
	Check if the switchback feedshift solenoid* malfunctions.	Run maintenance item U243 and select the switchback feedshift solenoid to be turned on and off. Check the status and remedy if necessary.
(28) Original jams frequently.	An original outside the specifications is used.	Use only originals conforming to the specifications.
	The DP forwarding pulley or DP paper feed pulley is dirty with paper powder.	Clean with isopropyl alcohol.
	The DP paper feed pulley and DP separation pad do not contact correctly.	Check and remedy.

*: Optional.

Problem	Causes/check procedures	Corrective measures
(29) A paper jam in the finisher* is indicated during copying (Intake jam). Jam code 81	Defective paper conveying switch*.	With 5 V DC present at CN4-9 on the finisher main PCB, check if CN4-10 on the finisher main PCB remains high or low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the feedshift roller or feedshift pulley is deformed.	Check visually and replace the pulley or roller if deformed.
(30) A paper jam in the finisher* is indicated during copying (jam during paper conveying for batch ejection 1). Jam code 83	Defective paper conveying switch*.	With 5 V DC present at CN4-9 on the finisher main PCB, check if CN4-10 on the finisher main PCB remains high or low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the feedshift roller or press roller is deformed.	Check visually and replace the pulley or roller if deformed.
(31) A paper jam in the finisher* is indicated during copying (jam during paper conveying for batch ejection 2). Jam code 84	Defective paper conveying switch*.	With 5 V DC present at CN4-9 on the finisher main PCB, check if CN4-10 on the finisher main PCB remains high or low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the eject roller or eject pulley is deformed.	Check visually and replace the pulley or roller if deformed.

*: Optional. .

1-5-2 Self-diagnosis

(1) Self-diagnostic function

This unit is equipped with a self-diagnostic function. When a problem is detected, copying is disabled. "C" and a number between 0030 and 8210 alternates, indicating the nature of the problem.

A message is also displayed requesting the user to call for service.

After removing the problem, the self-diagnostic function can be reset by power switch turns off and on.

List of system errors

When an unexpected error is detected for some reason, a system error will be indicated. After a system error is indicated, the error can be cleared by turning the main switch off and then on. If the error is detected continuously, however, perform the operation shown in Table 1-5-1. If a system error occurs frequently, a fault may have occurred. Check the details of the C call to take proper measures.

System error	Contents	Operation
0210	Communication problem between the main PCB and engine PCB	System error→Normal C call processing
0250	Scanner network board* communication problem	System error→Normal C call processing
0410	DP* communication problem	System error→Normal C call processing
0420	First paper feeder communication problem	System error→Normal C call processing
0440	Finisher* communication problem	System error
0500	Second paper feeder* communication problem	System error→Normal C call processing
0510	Third paper feeder* communication problem	System error→Normal C call processing
0630	DMA problem	System error→Normal C call processing
3100	Scanner carriage problem	System error→Normal C call processing

*: Optional.

Table 1-5-1 List of system errors

Partial operation control

If any of the following calls for service is detected, partial operation control will be activated. After taking measures against the cause of trouble, run maintenance item U906 to reset partial operation control.

Display	Contents
C8170	Finisher* front side registration motor problem
C8180	Finisher* rear side registration motor problem
C8190	Finisher* trailing edge registration motor problem
C8210	Finisher* front stapler problem

*: Optional.

(2) Self diagnostic codes

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0030	Fax control PCB* system problem Processing with the fax software was disabled due to a hardware or software problem.	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0070	Fax control PCB* incompatibility detection problem Fax software is not compatible with main software.	Fax software or main software is something of the other machine.	Check the version of the Fax software and the main software, upgrade the version to the compatible software.
C0100	Backup memory read/write problem (main PCB flash) Read and write data does not match.	Defective main PCB.	Replace the main PCB and check for correct operation.
C0110	Backup memory data problem (main PCB flash) Data in the specified area of the backup memory does not match the specified values.	Problem with the backup memory data.	Turn safety switch off and back on and run maintenance item U020 to set the contents of the backup memory data again.
		Defective backup RAM.	If the C0110 is displayed after re-setting the backup memory contents, replace the main PCB.
C0120	Drum EEPROM read/write problem Read and write data does not match.	Defective drum EEPROM or main PCB.	Replace the main PCB and check for correct operation.
C0130	Backup memory read/write problem (main PCB EEPROM) Read and write data does not match.	Defective EEPROM or main PCB.	Replace the main PCB and check for correct operation.
C0140	Backup memory data problem (main PCB EEPROM) Data in the specified area of the backup memory does not match the specified values.	Problem with the backup memory data.	Turn safety switch off and back on and run maintenance item U020 to set the contents of the backup memory data again.
		Defective EEPROM.	If the C0140 is displayed after re-setting the backup memory contents, replace the EEPROM or main PCB.
C0150	Backup memory read/write problem (engine PCB) Read and write data does not match.	Defective engine PCB.	Replace the engine PCB and check for correct operation.
C0160	Backup memory data problem (engine PCB) Data in the specified area of the backup memory does not match the specified values.	Problem with the backup memory data.	Turn safety switch off and back on and run maintenance item U020 to set the contents of the backup memory data again.
		Defective backup RAM.	If the C0160 is displayed after re-setting the backup memory contents, replace the engine PCB.
C0170	Accounting count problem When the power is turned on, the total count and the scan count are abnormal both on the main PCB and the engine PCB.	Defective main PCB or engine PCB.	Replace the main PCB or engine PCB and check for correct operation.

*: Optional.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0180	Machine number mismatch When the power is turned on, the machine number does not match between the main PCB and the engine PCB.	Correct EEPROM is not installed.	Install the correct EEPROM. If it does not solve the problem, contact the Service Administrative Division.
		Data damage of EEPROM.	Contact the Service Administrative Division.
C0210	Communication problem between the main PCB and engine PCB When the power is turned on, the machine does not detect the low level of SBSY and the high level of SDIR for 10 s.	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or engine PCB.	Replace the main PCB or engine PCB and check for correct operation.
C0240	Printer board PCB communication problem The printer board PCB does not respond 120 s after the power is turned on.	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or printer board PCB.	Replace the main PCB or printer board PCB and check for correct operation.
C0250	Scanner network board* communication problem The scanner network board does not respond.	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or scanner network board.	Replace the main PCB or scanner network board and check for correct operation.
C0280	Fax control PCB* communication problem Communication between the fax control PCB and the main PCB of the machine cannot be performed normally.	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or fax control PCB.	Replace the main PCB or fax control PCB and check for correct operation.
C0410	DP* communication problem Communication fails five times successively.	DP installed incorrectly.	Check the installation state of the DP and adjust it if it is not properly installed.
		Defective engine PCB or DP driver PCB.	Replace the engine PCB or DP driver PCB and check for correct operation.
C0420	First paper feeder communication problem Communication fails five times successively.	Paper feeder installed incorrectly.	Check the installation state of the paper feeder and adjust it if it is not properly installed.
		Defective engine PCB or drawer main PCB.	Replace the engine PCB or drawer main PCB and check for correct operation.
C0440	Finisher* communication problem Communication fails five times successively.	Finisher installed incorrectly.	Check the installation state of the finisher and adjust it if it is not properly installed.
		Defective engine PCB or finisher main PCB.	Replace the engine PCB or finisher main PCB and check for correct operation.

*: Optional.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0500	Second paper feeder* communication problem Communication fails five times successively.	Paper feeder installed incorrectly.	Check the installation state of the paper feeder and adjust it if it is not properly installed.
		Defective engine PCB or drawer main PCB.	Replace the engine PCB or drawer main PCB and check for correct operation.
C0510	Third paper feeder* communication problem Communication fails five times successively.	Paper feeder installed incorrectly.	Check the installation state of the paper feeder and adjust it if it is not properly installed.
		Defective engine PCB or drawer main PCB.	Replace the engine PCB or drawer main PCB and check for correct operation.
C0610	Bitmap (DIMM) problem There is a problem with the data or address bus of the bitmap DRAM.	Defective main PCB.	Replace the main PCB and check for correct operation.
		DIMM installed incorrectly.	Check if the DIMM is inserted into the socket on the main PCB correctly.
		Defective DIMM.	Replace the DIMM and check for correct operation.
C0630	DMA problem DMA transmission of compressed, decompressed, rotated, relocated or blanked-out image data does not complete within the specified period of time.	Defective main PCB.	Replace the main PCB and check for correct operation.
C0800	Image processing problem JAM05 is detected twice.	Defective main PCB.	Replace the main PCB and check for correct operation.
C0820	Fax control PCB* CG ROM checksum error A checksum error occurred with the CG ROM data of the fax control PCB.	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0830	Flash ROM program area checksum error A checksum error occurred with the program of the fax control PCB.	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0860	Fax control PCB* software switch checksum error A checksum error occurred with the software switch value of the fax control PCB.	Defective fax software.	Install the fax software to Ver. 2.xx or later.
		Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0870	Fax control PCB* to main PCB high-capacity data transfer problem High-capacity data transfer between the fax control PCB and the main PCB of the machine was not normally performed even if the data transfer was retried the specified times.	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or fax control PCB.	Replace the main PCB or fax control PCB and check for correct operation.

*: Optional.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0880	Fax control PCB* program archive problem When power is turned on, the compressed program in the Flash ROM on the fax control PCB was not successfully decompressed.	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0890	Fax control PCB* CG font archive problem When power is turned on, the compressed CG font in the Flash ROM on the fax control PCB was not successfully decompressed.	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0900	Fax software incompatibility detection problem Version of fax software is not compatible with that of main software.	Fax software version or main software is earlier.	Check the version of the fax software and the main software, upgrade the version to the compatible software.
C0920	Fax file system error The backup data is not retained for file system abnormality of flash memory of the fax control PCB.	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0960	Developer EEPROM read/write problem Read and write data does not match.	Defective developer EEPROM or main PCB.	Replace the main PCB and check for correct operation.
C2000	Drive motor problem LOCK ALM signal remains high for 1 s, 1 s after the drive motor has turned on.	Poor contact in the drive motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective drive motor rotation control circuit.	Replace the drive motor.
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
C3100	Scanner carriage problem The home position is not correct when the power is turned on or copying the document placed on the contact glass.	Poor contact of the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective scanner home position switch.	Replace the scanner home position switch.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
		Defective scanner motor.	Replace the scanner motor.

*: Optional.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C3200	Exposure lamp problem Non-lighting of the exposure lamp is detected at the beginning of copying.	Poor contact of the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective exposure lamp or inverter PCB.	Replace the exposure lamp or inverter PCB.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
		Incorrect shading position.	Adjust the position of the contact glass (shading plate). If the problem still occurs, replace the scanner home position switch.
C3300	Optical system (AGC) problem After AGC, correct input is not obtained at CCD.	Insufficient exposure lamp luminosity.	Replace the exposure lamp or inverter PCB.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
		Incorrect shading position.	Adjust the position of the contact glass (shading plate). If the problem still occurs, replace the scanner home position switch.
		Defective CCD PCB.	Replace the ISU.
C4000	Polygon motor synchronization problem The polygon motor does not reach the stable speed within 20 s of the START signal turning on.	Poor contact in the polygon motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective polygon motor.	Replace the LSU.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
C4010	Polygon motor steady-state problem The polygon motor rotation is not stable for 5 s after the polygon motor rotation has been stabilized.	Poor contact in the polygon motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective polygon motor.	Replace the LSU.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
C4200	BD steady-state problem The MIP detects a BD error for 600 ms after the polygon motor rotation has been stabilized.	Defective laser diode.	Replace the LSU.
		Defective polygon motor.	Replace the LSU.
		Defective main PCB.	Replace the main PCB and check for correct operation.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C6000	Broken fixing heater wire The temperature does not become 100°C/212°F even if 30 s pass before secondary stabilization. When there is no 1°C/33.8°F rise in 5 s before secondary stabilization.	Poor contact in the thermistor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Fixing thermistor installed incorrectly.	Check and reinstall if necessary.
		Fixing thermostat triggered.	Check for continuity. If none, replace the fixing thermostat.
		Fixing heater M or S installed incorrectly.	Check and reinstall if necessary.
		Broken fixing heater M or S wire.	Check for continuity. If none, replace the fixing heater M or S.
C6020	Abnormally high fixing unit thermistor temperature The fixing temperature exceeds 240°C/464°F for 40 ms.	Shorted thermistor.	Measure the resistance. If it is 0 Ω, replace the thermistor.
		Broken heater control circuit on the power supply PCB.	Replace the power supply PCB and check for correct operation.
C6050	Abnormally low fixing unit thermistor temperature The fixing temperature remains below 90°C/194°F for 1 s.	Poor contact in the thermistor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Broken fixing thermistor wire.	Measure the resistance. If it is ∞ Ω, replace the fixing thermistor.
		Fixing thermistor installed incorrectly.	Check and reinstall if necessary.
		Fixing thermostat triggered.	Check for continuity. If none, replace the fixing thermostat.
		Fixing heater M or S installed incorrectly.	Check and reinstall if necessary.
		Broken fixing heater M or S wire.	Check for continuity. If none, replace the fixing heater M or S.
C6400	Zero-crossing signal problem The engine PCB does not detect the zero-crossing signal for the time specified below. At power-on: 3 s Others: 5 s	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective power supply PCB.	Check if the zero-crossing signal is output from YC2-5 on the power supply PCB. If not, replace the power supply PCB.
		Defective engine PCB.	Replace the engine PCB if C6400 is detected while YC2-5 on the power supply PCB outputs the zero-crossing signal.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C6420	Fixing fuse cut problem When you try to cut the fixing fuse, the fixing is not cut even after 3 s elapse.	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Fixing unit connector inserted incorrectly.	Reinsert the fixing unit connector if necessary.
C7400	Developing unit connector insertion problem Absence of the developing unit is detected.	Developing unit connector inserted incorrectly.	Reinsert the developing unit connector if necessary.
		Defective developing unit connector.	Replace the developing unit.
C7410	Drum unit connector insertion problem Absence of the drum unit is detected.	Drum unit connector inserted incorrectly.	Reinsert the drum unit connector if necessary.
		Defective drum unit connector.	Replace the drum unit.
C7800	Broken external temperature thermistor The input voltage is 0.5 V or less.	Poor contact in the humidity sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective humidity sensor.	Replace the drawer PCB and check for correct operation.
C7810	Short-circuited external temperature thermistor The input voltage is 4.5 V or more.	Poor contact in the humidity sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective humidity sensor.	Replace the drawer PCB and check for correct operation.
C8170	Finisher* front side registration motor problem If the front side registration home position sensor is on in initialization, the sensor does not turn off within 570 ms of starting initialization. If the front side registration home position sensor is off in initialization, the sensor does not turn on within 3180 ms of starting initialization.	The front side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The front side registration motor malfunctions.	Replace the front side registration motor and check for correct operation.
		The front side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The front side registration home position sensor malfunctions.	Replace the front side registration home position sensor and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.


*: Optional.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8180	Finisher* rear side registration motor problem If the rear side registration home position sensor is on in initialization, the sensor does not turn off within 570 ms of starting initialization. If the rear side registration home position sensor is off in initialization, the sensor does not turn on within 2880 ms of starting initialization.	The rear side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The rear side registration motor malfunctions.	Replace the rear side registration motor and check for correct operation.
		The rear side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The rear side registration home position sensor malfunctions.	Replace the rear side registration home position sensor and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.
C8190	Finisher* trailing edge registration motor problem If the trailing edge registration home position sensor is on in initialization, the sensor does not turn off within 570 ms of starting initialization. If the trailing edge registration home position sensor is off in initialization, the sensor does not turn on within 4550 ms of starting initialization.	The trailing edge registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The trailing edge registration motor malfunctions.	Replace the trailing edge registration motor and check for correct operation.
		The trailing edge registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The trailing edge registration home position sensor malfunctions.	Replace the trailing edge registration home position sensor and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.
C8210	Finisher* front stapler problem The front stapler home position sensor does not change state from nondetection to detection within 200 ms of the start of front stapler motor counterclockwise (forward) rotation. During initialization, the front stapler home position sensor does not change state from non-detection to detection within 600 ms of the start of front stapler motor clockwise (reverse) rotation.	The front stapler connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The front stapler malfunctions. a) The front stapler is blocked with a staple. b) The front stapler is broken.	a) Remove the front stapler cartridge, and check the cartridge and the stapling section of the stapler. b) Replace the front stapler and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.

*: Optional.

1-5-3 Image formation problems

- (1) No image appears (entirely white).



See page 1-5-27.

- (2) No image appears (entirely black).



See page 1-5-27.

- (3) Image is too light.



See page 1-5-28.

- (4) Background is visible.




See page 1-5-28.

- (5) A white line appears longitudinally.



See page 1-5-28.

- (6) A black line appears longitudinally.



See page 1-5-29.
(11) The leading edge of the image is consistently misaligned with the original.

- (7) A black line appears laterally.



See page 1-5-29.
(12) The leading edge of the image is sporadically misaligned with the original.

- (8) One side of the copy image is darker than the other.




See page 1-5-29.
(13) Paper creases.




See page 1-5-30.
(14) Offset occurs.

- (10) Image is blurred.




See page 1-5-30.
(15) Image is partly missing.




See page 1-5-30.
(16) Fixing is poor.



See page 1-5-31.
(17) Image is out of focus.




See page 1-5-31.
(18) Image center does not align with the original center.



See page 1-5-31.



See page 1-5-32.



See page 1-5-32.



See page 1-5-32.




See page 1-5-33.

(1) No image appears (entirely white).

Causes

1. No transfer charging.
2. No LSU laser is output.
3. No developing bias is output.



Causes	Check procedures/corrective measures
1. No transfer charging.	
A. The connector terminals of the high-voltage PCB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
B. Defective engine PCB.	Replace the engine PCB and check for correct operation.
C. Defective high-voltage PCB.	Replace the high voltage PCB and check for correct operation.
2. No LSU laser is output.	
A. Defective laser scanner unit.	Replace the laser scanner unit (see page 1-6-29).
B. Defective main PCB.	Replace the main PCB and check for correct operation.
3. No developing bias is output.	
A. The connector terminals of the high-voltage PCB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
B. Defective engine PCB.	Replace the engine PCB and check for correct operation.
C. Defective high-voltage PCB.	Replace the high voltage PCB and check for correct operation.

(2) No image appears (entirely black).

Causes

1. No main charging.
2. Exposure lamp fails to light.



Causes	Check procedures/corrective measures
1. No main charging.	
A. Broken main charger wire.	Replace the main charger unit (see page 1-6-40).
B. Leaking main charger housing.	Clean the main charger wire, grid and shield.
C. The connector terminals of the high-voltage PCB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
D. Defective engine PCB.	Check if YC9-5 on the engine PCB goes low when maintenance item U100 is run. If not, replace the engine PCB.
E. Defective high-voltage PCB.	Check if main charging takes place when YC1-12 on the high-voltage PCB goes low while maintenance item U100 is run. If not, replace the high-voltage PCB.
2. Exposure lamp fails to light.	
A. The connector terminals of the exposure lamp make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
B. Defective inverter PCB.	Check if the exposure lamp lights when YC1-1 and 1-6 on the inverter PCB go low while maintenance item U061 is run. If not, replace the inverter PCB.
C. Defective engine PCB.	Check if YC17-1 and YC17-6 on the engine PCB goes low when maintenance item U061 is run. If not, replace the engine PCB.

(3) Image is too light.




Causes

1. Insufficient toner.
2. The transfer voltage is not output properly.
3. Dirty main charger wire.
4. Dirty main charger grid.

Causes	Check procedures/corrective measures
1. Insufficient toner.	If the display shows the message requesting toner replenishment, replace the container.
2. The transfer voltage is not output properly.	Clean or check the transfer roller (see page 1-6-42).
3. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).
4. Dirty main charger grid.	Clean the main charger grid or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).

(4) Background is visible.



Causes

1. The developing bias voltage is not properly.
2. Dirty main charger wire.

Causes	Check procedures/corrective measures
1. The developing bias voltage is not properly.	Replace the high voltage PCB and check for correct operation.
2. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).

(5) A white line appears longitudinally.




Causes

1. Dirty main charger wire.
2. Foreign matter in the developing unit.
3. Dirty shading plate.

Causes	Check procedures/corrective measures
1. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).
2. Foreign matter in the developing unit.	Check if the magnetic brush is formed uniformly. Replace the developing unit if any foreign matter (see page 1-6-41).
3. Dirty shading plate.	Clean the shading plate.

(6) A black line appears longitudinally.



Causes

1. Dirty contact glass.
2. Dirty or flawed drum.
3. Dirty scanner mirror.
4. Dirty main charger wire.

Causes	Check procedures/corrective measures
1. Dirty contact glass.	Clean the contact glass.
2. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace the drum unit (see page 1-6-38).
3. Dirty scanner mirror.	Clean the scanner mirror.
4. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).

(7) A black line appears laterally.



Causes

1. Dirty contact glass.
2. Dirty or flawed drum.
3. Dirty scanner mirror.
4. Dirty shading plate.
5. Leaking main charger housing.

Causes	Check procedures/corrective measures
1. Dirty contact glass.	Clean the contact glass.
2. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace it (see page 1-6-38).
3. Dirty scanner mirror.	Clean the scanner mirror.
4. Dirty shading plate.	Clean the shading plate.
5. Leaking main charger housing.	Clean the main charger wire, grid and shield.

(8) One side of the copy image is darker than the other.



Causes

1. Dirty main charger wire.
2. Defective exposure lamp.

Causes	Check procedures/corrective measures
1. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).
2. Defective exposure lamp.	Check if the exposure lamp light is distributed evenly. If not, replace the exposure lamp and inverter PCB.

(9) Black dots appear on the image.




Causes

1. Dirty or flawed drum.
2. Dirty contact glass.
3. Deformed or worn cleaning blade.
4. Dirty drum separation claws.
5. Dirty heat roller separation claws.

Causes	Check procedures/corrective measures
1. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace the drum unit (see page 1-6-38).
2. Dirty contact glass.	Clean the contact glass.
3. Deformed or worn cleaning blade.	Replace the drum unit (see page 1-6-38).
4. Dirty drum separation claws.	Clean the drum separation claws.
5. Dirty the heat roller separation claws.	Clean the heat roller separation claws.

(10) Image is blurred.



Causes

1. Scanner moves erratically.
2. Deformed press roller.
3. Paper conveying section drive problem.

Causes	Check procedures/corrective measures
1. Scanner moves erratically.	Check if there is any foreign matter on the front and rear scanner rails. If any, remove it.
2. Deformed press roller.	Replace the press roller (see page 1-6-45).
3. Paper conveying section drive problem.	Check the gears and belts and, if necessary, grease them.

(11) The leading edge of the image is consistently misaligned with the original.



Causes

1. Misadjusted leading edge registration.
2. Misadjusted scanner leading edge registration.

Causes	Check procedures/corrective measures
1. Misadjusted leading edge registration.	Readjust the leading edge registration (see page 1-6-16).
2. Misadjusted scanner leading edge registration.	Readjust the scanner leading edge registration (see page 1-6-35).

(12) The leading edge of the image is sporadically misaligned with the original.

Causes

1. Paper feed clutch, bypass paper feed solenoid or registration motor installed or operating incorrectly.



Causes	Check procedures/corrective measures
1. Paper feed clutch, bypass paper feed solenoid or registration motor installed or operating incorrectly.	Check the installation position and operation of the paper feed clutch, bypass paper feed solenoid and registration motor. If any of them operates incorrectly, replace it.

(13) Paper creases.

Causes

1. Paper curled.
2. Paper damp.
3. Defective pressure springs.
4. Defective separation.
5. Dirty separation electrode.




Causes	Check procedures/corrective measures
1. Paper curled.	Check the paper storage conditions.
2. Paper damp.	Check the paper storage conditions.
3. Defective pressure springs.	Replace the pressure springs.
4. Defective separation.	Check the drum separation claws and heat roller separation claws.
5. Dirty separation electrode.	Clean the separation electrode.

(14) Offset occurs.

Causes

1. Defective cleaning blade.
2. Defective fixing section.



Causes	Check procedures/corrective measures
1. Defective cleaning blade.	Replace the drum unit (see page 1-6-38).
2. Defective fixing section.	Check the heat roller and press roller.

(15) Image is partly missing.




Causes

1. Paper damp.
2. Paper creased.
3. Dirty or flawed drum.
4. Dirty transfer roller.

Causes	Check procedures/corrective measures
1. Paper damp.	Check the paper storage conditions.
2. Paper creased.	Replace the paper.
3. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace the drum unit (see page 1-6-38).
4. Dirty transfer roller.	Clean the transfer roller.

(16) Fixing is poor.



Causes

1. Wrong paper.
2. Defective pressure springs.
3. Flawed press roller.
4. Defective fixing heater.

Causes	Check procedures/corrective measures
1. Wrong paper.	Check if the paper meets specifications.
2. Defective pressure springs.	Replace the pressure springs.
3. Flawed press roller.	Replace the press roller (see page 1-6-45).
4. Defective fixing heater.	Replace the fixing heater (see page 1-6-46).

(17) Image is out of focus.



Causes

1. Defective image scanning unit.
2. Drum condensation.

Causes	Check procedures/corrective measures
1. Defective image scanning unit.	Replace the image scanning unit (see page 1-6-28).
2. Drum condensation.	Clean the drum.

(18) Image center does not align with the original center.

**Causes**

1. Misadjusted center line of image printing.
2. Misadjusted scanner center line.
3. Original placed incorrectly.

Causes	Check procedures/corrective measures
1. Misadjusted center line of image printing.	Readjust the center line of image printing (see page 1-6-18).
2. Misadjusted scanner center line.	Readjust the scanner center line (see page 1-6-36).
3. Original placed incorrectly.	Place the original correctly.

1-5-4 Electric problems

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the power switch is turned on.	No electricity at the power outlet.	Measure the input voltage.
	The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	The front cover or left cover is not closed completely.	Check the front cover and left cover.
	Broken power cord.	Check for continuity. If none, replace the cord.
	Defective power switch.	Check for continuity across the contacts. If none, replace the power switch.
	Blown fuse in the power source PCB.	Check for continuity. If none, remove the cause of blowing and replace the fuse.
	Defective front or left cover safety switch.	Check for continuity across the contacts of each switch. If none, replace the switch.
	Defective power source PCB.	With AC present, check for 24 V DC at YC1-1 and 5 V DC at YC1-7 on the power source PCB. If none, replace the power source PCB.
(2) The drive motor does not operate (C2000).	Poor contact in the drive motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken drive motor gear.	Check visually and replace the drive motor if necessary.
	Defective drive motor.	Run maintenance item U030 and check if the drive motor operates when YC7-5 on the engine PCB goes low. If not, replace the drive motor.
	Defective engine PCB.	Run maintenance item U030 and check if YC7-5 on the engine PCB goes low. If not, replace the engine PCB.
(3) The registration motor does not operate.	Poor contact in the registration motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken registration motor gear.	Check visually and replace the registration motor if necessary.
	Defective registration motor.	Run maintenance item U030 and check if the registration motor operates when YC2-1,2,4,5 on the registration motor PCB goes low. If not, replace the registration motor.
	Defective engine PCB.	Run maintenance item U030 and check if YC4-4 on the engine PCB goes low. If not, replace the engine PCB.
(4) The exit motor does not operate.	Poor contact in the exit motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken exit motor gear.	Check visually and replace the exit motor if necessary.
	Defective exit motor.	Run maintenance item U030 and check if the exit motor operates when YC14-1,2,3,4 on the engine PCB go low. If not, replace the exit motor.
	Defective engine PCB.	Run maintenance item U030 and check if YC14-1,2,3,4 on the engine PCB go low. If not, replace the engine PCB.

Problem	Causes	Check procedures/corrective measures
(5) The scanner motor does not operate.	Broken scanner motor coil.	Check for continuity across the coil. If none, replace the scanner motor.
	Poor contact in the scanner motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
(6) Cooling fan motor 1 does not operate.	Broken cooling fan motor 1 coil.	Check for continuity across the coil. If none, replace cooling fan motor 1.
	Poor contact in the cooling fan motor 1 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(7) Cooling fan motor 2 does not operate.	Broken cooling fan motor 2 coil.	Check for continuity across the coil. If none, replace cooling fan motor 2.
	Poor contact in the cooling fan motor 2 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(8) Cooling fan motor 3 does not operate.	Broken cooling fan motor 3 coil.	Check for continuity across the coil. If none, replace cooling fan motor 3.
	Poor contact in the cooling fan motor 3 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(9) Cooling fan motor 4 does not operate.	Broken cooling fan motor 4 coil.	Check for continuity across the coil. If none, replace cooling fan motor 4.
	Poor contact in the cooling fan motor 4 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(10) Toner motor does not operate.	Broken toner motor coil.	Check for continuity across the coil. If none, replace toner motor.
	Poor contact in the toner motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(11) The drawer drive motor does not operate.	Poor contact in the drawer drive motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken drawer drive motor gear.	Check visually and replace the drawer drive motor if necessary.
	Defective drawer drive motor.	Run maintenance item U030 and check if the drawer drive motor operates when YC9-2,3,4,5 on the drawer main PCB goes low. If not, replace the drawer drive motor.
	Defective drawer main PCB.	Run maintenance item U030 and check if YC9-2,3,4,5 on the drawer main PCB goes low. If not, replace the drawer main PCB.
(12) The paper feed clutch does not operate.	Broken paper feed clutch-coil.	Check for continuity across the coil. If none, replace the paper feed clutch.
	Poor contact in the paper feed clutch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective engine PCB.	Run maintenance item U032 and check if YC8-3 on the engine PCB goes low. If not, replace the engine PCB.

Problem	Causes	Check procedures/corrective measures
(13) The bypass paper feed solenoid does not operate.	Broken bypass paper feed solenoid coil.	Check for continuity across the coil. If none, replace the bypass paper feed solenoid.
	Poor contact in the bypass paper feed solenoid connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective engine PCB.	Run maintenance item U032 and check if YC8-5 on the engine PCB goes low. If not, replace the engine PCB.
(14) The drawer paper feed clutch does not operate.	Broken drawer paper feed-clutch coil.	Check for continuity across the coil. If none, replace the drawer paper feed clutch.
	Poor contact in the drawer-paper feed clutch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective engine PCB.	Run maintenance item U032 and check if YC8-3 on the drawer main PCB goes low. If not, replace the drawer main PCB.
(15) The cleaning lamp does not turn on.	Poor contact in the cleaning lamp connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective cleaning lamp.	Check for continuity. If none, replace the cleaning lamp.
	Defective engine PCB.	If the cleaning lamp turns on when YC3-12, 13, 14 on the engine PCB is held low, replace the engine PCB.
(16) The exposure lamp does not turn on.	Poor contact in the exposure lamp connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective inverter PCB.	Run maintenance item U061 and check if the exposure lamp turns on with YC1-1 and YC1-6 on the inverter PCB go low. If not, replace the inverter PCB.
	Defective engine PCB.	Run maintenance item U061 and check if YC17-1 and YC17-6 on the engine PCB goes low. If not, replace the engine PCB.
(17) The exposure lamp does not turn off.	Defective inverter PCB.	If the exposure lamp does not turn off with YC1-1 and YC1-6 on the inverter PCB high, replace the inverter PCB.
	Defective engine PCB.	If YC17-1 and YC17-6 on the engine PCB are always low, replace the engine PCB.
(18) The fixing heater does not turn on (C6000).	Broken wire in fixing heater M or S.	Check for continuity across each heater. If none, replace the heater M or S.
	Fixing thermostat triggered.	Check for continuity across thermostat. If none, remove the cause and replace the thermostat.
(19) The fixing heater does not turn off.	Broken fixing thermistor wire.	Measure the resistance. If it is $\infty \Omega$, replace the fixing thermistor.
	Dirty sensor part of the fixing thermistor.	Check visually and clean the thermistor sensor parts.

Problem	Causes	Check procedures/corrective measures
(20) Main charging is not performed.	Broken main charger wire.	See page 1-5-27.
	Leaking main charger housing.	
	Poor contact in the high voltage PCB connector terminals.	
	Defective engine PCB.	
	Defective high-voltage PCB.	
(21) Transfer charging is not performed.	Poor contact in the high voltage PCB connector terminals.	See page 1-5-27.
	Defective engine PCB.	
	Defective high-voltage PCB.	
(22) No developing bias is output.	Poor contact in the high voltage PCB connector terminals.	See page 1-5-27.
	Defective engine PCB.	
	Defective high-voltage PCB.	
(23) The original size is not detected.	Defective original detection switch.	If the level of YC18-5 on the engine PCB does not change when the original detection switch is turned on and off, replace the original detection switch.
(24) The original size is not detected correctly.	Original is not placed correctly.	Check the original and correct if necessary.
	Poor contact in the original size detection sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective original size detection sensor.	Check if sensor operates correctly. If not, replace it.
(25) The message requesting paper to be loaded is shown when paper is present in the drawer 1.	Poor contact in the paper switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective paper switch.	If the level of YC8-2 on the engine PCB does not change when the paper switch is turned on and off, replace the paper switch.
(26) The message requesting paper to be loaded is shown when paper is present in the drawer 2.	Poor contact in the drawer paper switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective drawer paper switch.	If the level of YC5-2 on the drawer main PCB does not change when the drawer paper switch is turned on and off, replace the drawer paper switch.

Problem	Causes	Check procedures/corrective measures
(27) The size of paper in the drawer 1 is not displayed correctly.	Poor contact in the paper length switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective paper length switch.	Check if YC22-1,2,4 on the engine PCB goes low when the paper length switch is turned on. If not, replace the paper length switch.
(28) The size of paper in the drawer 2 is not displayed correctly.	Poor contact in the drawer paper length switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective drawer paper length switch.	Check if YC4-5,6,8 on the drawer main PCB goes low when the drawer paper length switch is turned on. If not, replace the drawer paper length switch.
(29) A paper jam in the paper feed, paper conveying or fixing section is indicated when the power switch is turned on.	A piece of paper torn from copy paper is caught around registration switch, exit switch or feedshift switch.	Check and remove if any.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding sensor is not light.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding sensor is not light.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding sensor is not light.
(30) The message requesting covers to be closed is displayed when the front cover and left cover are closed.	Poor contact in the connector terminals of safety switch.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective safety switch.	Check for continuity across each switch. If there is no continuity when the switch is on, replace it.
(31) Others.	Wiring is broken, shorted or makes poor contact.	Check for continuity. If none, repair.
	Noise.	Locate the source of noise and remove.

1-5-5 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers or pulleys are dirty with paper powder: forwarding pulley, paper feed pulley, separation pulley, registration rollers, bypass paper feed pulley, bypass separation pad, feed roller, drawer forwarding pulley, drawer paper feed pulley and drawer separation pulley.	Clean with isopropyl alcohol.
	Check if the forwarding pulley, paper feed pulley or separation pulley is deformed.	Check visually and replace any deformed pulleys (see pages 1-6-3 and 5).
	Check if the drawer forwarding pulley, drawer paper feed pulley or drawer separation pulley is deformed.	Check visually and replace any deformed pulleys (see pages 1-6-8 to 10).
	Electrical problem with the following electromagnetic clutches: paper feed clutch, bypass paper feed solenoid and drawer paper feed clutch.	See pages 1-5-35 and 36.
(2) No secondary paper feed.	Check if the surfaces of the right and left registration rollers are dirty with paper powder.	Clean with isopropyl alcohol.
	Electrical problem with the registration motor.	See page 1-5-34.
(3) Skewed paper feed.	Width guide in a drawer installed incorrectly.	Check the width guide visually and correct or replace if necessary.
	Deformed width guide in a drawer.	Repair or replace if necessary.
	Check if a pressure spring along the paper conveying path is deformed or out of place.	Repair or replace.
(4) The scanner does not travel.	Check if the scanner wire is loose.	Reinstall the scanner wire (see page 1-6-23).
	The scanner motor malfunctions.	See page 1-5-35.
(5) Multiple sheets of paper are fed at one time.	Check if the separation pulley or drawer separation pulley is worn.	Replace the separation pulley if it is worn (see page 1-6-3 and 8).
	Check if the paper is curled.	Change the paper.
(6) Paper jams.	Check if the paper is excessively curled.	Change the paper.
	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Check if the contact between the right and left registration rollers is correct.	Check visually and remedy if necessary.
	Check if the press roller is extremely dirty or deformed.	Clean or replace the press roller (see page 1-6-45).
	Check if the contact between the heat roller and its separation claws is correct.	Repair if any springs are off the separation claws.
	Check if the contact between the exit roller and pulley is correct.	Check visually and remedy if necessary.

Problem	Causes/check procedures	Corrective measures
(7) Toner drops on the paper conveying path.	Check if the developing unit is extremely dirty.	Clean the developing unit.
(8) Abnormal noise is heard.	Check if the pulleys, rollers and gears operate smoothly.	Grease the bearings and gears.
	Check if the following electromagnetic clutches are installed correctly: paper feed clutch, bypass paper feed solenoid and drawer paper feed clutch.	Correct.

1-6-1 Precautions for assembly and disassembly


(1) Precautions

Be sure to turn the power switch off and disconnect the power plug before starting disassembly.

When handling PCBs, do not touch connectors with bare hands or damage the board.

Do not touch any PCB containing ICs with bare hands or any object prone to static charge.

Use only the specified parts to replace the fixing unit thermostat. Never substitute electric wires, as the MFP may be seriously damaged.

(2) Running a maintenance item

1-6-2 Paper feed section

(1) Detaching and refitting the separation pulley

Follow the procedure below to replace the separation pulley.

Procedure

1. Open the front cover and left cover. Remove the waste toner box.
2. Pull out the drawer.




Figure 1-6-1

3. Remove the screw and then the front left lower cover.




Figure 1-6-2

4. Remove the screw and then the lower paper feed unit.





Figure 1-6-3

5. Remove the separation pulley unit from the lower paper feed unit.
6. Remove the separation pulley from the separation pulley unit.
7. Replace the separation pulley and refit all the removed parts.

**Figure 1-6-4**

(2) Detaching and refitting the forwarding pulley and paper feed pulley

Follow the procedure below to replace the forwarding pulley and paper feed pulley.

Procedure

1. Remove the lower paper feed unit (see page 1-6-3).
2. Remove the drum unit (see page 1-6-38).
3. Remove the rear cover.
4. Remove the paper feed clutch, stop ring and bushing at the machine rear.




Figure 1-6-5

5. Remove the screw and then the registration guide.




Figure 1-6-6

6. Remove the screw and then the upper paper feed unit.




Figure 1-6-7

7. Remove the springs, stop ring and bushing and then the shaft holder from the upper paper feed unit.




Figure 1-6-8

8. Remove the forwarding pulley from the upper paper feed unit.
9. Remove the paper feed pulley from the upper paper feed unit.
10. Replace the forwarding pulley and paper feed pulley and refit all the removed parts.




Figure 1-6-9

(3) Detaching and refitting the feed roller

Follow the procedure below to replace the feed roller.

Procedure

1. Remove the rear cover, right cover and front left lower cover.
2. Remove the three screws and then remove the main body from the paper feeder.




Figure 1-6-10-1

3. Open the drawer left cover.
4. Remove the two stop ring, gear and spring pin from rear side of the feed roller. When removing the gear, take care not to lose the spring pin.
5. Slide the bearings in the front and rear of the feed roller toward the inside, push the feed roller once into the rear side of the machine, and then remove it from the paper feeder.
6. Remove the two bushing from front and rear side of the feed roller.
7. Replace the feed roller and refit all the removed parts.





Figure 1-6-10-2

(4) Detaching and refitting the drawer separation pulley


Follow the procedure below to replace the drawer separation pulley.

Procedure

1. Pull out the drawer. Open the drawer left cover.
2. Remove the screw and then the lower paper feed unit.

**Figure 1-6-11**

3. Remove the drawer separation pulley unit from the lower paper feed unit.
4. Remove the drawer separation pulley from the drawer separation pulley unit.
5. Replace the drawer separation pulley and refit all the removed parts.

**Figure 1-6-12**

(5) Detaching and refitting the drawer forwarding pulley and drawer paper feed pulley

Follow the procedure below to replace the drawer forwarding pulley and drawer paper feed pulley.

Procedure

1. Remove the main body from the paper feeder (see page 1-6-7).
2. Remove the lower paper feed unit (see page 1-6-8).
3. Remove the drawer rear cover.
4. Remove the stop ring and drawer paper feed clutch from the machine rear side.
Remove the stop ring and bushing.




Figure 1-6-13

5. Remove the screw and then the upper paper feed unit.




Figure 1-6-14

6. Remove the springs, stop ring and bushing and then the shaft holder from the upper paper feed unit.




Figure 1-6-15

7. Remove the drawer forwarding pulley from the upper paper feed unit.
8. Remove the drawer paper feed pulley from the upper paper feed unit.
9. Replace the drawer forwarding pulley and drawer paper feed pulley and refit all the removed parts.




Figure 1-6-16

(6) Detaching and refitting the paper conveying unit

Follow the procedure below to maintenance of the paper feed section.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Remove the stop ring and strap from the rear side. Restore the paper conveying unit. Remove the pin and plate, and then remove the stopper from the front side.




Figure 1-6-17

3. Open the left cover until it is put horizontally.
4. Push the fitting portions of the fixtures located on the front and rear and then remove the fixtures from the left cover.
5. Remove the left cover from the MFP.






Figure 1-6-18


6. Push the fitting portions of the bypass upper cover. Remove the bypass upper cover from the bypass unit.

**Figure 1-6-19**

7. Detach the connector and remove the bypass lower cover from the MFP.

**Figure 1-6-20**

8. Remove the paper conveying unit from the MFP.

**Figure 1-6-21**

(7) Detaching and refitting the bypass paper feed pulley and bypass separation pad

Follow the procedure below to replace the bypass paper feed pulley and bypass separation pad.

Procedure

1. Open the front cover and remove the waste toner box. Pull out the drawer.
2. Remove the screw and then the front left lower cover.




Figure 1-6-22

3. Remove the paper conveying unit (see page 1-6-11).
4. Remove the stop ring and bushing at the machine front side.




Figure 1-6-23

5. Remove the rear cover.
6. Remove the stop ring and bypass paper feed clutch gear at the machine rear side.




Figure 1-6-24

7. Temporarily push the bypass paper feed pulley unit into the rear side to unlock the front side and then remove it from the MFP.




Figure 1-6-25

8. Remove the bypass paper feed pulley from the bypass paper feed pulley shaft.




Figure 1-6-26

9. Push the fitting portions of the bypass separation pad. Remove the bypass separation pad from the MFP.
10. Replace the bypass paper feed pulley and bypass separation pad and refit all the removed parts.




Figure 1-6-27

(8) Detaching and refitting the registration left roller

Follow the procedure below to replace the registration left roller.

Procedure

1. Remove the paper conveying unit (see page 1-6-11).
2. Remove the transfer roller (see page 1-6-42).
3. Release the stoppers at the front and rear side, and then remove the registration left roller from the paper conveying unit.
4. Replace the registration left roller and refit all the removed parts.




Figure 1-6-28

(9) Detaching and refitting the registration cleaner

Follow the procedure below to replace the registration cleaner.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Remove the screw and then the registration guide.




Figure 1-6-29

3. Remove the screw and then the registration cleaner.
4. Replace the registration cleaner and refit all the removed parts.





Figure 1-6-30

(10) Adjustment after roller and clutch replacement

Perform the following adjustment after refitting rollers and clutches.

(10-1) Adjusting the leading edge registration of image printing


Make the following adjustment if there is a regular error between the leading edges of the copy image and original.



Caution:


Check the copy image after the adjustment. If the image is still incorrect, perform the above adjustments in maintenance mode.

Procedure



(10-2) Adjusting the leading edge registration for memory image printing

Make the following adjustment if there is a regular error between the leading edge of the copy image and the leading edge of the original during memory copying.



Caution:

Before making the following adjustment, ensure the above adjustments have been made in maintenance mode.

Procedure






Figure 1-6-32

Setting range: -2.0 – +2.0
Initial setting: 0.0
Changing the value by 1 moves the leading edge by 0.1 mm.


(10-3) Adjusting the center line of image printing

Make the following adjustment if there is a regular error between the center lines of the copy image and original when paper is fed from the drawer.




Caution:
Check the copy image after the adjustment. If the image is still incorrect, perform the above adjustments in maintenance mode.

Procedure




(10-4) Adjusting the trailing edge margin of image printing

Make the following adjustment if there is a regular error between the trailing edges of the copy image and original.


Procedure

(10-5) Adjusting the margins for printing

Make the following adjustment if the margins are not correct.



**Caution:**

Check the copy image after the adjustment. If the margins are still incorrect, perform the above adjustments in maintenance mode.

Procedure**Figure 1-6-35**

(10-6) Adjusting the amount of slack in the paper

Make the following adjustment if the leading edge of the copy image is missing or varies randomly, or if the copy paper is Z-folded.

Procedure

1-6-3 Optical section

(1) Detaching and refitting the exposure lamp

Take the following procedure when the exposure lamp is to be replaced.

Procedure

1. Remove the original cover or the DP.
2. Remove the two screws holding the upper right cover and then the cover. Remove the contact glass.




Figure 1-6-37

3. Move the mirror 1 frame to the cutouts of the machine.
* When moving the mirror 1 frame, do not touch the exposure lamp nor the inverter PCB.
4. Detach the exposure lamp connector from the inverter PCB and release the wire from three clamps.




Figure 1-6-38

5. Remove the two screws holding the exposure lamp and then the lamp.
6. Replace the exposure lamp and refit all the removed parts.




Figure 1-6-39

(2) Detaching and refitting the scanner wires

Take the following procedure when the scanner wires are broken or to be replaced.

(2-1) Detaching the scanner wires

Procedure

1. Remove the exposure lamp (see page 1-6-22).
2. Remove the two screws holding the upper rear cover and then the cover. Remove the two screws holding the middle left cover and upper left cover and then the covers.




Figure 1-6-40

3. Remove the screw and then the slit retainer and slit glass. Detach the fitting portions and then remove the front scanner cover.




Figure 1-6-41

4. Remove the inverter wire guide and then detach the inverter wire from the inverter PCB.






Figure 1-6-42

5. Remove the screw holding each of the front and rear wire retainers and then remove the mirror 1 frame from the scanner unit.

**Figure 1-6-43**

6. Unhook the round terminal of the scanner wire from the scanner tension spring on the left side of the scanner unit.
7. Remove the scanner wire.

**Figure 1-6-44**

(2-2) Fitting the scanner wires

Caution:

When fitting the wires, be sure to use those specified below.

Machine front: P/N 2C91236 (gray)

Machine rear: P/N 2C91235 (black)

Fitting requires the following tools:

Two frame securing tools (P/N 302C968310)

Two scanner wire stoppers (P/N 3596811)

Procedure

1. Remove the screw and then scanner wire drum gear at the machine rear side.




Figure 1-6-45

2. Remove the stop ring and bushing from the front of the scanner wire drum shaft.
3. Remove the scanner wire drum shaft from the scanner unit.




Figure 1-6-46

4. Insert the locating ball on each of the scanner wires into the hole in the respective scanner wire drum and wind the scanner wire three turns inward and four turns outward.
With the locating ball as the reference point, wind the shorter end of each of the wires outward.
5. Secure the scanner wires using the scanner wire stoppers.




Figure 1-6-47

6. Refit the scanner wire drum shaft to the scanner unit.
7. Insert the two frame securing tools into the positioning holes at the front and rear of the scanner unit to pin the mirror 2 frame in position.




Figure 1-6-48

8. Loop the outer ends of the scanner wires around the outer grooves in the pulleys on the mirror 2 frame, winding from below to above. (1)
9. Hook the round terminals onto the catches inside the scanner unit. (2)
10. Loop the inner ends of the scanner wires around the grooves in the pulleys at the left of the scanner unit, winding from below to above. (3)
11. Loop the scanner wires around the inner grooves in the pulleys on the mirror 2 frame, winding from above to below. (4)
12. Wind the scanner wires around the grooves in the scanner wire guides at the left of the scanner unit. (5)
13. Hook the round terminals onto the scanner tension springs. (6)




Figure 1-6-49

14. Remove the scanner wire stoppers and frame securing tools.
15. Gather the scanner wires toward the locating balls.
16. Move the mirror 2 frame from side to side to correctly locate the wires in position.
17. Put the mirror 1 frame on the scanner rail and move it toward the left side of the machine.
18. Insert the frame securing tools into the positioning holes (leftmost holes) at the front and the rear of the scanner unit and screw the mirror 1 frame while securing both the mirror 1 frame and the mirror 2 frame.
19. Remove the two frame securing tools.
20. Refit all the removed parts.




Figure 1-6-50

(3) Detaching and refitting the ISU (reference)

Take the following procedure when the ISU is to be replaced.

Procedure

Detaching the ISU

1. Remove the contact glass (see page 1-6-22).
2. Remove the four screws holding the ISU cover and then the cover.




Figure 1-6-51

3. Detach the CCD wire from the CCD PCB.
4. Remove the four screws holding the ISU and then the ISU.
5. Replace the ISU.




Figure 1-6-52

Refitting the ISU

1. Align the positioning holes of the ISU by pushing it a little and attach the ISU to the scanner unit.
* Attach the ISU with reference to marking "C".
2. Secure the ISU using the four screws.
3. Refit the CCD wire to CCD PCB.
4. Refit all the removed parts.




Figure 1-6-53

(4) Detaching and refitting the laser scanner unit

Take the following procedure when the laser scanner unit is to be replaced.

Procedure

1. Remove the original cover or the DP.
2. Remove the upper right cover, contact glass, upper rear cover, middle left cover, upper left cover, slit glass and front scanner cover (see page 1-6-23).
3. Remove the four screws holding the right cover and then the cover. Remove the seven screws holding the rear cover and then the cover.




Figure 1-6-54

4. Detach the connector YC8 on the main PCB. Detach the connectors YC16, YC17, YC18 and YC19 on the engine PCB.






Figure 1-6-55


5. Remove the four pins holding the scanner unit and then the unit.

**Figure 1-6-56**


6. Remove the screw holding the exit cover and then the cover. Remove the two screws holding the inner rear cover and then the cover.

**Figure 1-6-57**


7. Remove the front and rear left cover.

**Figure 1-6-58**


8. Remove the two screws holding the exit unit and then pull out the unit a little.

**Figure 1-6-59**

9. Remove the exit tray.

**Figure 1-6-60**

10. Remove the four screws and detach the two connector and then remove the laser scanner unit.
11. Replace the laser scanner unit and refit all the removed parts.

**Figure 1-6-61**

(5) Adjusting the longitudinal squareness (reference)

Perform the following adjustment if the copy image is longitudinally skewed (longitudinal squareness not obtained).

Caution:

Adjust the amount of slack in the paper (page 1-6-21) first. Check for the longitudinal squareness of the copy image, and if it is not obtained, perform the longitudinal squareness adjustment.

Before making the following adjustment, output a VTC-PG2 pattern in maintenance item U993 to use as the original for the adjustment.

Procedure






Figure 1-6-63

(6) Adjusting magnification of the scanner in the main scanning direction


Perform the following adjustment if the magnification in the main scanning direction is not correct.



Caution:


Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode. Also, perform “(7) Adjusting magnification of the scanner in the auxiliary scanning direction” (page 1-6-34) and “(9) Adjusting the scanner center line” (page 1-6-36) after this adjustment.

Procedure



(7) Adjusting magnification of the scanner in the auxiliary scanning direction

Perform the following adjustment if the magnification in the auxiliary scanning direction is not correct.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure






Figure 1-6-65

(8) Adjusting the scanner leading edge registration


Perform the following adjustment if there is regular error between the leading edges of the copy image and original.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure



(9) Adjusting the scanner center line


Perform the following adjustment if there is a regular error between the center lines of the copy image and original.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure



(10) Adjusting the margins for scanning an original on the contact glass

Perform the following adjustment if the margins are not correct.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure




Figure 1-6-68

1-6-4 Drum section

(1) Detaching and refitting the drum unit

Follow the procedure below to replace the drum unit.

Cautions:

Avoid direct sunlight or strong light when detaching and refitting the drum unit.
Never touch the drum surface when holding the drum unit.

Procedure

1. Open the front cover and left cover. Remove the waste toner box and toner container.
2. Remove the inner cover.
3. Remove the screw and then remove the developing wire cover.
4. Pull the developing release lever and then release the developing unit.




Figure 1-6-69

5. Remove the screw and detach the two connectors.
 6. Remove the drum unit from MFP.
 7. Replace the drum unit and refit all the removed parts.
- When installing the drum unit, open the drum cover to outside (machine left side).





Figure 1-6-70

(2) Detaching and refitting the drum separation claws

Follow the procedure below to replace the drum separation claws.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Push the drum separation claws with the minus driver from the top of the corner hole and remove the claws.
3. Replace the drum separation claws and refit all the removed parts.




Figure 1-6-71

(3) Detaching and refitting the main charger unit

Follow the procedure below to replace the main charger unit.

Procedure

1. Open the front cover and remove the waste toner box and inner cover.
2. While lifting the main charger unit toward the upper right, remove the unit from the MFP.
3. While pressing the main charger release lever in the direction indicated by the arrow at the removal stopper position to release the removal stopper, remove the main charger unit from the MFP.
4. Replace the main charger unit and refit all the removed parts.




Figure 1-6-72

1-6-5 Developing section

(1) Detaching and refitting the developing unit

Follow the procedure below to replace the developing unit.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Remove the two connectors from the developing unit.




Figure 1-6-73-1

3. While lifting the developing unit a little, remove the unit from the MFP.
4. Replace the developing unit and refit all the removed parts.




Figure 1-6-73-2

1-6-6 Transfer section

(1) Detaching and refitting the transfer roller

Follow the procedure below to replace the transfer roller.

Procedure

1. Remove the paper conveying unit (see page 1-6-11).
2. Remove the screw holding each of the front and rear release lever stoppers and then the stoppers from the release lever shaft.




Figure 1-6-74

3. Detach the fitting portions located on the front and rear and then remove the transfer roller from the paper conveying unit.
4. Replace the transfer roller and refit all the removed parts.




Figure 1-6-75

1-6-7 Fixing section

(1) Detaching and refitting the fixing unit

Follow the procedure below to replace the fixing unit.

Procedure

1. Open the front cover and left cover and then remove the inner cover.
2. Insert a flat-blade screwdriver or the like through the groove at the left side of the machine and unlock the engaged portion of front left cover 1 to remove it.




Figure 1-6-76

3. Remove the screw and then remove the front left cover 2.




Figure 1-6-77

4. Remove the screw and then remove the stopper and spacer.
When attaching the spacer, place the fixing unit on the original step.




Figure 1-6-78

5. Remove the screw and detach the two connectors and then remove the fixing unit from MFP.
6. Replace the fixing unit and refit all the removed parts.




Figure 1-6-79

(2) Detaching and refitting the press roller

Follow the procedure below to replace the press roller.

Procedure

1. Remove the fixing unit (see page 1-6-43).
2. Remove the two screws and then separate the fixing right unit and left unit.




Figure 1-6-80

3. Remove the three screws holding the press roller guide from fixing right unit.




Figure 1-6-81

4. Remove the press roller from the fixing right unit.
5. Replace the press roller and refit all the removed parts.




Figure 1-6-82

(3) Detaching and refitting the fixing heater M and S

Follow the procedure below to replace the fixing heater M and S.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 45).
2. Remove the two screws holding each of the fixing heater M and S on the front and rear of the fixing left unit.




Figure 1-6-83

3. Pull out the fixing heater M and S from the fixing left unit.
4. Replace the fixing heater M and S, and refit all the removed parts.




Figure 1-6-84

(4) Detaching and refitting the heat roller separation claws

Follow the procedure below to replace the heat roller separation claws.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 45).
2. Detach the fitting portions and then remove the heat roller guide from the fixing left unit.




Figure 1-6-85

3. Remove the heat roller separation claws from the fixing left unit.
4. Replace the heat roller separation claws and refit all the removed parts.




Figure 1-6-86

(5) Detaching and refitting the heat roller

Follow the procedure below to replace the heat roller.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 45).
2. Remove the heat roller separation claws. (see page 1-6-47).
3. Pull out the heat roller bushing from the fixing left unit and then remove the heat roller.
4. Replace the heat roller and refit all the removed parts.




Figure 1-6-87

(6) Detaching and refitting the fixing thermostat

Follow the procedure below to replace the fixing thermostat.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 45).
2. Remove the heat roller (see page 1-6-48).
3. Remove the two screws holding the fixing thermostat and then the thermostat.
4. Replace the fixing thermostat and refit all the removed parts.




Figure 1-6-88

(7) Detaching and refitting the fixing thermistor

Follow the procedure below to replace the fixing thermistor.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 45).
2. Remove the heat roller (see page 1-6-48).
3. Remove the screw holding the fixing thermistor and then the thermistor.
4. Replace the fixing thermistor and refit all the removed parts.




Figure 1-6-89

(8) Adjusting the fixing unit height (adjusting lateral squareness)

Follow the procedure below if the drum is not parallel to the fixing unit and therefore paper is not fed straight to the fixing section and the trailing edge of image on either the front or rear side becomes longer.

Procedure

1. Remove the front left cover 1 and 2 (see page 1-6-43).
2. Remove the screw and then remove the stopper.
3. Loosen the screw holding the fixing unit.




Figure 1-6-90

4. In the case of copy example 1 (the trailing edge of image of the machine rear side becomes longer): Place the fixing unit on the third step from the bottom of the spacer to adjust the spacer position (height adjustment of +0.5 mm).

In the case of copy example 2 (the trailing edge of image of the machine front side becomes longer): Place the fixing unit on the first step from the bottom of the spacer to adjust the spacer position (height adjustment of -0.5 mm).





Figure 1-6-91



[Cross section viewing from the right side of the machine]

Figure 1-6-92

5. Retighten the screw holding the fixing unit and refit the stopper.
6. Refit all the removed parts.

1-7-1 Upgrading the firmware on the main PCB

Firmware upgrading requires the following tools:

Compact Flash (Products manufactured by SANDISK are recommended.)

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Turn the power switch off and disconnect the power plug.
2. Remove the rear cover.
3. Insert Compact Flash in a socket of the machine (insert the surface of Compact Flash toward the machine rear).
4. Insert the power plug and turn the power switch on. Upgrading firmware starts.
Caution:
Never turn the power switch off during upgrading.
5. "Completed" is indicated on the message display when upgrading is complete.
6. Turn the power switch off and disconnect the power plug.
7. Remove Compact Flash from the machine and refit the rear cover.
8. Insert the power plug and turn the power switch on.




Figure 1-7-1

1-7-2 Upgrading the printer board firmware

Firmware upgrading requires the following tools:

Compact Flash (Products manufactured by SANDISK are recommended.)

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Turn the power switch off and disconnect the power plug.
2. Insert Compact Flash in a notch hole of the machine (insert the surface of Compact Flash toward the machine rear).
3. Insert the power plug and turn the power switch on. Upgrading firmware starts.
Caution:
Never turn the power switch off during upgrading.
4. "Completed" is indicated on the message display when upgrading is complete.
5. Turn the power switch off and disconnect the power plug.
6. Remove Compact Flash from the machine and refit the rear cover.
7. Insert the power plug and turn the power switch on.




Figure 1-7-2

1-7-3 Adjustment-free variable resistors (VR)

The variable resistors listed below are set at the factory prior to shipping and cannot be adjusted in the field.

High-voltage PCB: VR201, VR202, VR301

Drum unit zener PCB: VR1

1-7-4 Remarks on PCBs replacement

Confirm the version of the firmware and upgrade the version in up-to-date state when replacing PCBs.

When replacing the engine PCB or main PCB, remove the EEPROM from the engine PCB or main PCB that has been removed and then reattach it to the new engine PCB or main PCB.




Figure 1-7-3

2-1-1 Paper feed section

The paper feed section conveys paper from the drawer or bypass tray to the left and right registration rollers, at which point secondary feed takes place and the paper travels to the transfer section in sync with the printing timing. Drawer can hold up to 300 sheets of paper. Paper is fed from the drawer by the rotation of the forwarding pulley and paper feed pulley. The separation pulley prevents multiple sheets from being fed at one time, via the torque limiter. The bypass tray can hold up to 50 sheets of paper. Paper is fed from the bypass tray by the rotation of the bypass paper feed pulley.




Figure 2-1-1 Paper feed section

- | | |
|-------------------------------|--|
| (1) Separation pulley | (10) Bypass paper width switch (BYPPWSW) |
| (2) Forwarding pulley | (11) Drawer paper feed pulley |
| (3) Paper feed pulley | (12) Drawer forwarding pulley |
| (4) Bypass paper feed pulley | (13) Drawer separation pulley |
| (5) Bypass separation pad | (14) Feed roller |
| (6) Left registration roller | (15) Feed pulley |
| (7) Right registration roller | (16) Drawer lift |
| (8) Drawer lift | (17) Drawer feed switch (DFSW) |
| (9) Registration switch (RSW) | |





Figure 2-1-2 Paper feed section block diagram



Timing chart 2-1-1 Paper feed from the drawer (A4, single-sided copy)

- a: 200 ms after the drive motor (DM) turns on, the paper feed clutch (PFCL) turns on to start primary paper feed.
- b: 340 ms after the paper feed clutch (PFCL) turns on, the registration switch (RSW) turns on.
- c: 85 ms after the registration switch (RSW) turns on, the paper feed clutch (PFCL) turns off.
- d: The paper feed clutch (PFCL) turns on at the same time, the registration motor (RM) turns on to start secondary paper feed.
- e: 280 ms after the paper feed clutch (PFCL) turns on, the paper feed clutch (PFCL) turns off.
- f: 155 ms after the registration switch (RSW) turns off, the registration motor (RM) turns off.

2-1-2 Optical section

The optical section consists of the scanner, mirror frames and the image scanning unit for scanning and the laser scanner unit for printing.




Figure 2-1-3 Optical section

- (1) Mirror 1 frame
- (2) Mirror 2 frame
- (3) Exposure lamp (EL)
- (4) Mirror 1
- (5) Mirror 2
- (6) Mirror 3
- (7) Image scanning unit (ISU)
- (8) CCD PCB (CCDPCB)
- (9) Laser scanner unit (LSU)
- (10) Scanner home position switch (SHPSW)
- (11) Original detection switch (ODSW)
- (12) Original size detection sensor (OSDS)

(1) Original scanning

The original image is illuminated by the exposure lamp (EL) and scanned by the CCD PCB (CCDPCB) in the image scanning unit via the three mirrors, the reflected light being converted to an electrical signal.

The scanner and mirror frames travel to scan on the optical rails on the front and rear of the machine to scan from side to side. The speed of the mirror frames is half the speed of the scanner. When the DP is used, the scanner and mirror frames stop at the DP original scanning position to start scanning.




Figure 2-1-4 Optional section block diagram

(2) Image printing

The image data scanned by the CCD PCB (CCDPB) is processed on the main PCB (MPCB) and transmitted as image printing data to the laser scanner unit (LSU). By repeatedly turning the laser on and off, the laser scanner unit forms a latent image on the drum surface.




Figure 2-1-5 Laser scanner unit

- 1: Laser diode: Generates the laser beam which forms a latent image on the drum.
- 2: Collimator lens: Collimates the diffused laser beam emitted from the laser diode to convert it into a cylindrical beam.
- 3: Cylindrical lens: Shapes the collimated laser beam to suit the printing resolution.
- 4: Polygon mirror: Six-facet mirror that rotates at approximately 23619 rpm with each face reflecting the laser beam toward the drum for one main-direction scan.
- 5: Polygon motor: Drives the polygon mirror.
- 6: F θ lens: Corrects for non-linearity of the laser beam scanning speed on the drum surface, keeps the beam diameter constant and corrects for the vertical alignment of the polygon mirror to ensure that the focal plane of the laser beam is on the drum surface.
- 7: F θ lens: Corrects for non-linearity of the laser beam scanning speed on the drum surface, keeps the beam diameter constant and corrects for the vertical alignment of the polygon mirror to ensure that the focal plane of the laser beam is on the drum surface.
- 8: PD sensor mirror: Reflects the laser beam to the PD sensor to generate the main-direction (horizontal) sync signal.
- 9: Cylindrical correcting lens: Corrects for the deviation of the laser beam reflected by the PD sensor mirror to the PD sensor.
- 10: PD sensor: Detects the beam reflected by the PD sensor mirror, outputting a signal to the main PCB (MPCB) to provide timing for the main-direction sync signal.

The dimensions of the laser beam are as shown in Figure 2-1-6.




Figure 2-1-6

Scanning in the main direction is provided by the rotating polygon mirror, while scanning in the auxiliary direction is provided by the rotating drum, forming a static latent image on the drum.

The static latent image of the letter "A", for example, is formed on the drum surface as shown in Figure 2-1-7. Electrical charge is dissipated on the area of the drum surface irradiated by the laser.

The focal point of the laser beam is moved line by line, and adjacent lines slightly overlap each other.




Figure 2-1-7

2-1-3 Drum section

The drum section consists of the drum, main charger section, cleaning section and cleaning lamp.

The main charger section consists of main charger wire, main charger grid and main charger shield, and the drum is charged by a high voltage applied to the main charger wire. In addition, this section is equipped with a manual main charger cleaner that is used for cleaning the main charger wire.

The cleaning section consists of the cleaning blade and cleaning roller that removes residual toner from the drum surface after the transfer process, and the cleaning spiral that carries the residual toner back to the waste toner box.

The cleaning lamp (CL) consists of LEDs which remove residual charge from the drum surface.

Also the drum section is equipped with a drum cover to protect the drum in jammed paper removal.




Figure 2-1-8 Drum section

- (1) Drum
- (2) Main charger unit
- (3) Main charger wire
- (4) Drum separation claw
- (5) Cleaning roller
- (6) Cleaning spiral
- (7) Cleaning blade
- (8) Cleaning lamp (CL)
- (9) Drum cover
- (10) Drum cover open/close lever





Figure 2-1-9 Drum section block diagram



Timing chart 2-1-2 Main charging section operation

- a: The drive motor (DM) turns on at the same time, the cleaning lamp (CL) turns on.
 b: 30 ms after the drive motor (DM) turns on, main charging starts.
 c: The drive motor (DM) turns off at the same time, main charging is completed and the cleaning lamp (CL) turns off.

2-1-4 Developing section

The developing section consists of the developing unit and the toner container.

The developing unit consists of the developing roller where a magnetic brush is formed, the doctor blade and the developing spirals that agitate the toner.

Also, the toner container sensor (TCS) checks whether or not toner remains in the toner container.




Figure 2-1-10 Developing section

- (1) Developing unit
- (2) Developing roller
- (3) Doctor blade
- (4) Left developing spiral
- (5) Right developing spiral
- (6) Toner container
- (7) Toner container sensor (TCS)
- (8) Toner container detection switch (TCDSW)
- (9) Toner empty sensor (TES)

(1) Formation of magnetic brush

The developing roller consists of a magnet roller with four poles and a sleeve roller. Rotation of the sleeve roller around the magnet roller entrains toner, which in turn forms a magnetic brush at pole N1 on the magnet roller. The height of the magnetic brush is regulated by the doctor blade; the developing result is affected by the position of the poles on the magnet roller and the position of the doctor blade.

A developing bias voltage generated by the high-voltage PCB (HVTPCB) is applied to the developing roller to provide image contrast.




Figure 2-1-11 Forming a magnetic brush




Figure 2-1-12 Developing section block diagram

(2) Single component developing system

This machine uses the single component developing system, and reversal processing is performed with a + charged drum (a-Si) and a + charged magnetic toner.

With the single component developing system, toner is electrically charged by friction with the developing sleeve and + charged when it passes through the magnetic doctor blade. The toner that has passed through the magnetic doctor blade forms a uniform layer on the developing sleeve. When the toner layer comes to the location where the developing sleeve is the nearest to the drum, toner moves between the drum and the developing sleeve by an electric field of the magnetic pole. Then, when the developing sleeve rotates and passes through the nearest location to the drum, on the portion of the drum that has been exposed to light, toner is attracted toward the drum by potential difference between the developing bias and the drum surface and development is performed. On the other hand, on the portion of the drum that has not been exposed to light, toner is attracted toward the sleeve and development is not performed. When toner comes to an area where the gap between the drum and the developing sleeve is large, an electric field disappears and toner does not leave the developing sleeve. Development is complete.




Figure 2-1-13 Single component developing system

Developing bias parameters

For the bias to the developing sleeve, an alternating current (AC) is applied. Parameters for the developing bias are shown below.

Vp-p: Difference between the maximum and the minimum of applied voltage

1.6 kV (fixed)

Vf: Frequency

Typically 2.7 kHz. This value varies depending on the preset value of the drive time and the environmental correction. (Can be adjusted with the maintenance item U101.)

Duty: Ratio of time where + voltage is applied in a cycle

Typically 45%. (Can be adjusted with the maintenance item U101.)

Vdc: Developing shift bias potential 290 V

Supplementation

Vo: Drum surface potential on non-image area (area not exposed to light)

VL: Drum surface potential on image area (area exposed to light)




Figure 2-1-14 Developing bias waveformsa

2-1-5 Transfer and separation sections

The transfer and separation sections consists of the transfer roller, separation electrode and drum separation claws. A high voltage generated by the high-voltage PCB (HVTPCB) is applied to the transfer roller for transfer charging. Paper after transfer is separated from the drum by applying separation bias that is output from the high-voltage PCB (HVT-PCB) to the separation electrode.




Figure 2-1-15 Transfer and separation sections

- (1) Transfer roller
- (2) Separation electrode
- (3) Drum separation claw
- (4) Drum





Figure 2-1-16 Transfer and separation sections block diagram



Timing chart 2-1-3 Transfer and separation sections operation

- a: The drive motor (DM) turns on at the same time, the transfer bias (+590 V) turns on.
 b: 230 ms after secondary paper feed starts, the transfer bias turns off.
 c: 40 ms after the transfer bias turns off, separation charging starts.
 d: 10 ms after separation charging starts, the transfer bias (-40 μ A) turns on.
 e: 290 ms after the registration switch (RSW) turns off, the transfer bias (-20 μ A) turns on. And 50 ms after the transfer bias turns off.
 f: 40 ms after the transfer bias turns off, separation charging ends.
 g: 260 ms after separation charging ends, the transfer bias (+590 V) turns on.
 h: The drive motor (DM) turns off at the same time, the transfer bias turns off.

2-1-6 Fixing section

The fixing section consists of the parts shown in figure. When paper reaches the fixing section after the transfer process, it passes between the press roller and heat roller, which is heated by fixing heaters M and S (FH-M/FH-S). Pressure is applied by the fixing unit pressure springs so that the toner on the paper is melted, fused and fixed onto the paper. The heat roller is heated by fixing heaters M and S (FH-M/FH-S) inside it; its surface temperature is detected by the fixing thermostat (FTH) and is regulated by the fixing heaters turning on and off.

If the fixing section becomes abnormally hot, fixing thermostat (FTS) operates shutting the power to the fixing heaters off. When the fixing process is completed, the paper is separated from the heat roller by its separation claws and is conveyed from the MFP to exit and switchback section.




Figure 2-1-17 Fixing section

- | | |
|-----------------------|---------------------------------|
| (1) Left fixing unit | (5) Fixing heater M (FH-M) |
| (2) Right fixing unit | (6) Fixing heater S (FH-S) |
| (3) Press roller | (7) Heat roller separation claw |
| (4) Heat roller | (8) Fixing thermostat (FTH) |




Figure 2-1-18 Fixing section block diagram

(1) Fixing temperature system




Figure 2-1-19 Fixing temperature system

Warm-up control

1. 500 ms after the fixing heater S (FH-S) turns on, the fixing heater M (FH-M) turns on.
2. When the fixing temperature reaches preset temperature, both fixing heater S (FH-S) and fixing heater M (FH-M) turn off simultaneously.

Ready state control

1. When the fixing temperature drops to the preset temperature, fixing heater S (FH-S) turns on, and after specified time, the heater turns off.
2. When fixing heater S (FH-S) turns off, fixing heater M (FH-M) turns on at the same time, and after specified time, the heater turns off.
3. The operation above is repeated to keep the fixing temperature to the preset temperature.
If a temperature more than or equal to the preset temperature + 20°C/68°F is detected, both fixing heater S (FH-S) and fixing heater M (FH-M) are turned off forcibly.

(2) Fixing temperature control based on ambient temperature

This machine performs fixing temperature control based on the ambient temperature.

Ambient temperature	Fixing temperature (°C)
Lower than 13°C/55.4°F	Reference value +10
Higher than or equal to 13°C/55.4°F, lower than 18°C/64.4°F	Reference value +5
Higher than or equal to 18°C/64.4°F, lower than 31°C/87.8°F	Reference value

2-1-7 Exit and switchback sections

The exit and switchback sections exit paper on which fixing has ended with the exit roller that is rotated by forward rotation of the exit motor.

In duplex copying, paper is turned over by reverse rotation of the exit motor.




Figure 2-1-20 Exit and switchback sections

- (1) Feedshift guide
- (2) Exit roller
- (3) Exit pulley
- (4) Feedshift guide
- (5) Switchback roller
- (6) Switchback pulley
- (7) Exit switch (ESW)
- (8) Feedshift switch (FSSW)




Figure 2-1-21 Exit and switchback sections block diagram

2-1-8 Duplex section

In duplex mode, after copying on to the reverse face of the paper, the paper is reversed in the switchback section and conveyed to the duplex unit. The paper is then conveyed to the MFP paper feed section by the upper and lower duplex feed rollers.




Figure 2-1-22 Duplex section




Figure 2-1-23 Duplex section block diagram

(1) Paper conveying operation in duplex copying

Paper of which copying onto the reverse side is complete is conveyed to the switchback section, the exit motor switches from forward rotation to reverse rotation to switch the exit roller to reverse rotation, and the paper conveying direction is reversed. Paper that has been switched back is conveyed to the duplex unit via the exit roller and the switchback roller. Paper that has been conveyed to the duplex unit is conveyed to the paper feed section again by rotation of the upper duplex feed roller and the lower duplex feed roller and copying onto the front side is performed.




Figure 2-1-24

2-2-1 Electrical parts layout

(1) PCBs





Figure 2-2-1 PCBs


- | | |
|--|---|
| 1. Engine PCB (EPCB) | Controls the other PCBs, electrical components and optional devices. |
| 2. Main PCB (MPCB) | Controls the operation panel and laser scanner unit. |
| 3. Power source PCB (PSPCB) | Generates +24 V DC and 5V DC; controls the fixing heater. |
| 4. High-voltage PCB (HVTPCB) | Main charging. Generates high voltages for transfer and high voltages for separation. |
| 5. Inverter PCB (INPCB) | Controls the exposure lamp. |
| 6. CCD PCB (CCDPCB) | Reads the image off originals. |
| 7. Operation unit PCB (OPCB) | Consists of the operation keys and display LEDs. |
| 8. Drawer PCB (DPCB) | Controls the electrical components. |
| 9. APC PCB (APCPCB) | Generates and controls the laser light. |
| 10. PD PCB (PDPCB) | Controls horizontal synchronizing timing of laser beam. |
| 11. Registration motor PCB (RMPCB) | Controls the registration motor. |
| 12. Printer board PCB (PRNPCB) | Controls the printer functions. |
| 13. LCD PCB (LCDPCB) | Controls the display of LCD. |
| 14. Drawer main PCB (DMPCB) | Controls electrical components of the drawer. |
| 15. Drawer heater PCB (DHPCB) | Relays the drawer heater power. |
| 16. Drum PCB (DRPCB) | Stores the individual drum unit information. |
| 17. Developing PCB (DVPCB) | Stores the individual developing unit information. |
| 18. Fixing PCB (FXPCB) | Relays internal wiring of the fixing unit. |

(2) Switches and sensors**Figure 2-2-2 Switches and sensors**


- | | |
|--|---|
| 1. Power switch (POWSW) | Turns the AC power on and off. |
| 2. Front cover safety switch (FCSSW) | Breaks the safety circuit when the front cover is opened. |
| 3. Left cover safety switch (LCSSW) | Breaks the safety circuit when the left cover is opened. |
| 4. Paper switch (PSW) | Detects the presence of paper in the drawer. |
| 5. Paper size length switch (PLSW) | Detects the length of paper in the drawer. |
| 6. Paper size width switch (PWSW) | Detects the width of paper in the drawer. |
| 7. Bypass paper size width switch (BYPPWSW) | Detects the width of paper on the bypass tray. |
| 8. Scanner home position switch (SHPSW) | Detects the optical system in the home position. |
| 9. Original detection switch (ODSW) | Operates the original size detection sensor. |
| 10. Original size detection sensor (OSDS) | Detects the size of the original. |
| 11. Registration switch (RSW) | Controls the secondary paper feed start timing. |
| 12. Exit switch (ESW) | Detects a paper misfeed in the fixing section. |
| 13. Feedshift switch (FSSW) | Detects a paper misfeed in the switchback section in a duplex copy. |
| 14. Toner container sensor (TCS) | Detects the quantity of toner in a toner container. |
| 15. Toner container detection switch (TCDSW) | Detects the presence of the toner container. |
| 16. Overflow sensor (OFS) | Detects when the waste toner box is full. |
| 17. Fixing thermistor (FTH) | Detects the heat roller temperature. |

- 18. Drawer left cover safety switch
(DLCSSW) Breaks the safety circuit when the drawer left cover is opened.
- 19. Drawer feed switch (DFSW) Detects a paper misfeed.
- 20. Drawer paper switch (DPSW) Detects the presence of paper in the drawer.
- 21. Drawer paper size width switch
(DPWSW) Detects the width of paper in the drawer.
- 22. Drawer paper size length switch
(DPLSW) Detects the length of paper in the drawer.
- 23. Duplex paper conveying switch
(DUPPCSW)* Detects a paper misfeed in the duplex unit.
- 24. Toner empty sensor (TES) Detects the quantity of toner in the developing unit.

*: Optional.

(3) Motors**Figure 2-2-3 Motors**

- | | |
|-------------------------------------|--------------------------------|
| 1. Drive motor (DM) | Drives the machine. |
| 2. Scanner motor (SM) | Drives the optical system. |
| 3. Exit motor (EM) | Drives the exit section. |
| 4. Cooling fan motor 1 (CFM1) | Cools the machine interior. |
| 5. Cooling fan motor 2 (CFM2) | Cools the machine interior. |
| 6. Cooling fan motor 3 (CFM3) | Cools the machine interior. |
| 7. Cooling fan motor 4 (CFM4) | Cools the machine interior. |
| 8. Polygon motor (PM) | Drives the polygon mirror. |
| 9. Registration motor (RM) | Drives the registration roller |
| 10. Drawer drive motor (DDM) | Drives the drawer section. |
| 11. Toner motor (TM) | Agitates toner. |

(4) Other electrical components**Figure 2-2-4 Other electrical components**

- | | |
|---|--|
| 1. Paper feed clutch (PFCL) | Primary paper feed from the drawer. |
| 2. Bypass paper feed solenoid (BYPPFSOL) .. | Primary paper feed from the bypass tray. |
| 3. Exposure lamp (EL) | Exposes originals. |
| 4. Cleaning lamp (CL) | Removes residual charge from the drum surface. |
| 5. Fixing heater M (FH-M) | Heats the heat roller. |
| 6. Fixing heater S (FH-S) | Heats the heat roller. |
| 7. Fixing thermostat (FTS) | Prevents overheating in the fixing section. |
| 8. Drawer heater (DH)* | Dehumidifies the drawer section. |
| 9. Drawer heater (DH) | Dehumidifies the drawer section. |
| 10. Drawer paper feed clutch (DPFCL) | Primary paper feed from the drawer. |
| 11. Duplex feed clutch (DUPFCL)* | Controls the drive of the duplex feed roller. |

*: Optional.

2-3-1 Power source PCB




Figure 2-3-1 Power source PCB block diagram

The power source PCB (PSPCB) is a switching regulator that converts an AC input to generate 24 V DC and 5 V DC. It includes a rectifier circuit, a switching regulator circuit, a 24 V DC output circuit, a 5 V DC output circuit, overvoltage detection circuit, zero-cross circuit and a fixing heater control circuit.

The rectifier circuit full-wave rectifies the AC input using the diode bridge D1. The smoothing capacitor (C5) smoothes out the pulsed current from the diode bridge.

In the switching control circuit, switching circuit turns the power MOSFET (Q1) on and off to switch the voltage induced in the primary coil of the transformer (T1).

The 5 V DC output circuit rectifies and smoothes the voltage induced in the secondary coil of the transformer (T1) via diodes (D102) and smoothing capacitors (C102, C105), and the output is controlled by the overvoltage detection circuit (IC101). For 5 V DC output, the switching circuit of the switching control circuit changes the duty of the switching pulse width of the power MOSFET (Q1) via a photo coupler (PC1) based on the output voltage status to adjust the 5 V DC output.

The 24 V DC output circuit rectifies and smoothes the voltage induced in the secondary coil of the transformer (T1) via diodes (D101) and smoothing capacitors (C101, C104), and the output is controlled by the overvoltage detection circuit (IC101).


The zero-cross circuit detects zero-crossing of the AC input voltage with the AC detection circuit and outputs the zero-cross signal (ZCROSSC) from the zero-cross output circuit through the photo coupler (PC3).

The fixing heater control circuit is divided into the sub-heater output (SH.OUT) and the main heater output (MH.OUT). When the control signals (SHEATN and MHEATN) input from the machine engine side show a low level, this circuit turns on the sub-heater and the main heater respectively by turning on the photo triac couplers (PC2 and PC201) with a zero-cross circuit to turn on the triacs (TRA1 and TR201) in the fixing heater ON/OFF circuit.

The power-saving control circuit performs power-saving control by turning off the 24 V DC output in the 24 V DC output ON/OFF switching circuit and controlling the switching control circuit and the AC detection circuit through the photo coupler (PC4) to decrease the switching frequency, stop the starting circuit in the switching control circuit, and stop the AC detection circuit when the sleep signal (SLEPN) input from the machine engine side is low.

In addition, 5 V DC 3-terminal regulator (IC102) is connected to the back of the 24 V DC output ON/OFF switching circuit to output +5 V1, and this output stops when the sleep signal (SLEPN) is low.

Figure 2-3-2 Power source PCB silk-screen diagram



Connector	Pin No.	Signal	I/O	Description
CN1 Connected to the AC power plug	1	AC-L	I	AC supply (LIVE)
	2	FG	-	Ground
	3	AC-N	I	AC supply (NEUTRAL)
YC1 Connected to the engine PCB and left cover safety switch	1	+24V1	O	24 V DC power supply for LCSSW
	2	NC	-	Not used
	3	+24V2	I	24 V DC power supply (Via LCSSW)
	4	+24V4	O	24 V DC power supply for EPCB (Via LCSSW)
	5	PGND	-	Ground
	6	SGND	-	Ground
	7	+5V	O	5 V DC power supply for EPCB
YC2 Connected to the engine PCB	1	+5V	O	5 V DC power supply for EPCB (Via FCSSW)
	2	SGND	-	Ground
	3	+24V2	O	24 V DC power supply (Via LCSSW)
	4	SGND	-	Ground
	5	ZCROSSC	O	Zero-cross signal
	6	SLEPN	I	Power source sleep signal
	7	SHEATN	I	FH-S on/off
	8	MHEATN	I	FH-M on/off
	9	COUNTN	I	Counter control signal
	10	PGND	-	Ground
	11	PGND	-	Ground
	12	+24V1	O	24 V DC power supply for EPCB
	13	+24V1	O	24 V DC power supply for EPCB
	14	+24V	O	24 V DC power supply for EPCB
YC5 Connected to the front cover safety switch	1	+5V1	O	5 V DC power supply for FCSSW
	2	NC	-	Not used
	3	+5V3	I	5 V DC power supply
YC6 Connected to the fixing heater M/S	1	H.LIVE	O	AC power supply for FH-M/S (LIVE)
	2	MH.OUT	O	AC power supply for FH-M
	3	SH.OUT	O	AC power supply for FH-S
YC7 Connected to the paper feeder	1	DH2.LIVE	O	AC power supply for drawer heater of the paper feeder (LIVE)
	2	NC	-	Not used
	3	NC	-	Not used
	4	DH2.OUT	O	AC power supply for drawer heater of the paper feeder
YC8 Connected to the drawer heater*	1	DH1.LIVE	O	AC power supply for drawer heater (LIVE)
	2	NC	-	Not used
	3	NC	-	Not used
	4	DH1.OUT	O	AC power supply for drawer heater
YC9 Connected to the paper feeder	1	+24V4	O	24 V DC power supply for paper feeder
	2	PGND	-	Ground

*: Optional.

2-3-2 Main PCB




Figure 2-3-3 Main PCB block diagram

The main PCB (MPCB) consists of mainly CPU (U56), program memory flash ROM (U23), work memory SDRAMs (U54, U57), XIO (U49), image processing ASIC (U7), memory copy ASIC (U20), codec IC (U19), AFE (U3), LCD controller (U17), EEPROM (U39), and RTC (U40).




Figure 2-3-4 Main PCB silk-screen diagram

Connector	Pin No.	Signal	I/O	Description
YC1	1	CCDO	I	CCDPCB image scanning signal
Connected to the CCD PCB	2	CCDON	-	Ground
	3	CCDE	I	CCDPCB image scanning signal
	4	CCDEN	-	Ground
	5	+5V	O	5 V DC power supply for CCDPCB
	6	SGND	-	Ground
	7	+12V	O	+12 V DC power supply for CCDPCB
	8	SGND	-	Ground
	9	CCDCLK	O	CCDCLK signal
	10	SGND	-	Ground
	11	CCDCLKN	O	CCDCLKN signal
	12	SGND	-	Ground
	13	RS	O	CCDPCB RS signal
	14	SGND	-	Ground
	15	CP	O	CCDPCB CP signal
	16	SGND	-	Ground
	17	SH	O	CCDPCB SH signal
	18	SGND	-	Ground
YC2	1	PDN	I	Laser sync signal
Connected to the APC PCB	2	SGND	-	Ground
	3	OUTPEN	O	Laser diode output signal
	4	SAMPLEN	O	Laser light signal
	5	VDON	O	Image differential signal (negative)
	6	VDOP	O	Image differential signal (positive)
	7	+5V1	O	5 V DC power supply for APCPCB
YC5	1	SCAN7N	O	Key switch scan signal 7
Connected to the operation unit PCB	2	SCAN6N	O	Key switch scan signal 6
	3	SCAN5N	O	Key switch scan signal 5
	4	SCAN4N	O	Key switch scan signal 4
	5	SCAN3N	O	Key switch scan signal 3
	6	SCAN2N	O	Key switch scan signal 2
	7	SCAN1N	O	Key switch scan signal 1
	8	SCAN0N	O	Key switch scan signal 0
	9	BUZERDRN	O	OPCB buzzer signal
	10	+5V	O	5 V DC power supply for OPCB
	11	SGND	-	Ground
YC6	1	POWERKEYN	I	Power key operating signal input
Connected to the operation unit PCB	2	LED0	O	LED lighting selection signal 0
	3	LED1	O	LED lighting selection signal 1
	4	LED2	O	LED lighting selection signal 2
	5	LED3	O	LED lighting selection signal 3
	6	LED4	O	LED lighting selection signal 4
	7	KEY9	I	Key switch return signal 9
	8	KEY8	I	Key switch return signal 8
	9	KEY7	I	Key switch return signal 7
	10	KEY6	I	Key switch return signal 6
	11	KEY5	I	Key switch return signal 5
	12	KEY4	I	Key switch return signal 4
	13	KEY3	I	Key switch return signal 3
	14	KEY2	I	Key switch return signal 2
	15	KEY1	I	Key switch return signal 1
	16	KEY0	I	Key switch return signal 0

Connector	Pin No.	Signal	I/O	Description
YC7 Connected to the LCD PCB	1	+5VSLEEP	O	5 V DC power supply from LCDPCB
	2	-12V	O	-12 V DC power supply from LCDPCB
	3	LCDUD3	O	LCD display data signal
	4	LCDUD2	O	LCD display data signal
	5	LCDUD1	O	LCD display data signal
	6	LCDUD0	O	LCD display data signal
	7	LCDCP	O	LCD display control signal
	8	LCDFLM	O	LCD display control signal
	9	LCDENB	O	LCD display control signal
	10	LCDLP	O	LCD display control signal
	11	LCDVO	O	LCD display control signal
	12	SGND	-	Ground
	13	LCDGND	-	Ground
YC10 Connected to the printer board PCB	1	+24V	I	24 V DC power supply from PRNPCB
	2	SGND	-	Ground
	3	+12VCCD	I	24 V DC power supply from PRNPCB
	4	E2CSGND	-	Ground
	5	E2CRSTN	I	Reset signal
	6	E2CEGIRN	I	Engine communication E2CEGIRN signal
	7	PDMASKN	I	Printing image interval signal
	8	E2CEGSO	I	Engine serial communication reception
	9	E2CSCKN	O	Engine communication clock signal
	10	+5V	I	5 V DC power supply from PRNPCB
	11	E2CEGSI	O	Engine serial communication transmission
	12	+5V	I	5 V DC power supply from PRNPCB
	13	E2CSBSYN	I	Engine communication E2CSBSYN signal
	14	+3.3V	I	3.3 V DC power supply from PRNPCB
	15	E2CSDIR	I	Engine communication E2CSDIR signal
	16	PLGCLK	O	PM clock signal
	17	OUTEPN	I	Laser diode output signal
	18	PVSYNC	I	Printing image interval signal
	19	OVSYN	I	Original scanning interval signal
	20	+5VAPC	I	5 V DC power supply from PRNPCB
YC11 Connected to the printer board PCB	1	SGND	-	Ground
	2	C2PW_UP_PRTN	I	C2PW_UP_PRTN signal
	3	SGND	-	Ground
	4	C2PW_RST_PRTN	O	C2PW_RST_PRTN signal
	5	SGND	-	Ground
	6	C2PEGIRN	O	Engine communication C2PEGIRN signal
	7	C2PEGSO	O	Engine serial communication transmission
	8	+5V	I	5 V DC power supply from PRNPCB
	9	C2PSCKN	I	Engine communication clock signal
	10	+5V	I	5 V DC power supply from PRNPCB
	11	C2PEGSI	O	Engine serial communication reception
	12	+5V	I	5 V DC power supply from PRNPCB
	13	C2SBSYN	O	Engine communication C2SBSYN signal
	14	+3.3V	I	3.3 V DC power supply from PRNPCB
	15	C2PSDIR	O	Engine communication E2CSDIR signal
	16	PRBDN	O	Laser sync signal
	17	SGND	-	Ground
	18	C2PVIDEO_PRN_N	I	C2PVIDEO_PRN_N signal
	19	C2PVIDEO_PRN_P	I	C2PVIDEO_PRN_P signal
	20	SGND	-	Ground

2-3-3 Engine PCB




Figure 2-3-5 Engine PCB block diagram




Figure 2-3-6 Engine PCB silk-screen diagram

Connector	Pin No.	Signal	I/O	Description
YC1 Connected to the printer board PCB	1	+12V	O	+12 V DC power supply for MPCB
	2	OVSYNC	O	Original scanning interval signal
	3	RSTN	O	Reset signal
	4	EGRN	O	Engine communication EGRN signal
	5	SDIR	O	Engine communication SDIR signal
	6	SBSY	O	Engine communication SBSY signal
	7	PDMASKN	O	Printing image interval signal
	8	EGSI	I	Engine serial communication reception
	9	SCKN	I	Engine communication clock signal
	10	EGSO	O	Engine serial communication transmission
	11	PLGCLK	I	PM clock signal
	12	SGND	-	Ground
	13	OUTEPN	O	Laser diode output signal
	14	+5V	O	5 V DC power supply for MPCB
	15	+5V	O	5 V DC power supply for MPCB
	16	+5V	O	5 V DC power supply for MPCB
	17	SGND	-	Ground
	18	SGND	-	Ground
	19	SGND	-	Ground
	20	+5V1	O	5 V DC power supply for PRNPCB
	21	PGND	-	Ground
	22	+24V	O	24 V DC power supply for PRNPCB
YC3 Connected to the poly- gon motor, cleaning lamp, cool- ing fan motor 1 and overflow sensor	1	PLGCLKN	O	PM clock signal
	2	PLGRDYN	I	PM rotation sync signal
	3	PLGDRN	O	PM on/off
	4	PLGGND	-	Ground
	5	PLG+24V4	O	24 V DC power supply for PM
	6	FAN1DRN	O	CFM1 on/off
	7	+24V1	O	24 V DC power supply for CFM1
	8	TONNEGND	-	Ground
	9	TONFUL	I	OFS on/off
	10	TON+5V2	O	5 V DC power supply for OFS
	11	ERASE+24V4	O	24 V DC power supply for CL
	12	ERASE3N	O	CL on/off (3)
	13	ERASE2N	O	CL on/off (2)
	14	ERASE1N	O	CL on/off (1)
YC4 Connected to the regis- tration motor PCB	1	+5V	O	5 V DC power supply for RM
	2	RMLow	O	RM Low signal
	3	RMCLK	O	RM clock signal
	4	RME NB	O	RM on/off
	5	SGND	-	Ground
YC5 Connected to the fin- isher*/job separator*	1	RLSOLN	I	Finisher/Job separator FSSW (RET) on/off
	2	SLSOLN	I	Finisher/Job separator FSSW (ACT) on/off
	3	SCLK	O	Finisher/Job separator clock signal
	4	SDI	I	Finisher serial communication reception/ Job separator JBESW on/off
	5	SDO	O	Finisher/Job separator serial communication transmission
	6	OPRDY	I	Finisher READY signal/ Job separator EPDSW on/off
	7	OPSEL	O	Finisher SELECT signal
	8	SGND	-	Ground
	9	+5V4	O	5 V DC power supply for Finisher/Job separator
	10	PGND	-	Ground
	11	PGND	-	Ground
	12	+24V4	O	24 V DC power supply for Finisher/Job separator
	13	+24V4	O	24 V DC power supply for Finisher/Job separator

*: Optional.

Connector	Pin No.	Signal	I/O	Description
YC6	1	ORGTIMN	I	DP original scanning interval signal
Connected to the DP*	2	DOPRDY	I	DP READY signal
	3	DOPSEL	O	DP SELECT signal
	4	SGND	-	Ground
	5	DOPCLK	O	DP clock signal
	6	DOPSDI	I	DP serial communication reception
	7	DOPSDO	O	DP serial communication transmission
	8	+5V4	O	5 V DC power supply for DP
	9	PGND	-	Ground
	10	PGND	-	Ground
	11	+24V1	O	24 V DC power supply for DP
	12	+24V1	O	24 V DC power supply for DP
YC7	1	+24V4	O	24 V DC power supply for DM
Connected to the drive motor	2	PGND	-	Ground
	3	SGND	-	Ground
	4	+5V	O	5 V DC power supply for DM
	5	REM	O	DM on/off
	6	RDY	I	DM rotation sync signal
	7	CLK	O	DM clock signal
YC8	1	BPPESW	I	BYPPSW on/off
Connected to the drawer PCB	2	C1PD SWN	I	PSW on/off
	3	FCLTN	O	PFCL on/off
	4	+24V1	O	24 V DC power supply for DPCB
	5	BPSOLN	O	BYPPFCL on/off
	6	ICLTN	O	DUPFCL on/off
	7	IPPSWN	I	DUPPCSW on/off
	8	BPWSW	I	BYPPWSW on/off
	9	REGSWN	I	RSW on/off
	10	TONEPY	I	TCS on/off
	11	SGND	-	Ground
	12	+5V2	O	5 V DC power supply for DPCB
	13	C1PWSWN	I	PWSW on/off
	14	HUMIDC	I	HUMSENS analog signal
	15	HMCLK2	O	HUMSENS clock signal (2)
	16	HMCLK1	O	HUMSENS clock signal (1)
	17	TEMP	I	HUMSENS analog signal
YC9	1	HVCLK	O	Developing bias clock signal
Connected to the high-voltage PCB	2	+5V	O	5 V DC power supply for HVTPCB
	3	SHVISELN	O	Separation high-voltage switch signal
	4	PGND	-	Ground
	5	MHVDRN	O	Main charging high-voltage on/off
	6	PGND	-	Ground
	7	SHVDRN	O	Separation high-voltage on/off
	8	PGND	-	Ground
	9	MHVADJ	O	Main charging high-voltage adjust signal
	10	PGND	-	Ground
	11	THVDRN	O	Transfer high-voltage on/off
	12	+24V4	O	24 V DC power supply for HVTPCB
	13	THVADJ	O	Transfer high-voltage adjust signal
	14	+24V4	O	24 V DC power supply for HVTPCB
	15	PGND	-	Ground
	16	+24V4	O	24 V DC power supply for HVTPCB

*: Optional.

Connector	Pin No.	Signal	I/O	Description
YC10	1	LOPSRDY	I	Paper feeder READY signal
Connected to the paper feeder	2	LOPSEL2	O	Paper feeder SEL2 signal
	3	LOPSEL1	O	Paper feeder SEL1 signal
	4	LOPSEL0	O	Paper feeder SEL0 signal
	5	LOPSCLK	O	Paper feeder clock signal
	6	LOPSDI	I	Paper feeder serial communication reception
	7	LOPSDO	O	Paper feeder serial communication transmission
	8	SGND	-	Ground
	9	+5V2	O	5 V DC power supply for the paper feeder
	10	SGND	-	Ground
	11	+5V2	O	5 V DC power supply for the paper feeder
YC11	1	+24V4	O	24 V DC power supply for CFM2
Connected to the cooling fan motor 2	2	FAN2DRN	O	CFM2 on/off
YC12	1	+24V4	O	24 V DC power supply for CFM3
Connected to the cooling fan motor 3	2	FAN3DRN	O	CFM3 on/off
YC13	1	+24V1	O	24 V DC power supply for key counter
Connected to the key counter*	2	KEYCN	O	Key counter count signal
	3	SGND	-	Ground
	4	KEYENBN	I	Key counter set signal
YC14	1	COMDA	O	EM control signal (A)
Connected to the exit motor	2	COMDNB	O	EM control signal (_B)
	3	COMDNA	O	EM control signal (_A)
	4	COMDB	O	EM control signal (B)
YC15	1	PGND	-	Ground
Connect to the exit switch and feedshift switch	2	EXTSMN	I	ESW on/off
	3	SEPSWN	I	FSSW on/off
	4	+5V2	O	5 V DC power supply for ESW/FSSW
YC16	1	ISMDA	O	SM control signal (A)
Connected to the scanner motor	2	ISMDNB	O	SM control signal (_B)
	3	ISMDNA	O	SM control signal (_A)
	4	ISMDB	O	SM control signal (B)
YC17	1	LAMPN	O	EL on/off
Connected to the inverter PCB	2	PGND	-	Ground
	3	+24V1	O	24 V DC power supply for inverter PCB
	4	+24V1	O	24 V DC power supply for inverter PCB
	5	PGND	-	Ground
	6	LAMPN	O	EL on/off

*: Optional.

Connector	Pin No.	Signal	I/O	Description
YC18	1	+5V2	O	5 V DC power supply for SHPSW
Connected to the original detection switch and scanner home position switch	2	HPSWN	I	SHPSW on/off
	3	SGND	-	Ground
	4	+5V2	O	5 V DC power supply for ODSW
	5	OPSWN	I	ODSW on/off
	6	SGND	-	Ground
YC19	1	+5V2	O	5 V DC power supply for OSDS
Connected to the original size detection sensor	2	ORGLSWN	I	OSDS on/off
	3	SGND	-	Ground
YC20	1	+5 V	I	5 V DC power supply from PSPCB
Connected to the power source PCB	2	SGND	-	Ground
	3	PGND	-	Ground
	4	+24V4	I	24 V DC power supply from PSPCB (Via LCSSW)
YC21	1	+24V	I	24 V DC power supply from PSPCB
Connected to the power source PCB	2	+24V1	I	24 V DC power supply from PSPCB
	3	+24V1	I	24 V DC power supply from PSPCB
	4	PGND	-	Ground
	5	PGND	-	Ground
	6	COUNTN	-	Not used
	7	MHEATN	O	FH-M on/off
	8	SHEATN	O	FH-S on/off
	9	SLEPN	O	Power source sleep signal
	10	ZCROSSC	O	Zero-cross signal
	11	SGND	-	Ground
	12	+24V2	I	24 V DC power supply from PSPCB (Via LCSSW)
	13	SGND	-	Ground
	14	+5V3	I	24 V DC power supply from PSPCB (Via LCSSW)
YC22	1	C1PLSW3N	I	PLSW on/off
Connected to the paper size length switch and toner container detection switch	2	C1PLSW2N	I	PLSW on/off
	3	SGND	-	Ground
	4	C1PLSW1N	I	PLSW on/off
	5	TCONDET	I	TCDSW on/off
	6	SGND	-	Ground
YC23	1	FUFMLTN	O	FUSE signal
Connected to the fixing PCB, drum PCB and developing PCB	2	THERMA	I	FTH detection voltage
	3	THERMA+5V	O	5 V DC power supply for FTH
	4	+5V	O	5 V DC power supply for DRPCB
	5	IUID2SCL	O	DRPCB clock signal
	6	IUIDSDA	O	DRPCB data signal
	7	SGND	-	Ground
	8	IUID2DET	I	Drum unit detection signal
	9	+5V	O	5 V DC power supply for DVPCB
	10	IUID1SCL	O	DVPCB clock signal
	11	IUIDSDA	O	DVPCB data signal
	12	SGND	-	Ground
	13	IUID1DET	I	Developing unit detection signal

Connector	Pin No.	Signal	I/O	Description
YC24	1	+24V4	O	24 V DC power supply for RMPCB
Connected to the registration motor PCB	2	SGND	-	Ground
YC25	1	+24V4	O	24 V DC power supply for CFM4
Connected to the cooling fan motor 4	2	FAN4DRN	O	CFM4 on/off
YC26	1	+24V4	O	24 V DC power supply for TM
Connected to the toner motor	2	TONESOLDRN	O	TM on/off
YC27	1	DEVDETGND	-	Ground
Connected to the toner empty sensor	2	DEVDETN	I	TES On/Off
	3	DEVDET+5V	O	5 V DC power supply for TES

2-3-4 Printer board PCB




Figure 2-3-7 Printer board PCB block diagram




Figure 2-3-8 Printer board PCB silk-screen diagram

Connector	Pin No.	Signal	I/O	Description
YC6 Connected to the engine PCB	1	+12V	I	+12 V DC power supply from EPCB
	2	OVSYNC	I	Original scanning interval signal
	3	RSTN	I	Reset signal
	4	EGRN	I	Engine communication EGRN signal
	5	SDIR	I	Engine communication SDIR signal
	6	SBSY	I	Engine communication SBSY signal
	7	PDMASKN	I	Printing image interval signal
	8	EGSI	O	Engine serial communication transmission
	9	SCKN	O	Engine communication clock signal
	10	EGSO	I	Engine serial communication reception
	11	PLGCLK	O	PM clock signal
	12	SGND	-	Ground
	13	OUTEPN	I	Laser diode output signal
	14	+5V	I	5 V DC power supply from EPCB
	15	+5V	I	5 V DC power supply from EPCB
	16	+5V	I	5 V DC power supply from EPCB
	17	SGND	-	Ground
	18	SGND	-	Ground
	19	SGND	-	Ground
	20	+5V1	I	5 V DC power supply from EPCB
	21	PGND	-	Ground
	22	+24V	I	24 V DC power supply from EPCB
YC7 Connected to the main PCB	1	+24V	O	24 V DC power supply for MPCB
	2	SGND	-	Ground
	3	+12VCCD	O	+12 V DC power supply for MPCB
	4	E2CSGND	-	Ground
	5	E2CRSTN	O	Reset signal
	6	E2CEGIRN	O	Engine communication E2CEGIRN signal
	7	PDMASKN	O	Printing image interval signal
	8	E2CEGSO	O	Engine serial communication transmission
	9	E2CSCKN	I	Engine communication clock signal
	10	+5V	O	5 V DC power supply for MPCB
	11	E2CEGSI	I	Engine serial communication reception
	12	+5V	O	5 V DC power supply for MPCB
	13	E2CSBSYN	O	Engine communication E2CSBSYN signal
	14	+3.3V	O	3.3 V DC power supply for MPCB
	15	E2CSDIR	O	Engine communication E2CSDIR signal
	16	PLGCLK	I	PM clock signal
	17	OUTEPN	O	Laser diode output signal
	18	PVSYNC	O	Printing image interval signal
	19	OVSYNC	O	Original scanning interval signal
	20	+5VAPC	O	5 V DC power supply for MPCB

Connector	Pin No.	Signal	I/O	Description
YC8	1	SGND	-	Ground
Connected to the main PCB	2	C2PW_UP_PRTN	O	C2PW_UP_PRTN signal
	3	SGND	-	Ground
	4	C2PW_RST_PRTN	I	C2PW_RST_PRTN signal
	5	SGND	-	Ground
	6	C2PEGIRN	I	Engine communication C2PEGIRN signal
	7	C2PEGSO	I	Engine serial communication reception
	8	+5V	O	5 V DC power supply for MPCB
	9	C2PSCKN	O	Engine communication clock signal
	10	+5V	O	5 V DC power supply for MPCB
	11	C2PEGSi	I	Engine serial communication transmission
	12	+5V	O	5 V DC power supply for MPCB
	13	C2SBSYN	I	Engine communication C2SBSYN signal
	14	+3.3V	O	3.3 V DC power supply from PRNPCB
	15	C2PSDIR	I	Engine communication E2CSDIR signal
	16	PRBDN	I	Laser sync signal
	17	SGND	-	Ground
	18	C2PVIDEO_PRN_N	O	C2PVIDEO_PRN_N signal
	19	C2PVIDEO_PRN_P	O	C2PVIDEO_PRN_P signal
	20	SGND	-	Ground

2-3-5 Operation unit PCB





Figure 2-3-9 Operation unit PCB block diagram


The operation unit PCB (OPPCB) consists of key switches, LEDs and buzzer. The lighting of LEDs is determined by scan signals (SCAN0 to SCAN7) and LED lighting selection signals (LED0 to LED4) from the main PCB (MPCB). The key switches operated are identified by the scan signals (SCAN0 to SCAN7) and the return signals (KEY0 to KEY9).

As an example, to light L1, the LED lighting selection signal (LED4) should be driven low in synchronization with a low level on the scan signal (SCAN0). LEDs can be lit dynamically by repeating such operations.

As another example, if K1 is pressed, the corresponding key switch is turned on feeding the low level of the scan signal (SCAN0) back to the main PCB (MPCB) via the return signal (KEY9). The main PCB (MPCB) locates the position where the line outputting the scan signal and the line inputting the return signal cross, and thereby determines which key switch was operated.



Connector	Pin No.	Signal	I/O	Description
YC1	1	SGND	-	Ground
Connected to the main PCB	2	+5V	I	5 V DC power supply from MPCB
	3	BUZERDRN	I	OPCB buzzer signal
	4	SCAN0N	I	Key switch scan signal 0
	5	SCAN1N	I	Key switch scan signal 1
	6	SCAN2N	I	Key switch scan signal 2
	7	SCAN3N	I	Key switch scan signal 3
	8	SCAN4N	I	Key switch scan signal 4
	9	SCAN5N	I	Key switch scan signal 5
	10	SCAN6N	I	Key switch scan signal 6
	11	SCAN7N	I	Key switch scan signal 7
YC2	1	KEY0	O	Key switch return signal 0
Connected to the main PCB	2	KEY1	O	Key switch return signal 1
	3	KEY2	O	Key switch return signal 2
	4	KEY3	O	Key switch return signal 3
	5	KEY4	O	Key switch return signal 4
	6	KEY5	O	Key switch return signal 5
	7	KEY6	O	Key switch return signal 6
	8	KEY7	O	Key switch return signal 7
	9	KEY8	O	Key switch return signal 8
	10	KEY9	O	Key switch return signal 9
	11	LED4	I	LED lighting selection signal 4
	12	LED3	I	LED lighting selection signal 3
	13	LED2	I	LED lighting selection signal 2
	14	LED1	I	LED lighting selection signal 1
	15	LED0	I	LED lighting selection signal 0
	16	POWERKEYN	O	Power key operating output signal

2-3-6 CCD PCB**Figure 2-3-11 CCD PCB block diagram**

The CCD PCB (CCDPCB) is equipped with a CCD sensor (U2) for original scanning. The clock signals for driving the CCD sensor (U2) are sent from the main PCB (MPCB), and then input to the CCD sensor (U2) via the clock drivers (U1 and U3). Image signals are analog signals. Even- and odd-numbered pixels are output separately. These analog image signals are amplified in the transistors (TR1 to 4) and then transmitted to the analog signal processing circuit in the main PCB (MPCB).






Figure 2-3-12 CCD PCB silk-screen diagram

Connector	Pin No.	Signal	I/O	Description
YC1	1	SGND	-	Ground
Connected to the main PCB	2	SH	I	MPCB SH signal
	3	SGND	-	Ground
	4	CP	I	MPCB CP signal
	5	SGND	-	Ground
	6	RS	I	MPCB RS signal
	7	SGND	-	Ground
	8	CCDCLKN	I	CCDCLKN signal
	9	SGND	-	Ground
	10	CCDCLK	I	CCDCLK signal
	11	SGND	-	Ground
	12	+12V	I	+12 V DC power supply from MPCB
	13	SGND	-	Ground
	14	+5V	I	5 V DC power supply from MPCB
	15	CCDEN	-	Ground
	16	CCDE	O	CCDPCB image scanning signal
	17	CCDON	-	Ground
	18	CCDO	O	CCDPCB image scanning signal


Timing chart No.1 Paper feed from drawer, single-side mode, original size A4/11" x 8 1/2", two sheets



Timing chart No.2 Paper feed from first paper feeder, single-side mode, original sizeA4/11" x 8 1/2", two sheets



Timing chart No.3 Paper feed from second paper feeder (optional), single-side mode, original size A4/11" x 8 1/2", two sheets



Timing chart No.4 Paper feed from third paper feeder (optional), single-side mode, original size A4/11" x 8 1/2" , two sheets




















Chart of image adjustment procedures

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Display			
①	Adjusting the magnification in the main scanning direction (printing adjustment)		Polygon motor speed adjustment	U053	POLY	U053 test pattern	1-4-13	
②	Adjusting the magnification in the auxiliary scanning direction (printing adjustment)		Drive motor speed adjustment	U053	MAIN	U053 test pattern	1-4-13	
③	Adjusting the center line of the bypass tray (printing adjustment)		Adjusting the LSU print start timing	U034	LSU BYP	U034 test pattern	1-6-18	
④	Adjusting the center line of the drawers (printing adjustment)		Adjusting the LSU print start timing	U034	LSU OUT	U034 test pattern	1-6-18	First paper feeder: select LSU T1 Second paper feeder: select LSU T2 Third paper feeder: select LSU T3 Duplex copying: select LSU DUP
⑤	Adjusting the leading edge registration of the bypass tray (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	RCL BYP	U034 test pattern	1-6-16	
⑥	Adjusting the leading edge registration of the drawer (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	RCL ON	U034 test pattern	1-6-16	First paper feeder: select RCL T1 Second paper feeder: select RCL T2 Third paper feeder: select RCL T3 Duplex copying: select RCL DUP
⑦	Adjusting the leading edge margin (printing adjustment)		LSU illumination start timing	U402	LEAD	U402 test pattern	1-6-20	
⑧	Adjusting the trailing edge margin (printing adjustment)		LSU illumination end timing	U402	TRAIL	U402 test pattern	1-6-20	

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Display			
⑨	Adjusting the left and right margins (printing adjustment)		LSU illumination start/end timing	U402	AC	U402 test pattern	1-6-20	
⑩	Adjusting magnification of the scanner in the main scanning direction (scanning adjustment)		Data processing	U065	MAIN SCAN ADJ	Test chart	1-6-33	No adjustment for copying using the DP.
⑪	Adjusting magnification of the scanner in the auxiliary scanning direction (scanning adjustment)		Original scanning speed	U065 U070	SUB SCAN ADJ	Test chart	1-6-34 1-4-16	U065: For copying an original placed on the contact glass. U070: For copying originals from the DP.
⑫	Adjusting the center line (scanning adjustment)		Adjusting the original scan data (image adjustment)	U067 U072	— —	Test chart	1-6-36 1-4-18	U067: For copying an original placed on the contact glass. U072: For copying originals from the DP.
⑬	Adjusting the leading edge registration (scanning adjustment)		Original scan start timing	U066 U071	— —	Test chart	1-6-35 1-4-17	U066: For copying an original placed on the contact glass. U071: For copying originals from the DP.
⑭	Adjusting the leading edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403 U404	B MARGIN B MARGIN	Test chart	1-6-37 1-4-45	U403: For copying an original placed on the contact glass. U404: For copying originals from the DP.
⑮	Adjusting the trailing edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403 U404	D MARGIN D MARGIN	Test chart	1-6-37 1-4-45	U403: For copying an original placed on the contact glass. U404: For copying originals from the DP.
⑯	Adjusting the left and right margins (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403 U404	A/C MARGIN A/C MARGIN	Test chart	1-6-37 1-4-45	U403: For copying an original placed on the contact glass. U404: For copying originals from the DP.

When maintenance item U092 (Adjusting the scanner automatically) is run using the specified original (P/N 2A068021), the following adjustments are automatically made:

- Adjusting the scanner center line (U067)
- Adjusting the scanner magnification in the main scanning direction (U065)
- Adjusting the scanner leading edge registration (U066)
- Adjusting the scanner magnification in the auxiliary scanning direction (U065)

When maintenance item U076 (Adjusting the DP automatically) is run using the specified original (P/N 2A068021), the following adjustments are automatically made:

- Adjusting the DP magnification (U070)
- Adjusting the DP scanning timing (U071)
- Adjusting the DP center line (U072)

Image quality

Item	Specifications
100% magnification	Copier: $\pm 1.0\%$ Using DP: $\pm 1.5\%$
Enlargement/reduction	Copier: $\pm 1.0\%$ Using DP: $\pm 1.5\%$
Lateral squareness	Copier: $\pm 1.5\text{ mm}/375\text{ mm}$ Using DP: $\pm 3.0\text{ mm}/375\text{ mm}$
Margins	A: $3.0 \pm 2.5\text{ mm}$ B: $3.0 \pm 2.5\text{ mm}$ C: $3.0 \pm 2.5\text{ mm}$ D: $3.0 \pm 2.5\text{ mm}$
Leading edge registration	Drawer: $\pm 2.5\text{ mm}$ Bypass: $\pm 2.5\text{ mm}$
Skewed paper feed (left-right difference)	Duplex copying: $\pm 2.5\text{ mm}$ Drawer: 1.5 mm or less Bypass: 1.5 mm or less
Lateral image shifting	Duplex copying: 2.0 mm or less Drawer: $\pm 2.0\text{ mm}$ Bypass: $\pm 2.0\text{ mm}$ Duplex copying: $\pm 3.0\text{ mm}$

Maintenance parts list

Maintenance part name		Part No.	Alternative part No.	Fig. No.	Ref. No.
Name used in service manual	Name used in parts list				
Paper feed pulley	PULLEY, PAPER FEED	2AR07220		7	39
Separation pulley	PULLEY, SEPARATION	2AR07230		7	40
Forwarding pulley	PULLEY, LEADING FEED	2AR07240		7	41
Drawer paper feed pulley	PULLEY, PAPER FEED	2AR07220		4	16
Drawer separation pulley	PULLEY, SEPARATION	2AR07230		4	17
Drawer forwarding pulley	PULLEY, LEADING FEED	2AR07240		4	18
Bypass paper feed pulley	PARTS, BYPASS PULLEY, SP	2C993130		8	19
Bypass separation pad	PARTS, BYPASS PAD, SP	2C993140		8	15
Left registration roller	ROLLER REGIST LEFT	2C916020		6	1
Right registration roller	RIGHT ROLL REGIST	2C907180		7	9
Registration cleaner	PARTS, REGIST CLEANER, ASSY	2C993210		7	27
Feed roller	ROLLER FEED	3HW06020		4	3
Feed pulley	PULLEY FEED	2BL16080		3	24
Slit glass	CONTACT GLASS ADF	2C912280		10	27
Contact glass	CONTACT GLASS	2C912250		10	24
Mirror 1	MIRROR A	2C912390		10	37
Mirror 2 and mirror 3	MIRROR B	2AV12160		10	4
Lens	LENS	2C912500		-	-
Reflector	REFLECTOR SCANNER	2C912110		10	12
Exposure lamp	LAMP SCANNER YG	2FT12010		10	10
Front scanner rail	FRONT RAIL SCANNER	2C912070		-	-
Rear scanner rail	REAR RAIL SCANNER	2C912080		-	-
Original size detection sensor	SENSOR ORIGINAL	2C912090		10	55
Laser scanner unit	PARTS, LK-420, SP	302FT93070	2FT93070	14	1
Transfer roller	ROLLER TRANSFER	2FT17010		6	37
Separation electrode	PLATE STA ELIMINATION	2FT17030		6	28
Developing unit	PARTS, DV-420, SP	302FT93050	2FT93050	11	1
Drum unit	PARTS, DK-420, SP	302FT93041	2FT93041	11	5
Fixing unit	PARTS, FK-420(A), SP	302FT93021	2FT93021	12	1
Fixing unit	PARTS, FK-420(E), SP	302FT93031	2FT93031	12	1
Heat roller	ROLLER HEAT	302FT20011	2FT20011	12	26
Press roller	ROLLER PRESS	2C920060		12	6
Heat roller separation claw	SEPARATOR ASSY B	302FT20160	2FT20160	12	24
Exit roller	ROLLER EXIT INNER	2C921010		9	17
Exit pulley	PULLEY EJECT	2C921360		9	46
Switchback roller	ROLLER FEED SHIFT	2C921020		9	18
Switchback pulley	PULLEY FEED SHIFT	2C921040		9	19

Periodic maintenance procedures

Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Test copy and test print	Perform at the maximum copy size	Test copy	Every service		



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Paper feed section	Paper feed pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-5
	Separation pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-3
	Forwarding pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-5
	Drawer paper feed pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-9
	Drawer separation pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-8
	Drawer forwarding pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-9
	Bypass paper feed pulley	Clean or replace	Every 300,000 counts	Clean with the alcohol.	1-6-13
	Bypass separation pad	Clean or replace	-	Clean with the alcohol.	1-6-13
	Left registration roller	Clean or replace	Every 300,000 counts	Clean with alcohol or a dry cloth.	1-6-15
	Right registration roller	Clean	Every 300,000 counts	Clean with alcohol or a dry cloth.	
	Registration cleaner	Clean or replace	Every 300,000 counts	Vacuum.	1-6-15
	Feed roller	Clean or replace	-	Clean with the alcohol.	1-6-7
	Feed pulley	Clean or replace	-	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Optical section	Slit glass	Clean	Every 300,000 counts	Clean with a dry cloth.	1-6-22
	Contact glass	Clean	Every 300,000 counts	Clean with alcohol and then a dry cloth.	
	Mirror 1	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Mirror 2 and mirror 3	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Lens	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Reflector	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Exposure lamp	Clean or replace	-	Replace if an image problem occurs or after the exposure lamp does not turn on.	
	Optical rail	Grease	-	Check noise and shifting and then apply scanner rail grease EM-50L..	
	Original size detection sensor	Clean	-	Clean with alcohol or a dry cloth.	
	Laser scanner unit	Clean	Every 300,000 counts	Clean with alcohol.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Transfer and separation section	Transfer roller	Clean	Every 300,000 counts	Vaccum or clean with a dry cloth.	1-6-42
	Separation electrode	Check or clean	Every 300,000 counts	Clean with the equipped brush.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Developing section	Developing unit	Check or replace	Every 300,000 counts	Replace if the problem occurs.	1-6-41



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Drum section	Drum unit	Check or replace	Every 300,000 counts	Replace if the problem occurs.	1-6-38
	Ozone filter	Clean	Every 300,000 counts	Vaccum.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Fixing section	Fixing unit	Check or replace	Every 300,000 counts	Replace if the problem occurs.	1-6-43
	Heat roller	Clean	Every 300,000 counts	Clean with alcohol or a dry cloth.	1-6-48
	Press roller	Clean	Every 300,000 counts	Clean with alcohol or a dry cloth.	1-6-45
	Heat roller separation claw	Clean or replace	Every 300,000 counts	Clean with alcohol. Replace if it is being lacking, deformed or rubbing.	1-6-47




Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Exit section	Exit roller	Check or clean	Every 300,000 counts	Clean with alcohol.	
	Exit pulley	Check or clean	Every 300,000 counts	Clean with alcohol.	
	Switchback roller	Check or clean	Every 300,000 counts	Clean with alcohol.	
	Switchback pulley	Check or clean	Every 300,000 counts	Clean with alcohol.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Covers	Covers	Clean	Every 300,000 counts	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Other	Image quality	Check and adjust	Every service		



KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: +31.(0)20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.

Hoeksteen 40 2132 MS Hoofddorp,
The Netherlands
Phone: +31.(0)20.587.7200

KYOCERA MITA (UK) LTD.

8 Beacontree Plaza
Gillette Way, Reading Berks RG2 0BS,
UK
Phone: +44.(0)118.931.1500

KYOCERA MITA ITALIA S.P.A.

Via Verdi 89 / 91 20063 Cernusco sul Naviglio,
(Milano), Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.

Hermesstraat 8A 1930 Zaventem,
Belgium
Phone: +32.(0)2.720.9270

KYOCERA MITA FRANCE S.A.

Parc Les Algorithmes, Saint Aubin
91194 GIF-SUR-YVETTE,
France
Phone: +33.(0)1.6985.2600

KYOCERA MITA ESPAÑA S.A.

Edificio Kyocera, Avda de Manacor N. 2,
Urb. Parque Rozas 28290 Las Rozas, Madrid,
Spain
Phone: +34.(0)91.631.8392

KYOCERA MITA FINLAND OY

Kirvesmiehenkatu 4 00810 Helsinki,
Finland
Phone: +358.(0)9.4780.5200

KYOCERA MITA (SCHWEIZ) AG

Industriestrasse 28, 8604 Volketswil,
Switzerland
Phone: +41.(0)1.908.4949

KYOCERA MITA DEUTSCHLAND GMBH

Mollsfeld 12-40670 Meerbusch,
Germany
Phone: +49.(0)2159.918.0

KYOCERA MITA GMBH AUSTRIA

Eduard-Kittenberger Gasse 95
A-1230 Wien,
Austria
Phone: +43.(0)1.86338.401

KYOCERA MITA SVENSKA AB

Vretenragen 2, 6tr 171 54 Solna,
Sweden
Phone: +46.(0)8.546.550.00

KYOCERA MITA NORGE

Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvet 6, NO 0694 Oslo,
Norway
Phone: +47.(0)22.62.73.00

KYOCERA MITA DANMARK A/S

Slotsmarken 11, 2 DK-2970 Hørsholm,
Denmark
Phone: +45.7022.3880

KYOCERA MITA PORTUGAL LDA.

Rua do Centro Cultural, no 41 1700-106 Lisbon,
Portugal
Phone: +351.(0)21.843.6780

KYOCERA MITA SOUTH AFRICA (PTY) LTD.

527 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.

Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.

1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.

9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.

121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED

11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN Corporation.

7F-1 ~2, No.41, Lane 221, Gangchi Rd.
Neihu District, Taipei, Taiwan, 114. R.O.C.
Phone: (02) 87511560

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>