



TASKalfa 1800

TASKalfa 1801

TASKalfa 2200

TASKalfa 2201

PARTS LIST

Published in June 2014
2NNPL074
842NN124
Rev.4

— CONTENTS —

FIG. 1	Covers	2
FIG. 2	Frames 1	4
FIG. 3	Frames 2	6
FIG. 4	Paper Cassette	8
FIG. 5	Paper Feed Section 1	10
FIG. 6	Paper Feed Section 2	12
FIG. 7	Paper Conveying Section 1	14
FIG. 8	Paper Conveying Section 2	16
FIG. 9	Scanner Section	18
FIG. 10	Laser Scanner Section	20
FIG. 11	Developer Section	22
FIG. 12	Image Formation Section	24
FIG. 13	Fuser Section	26
FIG. 14	Drive Section	28
FIG. 15	Electrical Components	30
FIG. 16	Operation Section(18ppm/22ppm)	32
FIG. 16	Operation Section(18ppm(F)/22ppm(F))	34
FIG. 17	Options	36
FIG. 18	Accessories	38
	• INDEX	40

<Notation of products>

For the purpose of this parts list, products are identified as following.

TASKalfa 1800 : 18ppm


TASKalfa 1801 : 18ppm(F)

TASKalfa 2200 : 22ppm

TASKalfa 2201 : 22ppm(F)

FIG. 1 Covers


2NC/2NF/2NG/2NN-4



2NC/2NF/2NG/2NN-4

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.




2NC/2NF/2NG/2NN-4

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.

FIG. 3 Frames 2


2NC/2NF/2NG/2NN-1



2NC/2NF/2NG/2NN-1

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with ". ." appearing immediately above them.



2NC/2NF/2NG/2NN

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with ". ." appearing immediately above them.




FIG. 5 Paper Feed Section 1

2NC/2NF/2NG/2NN-4

Ref. No.	Part.No.	Alternative.	Description	Notes	Quantity		
					120	230	240
1	302HN02611	2HN02611	FOOT		2	2	2
2	303M894260	3M894260	PARTS SENSOR OPT SP		1	1	1
3	302NG46260	2NG46260	WIRE MPF		1	1	1
4	302NG08170	2NG08170	ACTUATOR MPF		1	1	1
5	302NG08330	2NG08330	SPRING ACTUATOR MPF		1	1	1
6	302NG08140	2NG08140	PLATE LIFT MPF		1	1	1
7	302NG08130	2NG08130	ARM LIFT MPF		1	1	1
8	302NG08190	2NG08190	JOINT LIFT MPF		1	1	1
9	302NG08150	2NG08150	SPRING LIFT MPF		2	2	2
10	302NG08250	2NG08250	BUSH 8		2	2	2
11	302NG08240	2NG08240	SHAFT MPF		1	1	1
12	302NG08280	2NG08280	PIN FEED ROLLER		1	1	1
13	302NG08320	2NG08320	SPRING MPF ROLLER		1	1	1
14	302NG94130	2NG94130	PARTS ROLLER MPF SP		1	1	1
15	302NG08210	2NG08210	GUIDE UPPER MPF		1	1	1
16	302NG94021	2NG94021	PARTS PRIMARY FEED ASSY SP		1	1	1
17	302NG06200	2NG06200	HOLDER RETARD		1	1	1
18	302NG94110	2NG94110	PARTS ROLLER RETARD ASSY SP		1	1	1
19	302NG06020	2NG06020	FRAME FEED LOW A		1	1	1
20	302K306070	2K306070	SPRING SEPARATION		1	1	1
21	302NG06030	2NG06030	FRAME FEED LOW B		1	1	1
22	302NG06210	2NG06210	SHEET FEED A		1	1	1
23	302NG06011	2NG06011	FRAME FEED UP		1	1	1
24	302K331230	2K331230	BUSH DRIVE 8		1	1	1
25	302NG06040	2NG06040	SHAFT DRIVE FEED		1	1	1
26	302NG06090	2NG06090	GUIDE FEED SIDE R		1	1	1
27	302NG06060	2NG06060	GUIDE FEED SIDE F		1	1	1
28	302NG06170	2NG06170	HOLDER PULLEY		1	1	1
29	2C907410	2C907410	PULLEY GUIDE A		1	1	1
30	302NG06100	2NG06100	GUIDE FEED UP		1	1	1
31	302NG06050	2NG06050	HOLDER FEED		1	1	1
32	302NG06180	2NG06180	GEAR FEED Z27		1	1	1
33	302NG06110	2NG06110	SHAFT FEED L		1	1	1
34	302NG06190	2NG06190	GEAR FEED Z32		1	1	1
35	2F906230	2F906230	PULLEY FEED ASSY		1	1	1
36	302K306460	2K306460	BUSH 4		1	1	1
37	302NG06140	2NG06140	SHAFT PICKUP		1	1	1
38	302NG94120	2NG94120	PARTS PULLEY PICKUP ASSY SP		1	1	1
39	302NG06130	2NG06130	SPRING PICKUP		2	2	2
40	302NG08230	2NG08230	SPRING SEPARATION		1	1	1
41	302NG94380	2NG94380	PARTS PAD SEPARATION ASSY SP		1	1	1
	302NG08310	2NG08310	MOUNT SEPARATION		1	1	1
101	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR				
102	7BB200308H	BB105660	+BIND T.T P SCREW 3X8				
103	7BB702308H	BB107060	+TP-FLAT T.T S SCREW 3X8 SR				


•Parts with "⊙" indicate regular maintenance parts.

•Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.

•The (F) designation references Specific Products. Please see Page 1 for details.

•Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.


•Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.



2NC/2NF/2NG/2NN-4

- Parts with "☉" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.



2NC/2NF/2NG/2NN-1

- Parts with "☉" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.




FIG. 8 Paper Conveying Section 2

2NC/2NF/2NG/2NN

Ref. No.	Part.No.	Alternative.	Description	Notes	Quantity		
					120	230	240
	1	302NG24320	2NG24320	GUIDE TRANSFER RIGHT	1	1	1
	2	302K324230	2K324230	SPRING GUIDE TRANSFER	2	2	2
⊙	3	302K324170	2K324170	GEAR TRANSFER Z18L	1	1	1
	4	302NG24350	2NG24350	COLLAR ROLLER	3	3	3
⊙	5	302NG94150	2NG94150	PARTS ROLLER TRANSFER SP		1	1
⊙	5	302NG94160	2NG94160	PARTS ROLLER TRANSFER U SP	1		
	6	302NG24390	2NG24390	ARM TRANSFER F	1	1	1
	7	302NG24400	2NG24400	ARM TRANSFER R	1	1	1
	8	302K324430	2K324430	BUSH TRANSFER ROLL R	1	1	1
	9	302NG24370	2NG24370	SPRING TRANSFER R	1	1	1
	10	302K324240	2K324240	BUSH TRANSFER ROLL F	1	1	1
	11	302NG24380	2NG24380	SPRING TRANSFER F	1	1	1
	12	302NG24330	2NG24330	HOLDER SEPARATION	1	1	1
	13	302NG24340	2NG24340	PLATE SEPARATION	1	1	1
	14	302NG24130	2NG24130	TERMINAL SEPARATION	1	1	1
	15	302NG24150	2NG24150	TERMINAL TRANSFER	1	1	1
	16	302NG24120	2NG24120	SHEET REGIST RIGHT F	1	1	1
	17	302NG24140	2NG24140	SHEET REGIST RIGHT R	1	1	1
	18	302NG24160	2NG24160	SHEET DU	1	1	1
	19	302K324200	2K324200	SPRING REGIST F	1	1	1
	20	302K324440	2K324440	SPRING REGIST R	1	1	1
⊙	21	302NG24110	2NG24110	GEAR REGIST R Z17R	1	1	1
	22	302K324180	2K324180	BUSH REGIST F	1	1	1
	23	302K324270	2K324270	BUSH REGIST R	1	1	1
	24	302NG24100	2NG24100	BUSH REGIST C	1	1	1
	25	302NG24080	2NG24080	SPRING REGIST C	1	1	1
⊙	26	302NG94140	2NG94140	PARTS ROLLER REGIST RIGHT SP	1	1	1
	27	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	2	2	2
	28	302NG34090	2NG34090	LABEL A2	1	1	1
	29	302K329030	2K329030	SPRING DU FEED	2	2	2
	30	302NG29010	2NG29010	GUIDE DU	1	1	1
	31	302K329020	2K329020	PULLEY DU	3	3	3
	32	302NG24040	2NG24040	LEVER CONVEYING R	1	1	1
	33	302K324360	2K324360	SPRING CONVEYING R	1	1	1
	34	302NG24030	2NG24030	LEVER CONVEYING F	1	1	1
	35	302K324110	2K324110	SPRING CONVEYING F	1	1	1
	36	302NG24010	2NG24010	BASE CONVEYING	1	1	1
	37	302NG24050	2NG24050	GUIDE CONVEYING	1	1	1
	38	302NG24090	2NG24090	SPRING EARTH CONVEYING	1	1	1
	39	302K304550	2K304550	SHAFT RIGHT COVER F	1	1	1
	40	302K304630	2K304630	FILM CONVEYING SHAFT	1	1	1
	41	302NG04590	2NG04590	SHAFT RIGHT COVER R	1	1	1

•Parts with "⊙" indicate regular maintenance parts.

•Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.

•The (F) designation references Specific Products. Please see Page 1 for details.

•Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

•Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.





FIG. 9 Scanner Section

2NC/2NF/2NG/2NN-4

[illegible]

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.


- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with ". ." appearing immediately above them.



2NC/2NF/2NG/2NN-4

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.



2NC/2NF/2NG/2NN

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.





FIG. 12 Image Formation Section

2NC/2NF/2NG/2NN-4

[illegible]

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.


- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.



2NC/2NF/2NG/2NN

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.


- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.



2NC/2NF/2NG/2NN

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.



2NC/2NF/2NG/2NN-2

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.




FIG. 16 Operation Section(18ppm/22ppm)

2NC/2NF/2NG/2NN-2


[illegible]

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.

FIG. 16 Operation Section(18ppm(F)/22ppm(F))

2NC/2NF/2NG/2NN-2



2NC/2NF/2NG/2NN-2

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.




FIG. 17 Options

2NC/2NF/2NG/2NN-4

[illegible]

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.




FIG. 18 Accessories

2NC/2NF/2NG/2NN-4

[illegible]

- Parts with "⊙" indicate regular maintenance parts.
- Parts with Ref.No. indicate maintenance parts and the ones without it indicate out of the above.
- The (F) designation references Specific Products. Please see Page 1 for details.

- Parts with "." are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with ". ." are component parts or sub-assembly with "." appearing immediately above them.

INDEX

2NC/2NF/2NG/2NN-4

	Part.No.	Alternative.	Description	Fig.No.
⊙	1202NG0UN0	022NG0UN	PLATEN COVER TYPE H	17
	1702NG0UN0	072NG0UN	MK-4105/MAINTENANCE KIT	12
	2BC06910	2BC06910	STOPPER 6	6
	2BC06980	2BC06980	STOPPER 5	7
	2BL04200	2BL04200	LEVER CONT RELEASE	1
⊙	2C906080	2C906080	GEAR 18 BYPASS	7
	2C907100	2C907100	STOPPER CASSETTE	2
	2C907140	2C907140	PAD CASSETTE	4
	2C907410	2C907410	PULLEY GUIDE A	5
	2DC12280	2DC12280	STOPPER 8	7
	2FB07330	2FB07330	STOPPER BYPASS TABLE	7
	2FB20860	2FB20860	PIN FUSER COVER	3,9
	3019527401	19527401	POWER CORD(120)	3
	302AR94050	2AR94050	PARTS AC CORD EU SP	3
⊙	302BM07410	2BM07410	GEAR GUIDE SIDE	4
⊙	302F906230	2F906230	PULLEY FEED ASSY	5
	302F914130	2F914130	BUSH GEAR	3
	302F929140	2F929140	BUSH DU	13
⊙	302F944131	2F944131	MOTOR EJECT	14
	302FB17700	2FB17700	SPRING BYPASS TEBLE	7
	302GR25161	2GR25161	PIN LOWER FRAME	2
	302H002130	2H002130	PLATE POSITION A	2
	302H008140	2H008140	SPRING BYPASSFFED	3
	302H024360	2H024360	BUSH 8 EW	6
	302H024830	2H024830	BUSH 8	6
	302HN02611	2HN02611	FOOT	2,5
	302HN25450	2HN25450	BUSH EXIT	13
	302HN31650	2HN31650	SPRING INPUT MPF	14
⊙	302HN44160	2HN44160	SOLENOID MPF	14
	302K302A50	2K302A50	PLATE EARTH ISU	9
	302K304550	2K304550	SHAFT RIGHT COVER F	8
	302K304630	2K304630	FILM CONVEYING SHAFT	8
	302K306070	2K306070	SPRING SEPARATION	5
	302K306460	2K306460	BUSH 4	5
	302K309220	2K309220	SPRING SIDE SWITCH	4
	302K317670	2K317670	COVER POCKET	17
	302K324110	2K324110	SPRING CONVEYING F	8
⊙	302K324170	2K324170	GEAR TRANSFER Z18L	8
	302K324180	2K324180	BUSH REGIST F	8
	302K324200	2K324200	SPRING REGIST F	8
	302K324230	2K324230	SPRING GUIDE TRANSFER	8
	302K324240	2K324240	BUSH TRANSFER ROLL F	8
	302K324270	2K324270	BUSH REGIST R	8
	302K324360	2K324360	SPRING CONVEYING R	8
	302K324430	2K324430	BUSH TRANSFER ROLL R	8
	302K324440	2K324440	SPRING REGIST R	8
	302K329020	2K329020	PULLEY DU	8
	302K329030	2K329030	SPRING DU FEED	8
⊙	302K331170	2K331170	GEAR Z28S	14
	302K331230	2K331230	BUSH DRIVE 8	5,14

	Part.No.	Alternative.	Description	Fig.No.
	302KK02370	2KK02370	FILM PE	2
	302KK04570	2KK04570	CUT WASHER 5	7
	302KK39650	2KK39650	PLATE SHIELD ISU R	9
⊙	302KK94440	2KK94440	PARTS HEATER DEHUMIDIFIER 240 SP	2
	302LC34080	2LC34080	LABEL MPF PAPER LIMIT	4
	302MV34250	2MV34250	LABEL COVER CAUTION	7
	302MV34300	2MV34300	SHEET CASSETTE C	18
	302MV34410	2MV34410	LABEL COVER CAUTION 9NATIONS	7
	302MV34430	2MV34430	SHEET CASSETTE I	18
	302NC34010	2NC34010	SHEET EMBLEM	9
	302NF34010	2NF34010	SHEET EMBLEM	9
	302NG02210	2NG02210	GUIDE LEFT FRONT	2
	302NG02220	2NG02220	GUIDE LEFT REAR	2
	302NG02230	2NG02230	MOUNT INLET	2
	302NG02290	2NG02290	SHIELD MAIN PWB	15
	302NG02310	2NG02310	RAIL CONTAINER	3
	302NG02330	2NG02330	GUIDE PICKUP LEVER	2
	302NG02340	2NG02340	HOLDER PE LEVER	2
	302NG02350	2NG02350	RETAINER HOOK REAR	3
	302NG02360	2NG02360	MOUNT PUSH SW	2
	302NG02440	2NG02440	SHIELD DECK CONNECTOR	2
	302NG02480	2NG02480	GUIDE FUSER WIRE	3
	302NG02490	2NG02490	MOUNT DP CONNECTOR	3
	302NG02500	2NG02500	GUIDE WIRE LOW	2
	302NG02510	2NG02510	MOUNT LSU CONNECTOR	3
	302NG02520	2NG02520	GUIDE ISU WIRE	3
	302NG02530	2NG02530	LID PARTITION	3
	302NG02550	2NG02550	PROTECTOR LVU	15
	302NG02560	2NG02560	MOUNT HUMIDITY PWB	2
	302NG02570	2NG02570	SPRING EARTH ISU	9
	302NG02580	2NG02580	SHEET CONNECTOR	3
	302NG02590	2NG02590	SHEET LSU	2
	302NG02600	2NG02600	SPRING EARTH OPERATION	9
⊙	302NG04020	2NG04020	COVER FRONT LEFT	1
⊙	302NG04030	2NG04030	COVER FRONT RIGHT	1
⊙	302NG04040	2NG04040	COVER RIGHT FRONT	1
⊙	302NG04050	2NG04050	COVER RIGHT REAR	1
⊙	302NG04060	2NG04060	COVER RIGHT UPPER	1
⊙	302NG04070	2NG04070	COVER LEFT	1
	302NG04080	2NG04080	COVER LEFT INNER	1
	302NG04090	2NG04090	COVER EXIT REAR	1
⊙	302NG04100	2NG04100	COVER EXIT FRONT	1
⊙	302NG04110	2NG04110	TRAY RIGHT	1
⊙	302NG04120	2NG04120	TRAY LEFT	1
	302NG04130	2NG04130	COVER MIDDLE REAR	1
⊙	302NG04140	2NG04140	COVER REAR	1
⊙	302NG04150	2NG04150	COVER REAR PWB	1
	302NG04160	2NG04160	SHIELD REAR PWB	1
	302NG04170	2NG04170	COVER INNER	1
	302NG04190	2NG04190	LID DEVE WIRE	1

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302NG04200	2NG04200	MOUNT MAIN SW	1
	302NG04210	2NG04210	HOLDER MAIN KEY	1
	302NG04220	2NG04220	KEY POWER	1
	302NG04230	2NG04230	COVER EXIT UPPER	1
	302NG04250	2NG04250	MOUNT RIGHT INTERLOCK	3
	302NG04510	2NG04510	COVER RIGHT MIDDLE	7
	302NG04520	2NG04520	HOOK RIGHT COVER	7
	302NG04530	2NG04530	JOINT JUNCTION HOOK	7
	302NG04550	2NG04550	STRAP RIGHT COVER A	7
	302NG04560	2NG04560	STRAP RIGHT COVER B	7
	302NG04570	2NG04570	STRAP RIGHT COVER C	7
	302NG04580	2NG04580	SPRING JOINT HOOK	7
	302NG04590	2NG04590	SHAFT RIGHT COVER R	8
	302NG04610	2NG04610	STRAP FRONT COVER	1
	302NG04620	2NG04620	SPONGE COVER RIGHT MIDDLE	7
	302NG05010	2NG05010	COVER OPERATION	16
	302NG05020	2NG05020	KEY 10	16
	302NG05030	2NG05030	KEY START	16
	302NG05040	2NG05040	KEY STOP	16
	302NG05050	2NG05050	KEY RESET	16
	302NG05060	2NG05060	KEY POWER SUPPLY	16
	302NG05070	2NG05070	KEY LOGOUT INTERRUPT	16
	302NG05080	2NG05080	KEY MENU	16
	302NG05090	2NG05090	KEY CONTROL	16
	302NG05100	2NG05100	KEY OK	16
	302NG05110	2NG05110	KEY RETURN	16
	302NG05120	2NG05120	KEY SELECT	16
	302NG05130	2NG05130	KEY FUNCTION	16
	302NG05140	2NG05140	KEY FUNCTION L	16
	302NG05160	2NG05160	LID OPERATION	16
⊙	302NG05170	2NG05170	COVER PANEL	16
	302NG05180	2NG05180	LENS LED OPERATION	16
	302NG05190	2NG05190	SHEET OPERATION	16
	302NG05200	2NG05200	KEY FAX	16
	302NG05210	2NG05210	COVER FAX OPERATION	16
	302NG05220	2NG05220	LID OPERATION FAX	16
	302NG05260	2NG05260	SHEET SHIELD	16
	302NG05310	2NG05310	SPRING OPERATION	16
	302NG05320	2NG05320	SHEET OPERATION DE	16
	302NG05330	2NG05330	SHEET OPERATION FR	16
	302NG05340	2NG05340	SHEET OPERATION IT	16
	302NG05350	2NG05350	SHEET OPERATION ES	16
	302NG05360	2NG05360	SHEET OPERATION PT	16
	302NG05370	2NG05370	SHEET OPERATION NL	16
	302NG05380	2NG05380	SHEET OPERATION RU	16
	302NG06011	2NG0601	FRAME FEED UP	5
	302NG06020	2NG06020	FRAME FEED LOW A	5
	302NG06030	2NG06030	FRAME FEED LOW B	5
	302NG06040	2NG06040	SHAFT DRIVE FEED	5
	302NG06050	2NG06050	HOLDER FEED	5

	Part.No.	Alternative.	Description	Fig.No.
	302NG06060	2NG06060	GUIDE FEED SIDE F	5
	302NG06070	2NG06070	LEVER PICKUP	2
	302NG06080	2NG06080	SPRING LEVER	2
	302NG06090	2NG06090	GUIDE FEED SIDE R	5
	302NG06100	2NG06100	GUIDE FEED UP	5
	302NG06110	2NG06110	SHAFT FEED L	5
	302NG06130	2NG06130	SPRING PICKUP	5
	302NG06140	2NG06140	SHAFT PICKUP	5
	302NG06170	2NG06170	HOLDER PULLEY	5
⊙	302NG06180	2NG06180	GEAR FEED Z27	5
⊙	302NG06190	2NG06190	GEAR FEED Z32	5
	302NG06200	2NG06200	HOLDER RETARD	5
	302NG06210	2NG06210	SHEET FEED A	5
	302NG08010	2NG08010	COVER MPF	7
	302NG08020	2NG08020	TABLE MPF	7
	302NG08030	2NG08030	BASE TABLE MPF	7
	302NG08040	2NG08040	CURSOR MPF FRONT	7
	302NG08050	2NG08050	CURSOR MPF REAR	7
	302NG08060	2NG08060	SUB TABLE MPF A	7
	302NG08070	2NG08070	SUB TABLE MPF B	7
	302NG08080	2NG08080	SUB TABLE MPF C	7
	302NG08090	2NG08090	PLATE JOINT TABLE	7
	302NG08100	2NG08100	STRAP LINK MPF F	7
	302NG08130	2NG08130	ARM LIFT MPF	5
	302NG08140	2NG08140	PLATE LIFT MPF	5
	302NG08150	2NG08150	SPRING LIFT MPF	5
	302NG08160	2NG08160	PAD LIFT	7
	302NG08170	2NG08170	ACTUATOR MPF	5
	302NG08190	2NG08190	JOINT LIFT MPF	5
	302NG08210	2NG08210	GUIDE UPPER MPF	5
	302NG08230	2NG08230	SPRING SEPARATION	5
	302NG08240	2NG08240	SHAFT MPF	5
	302NG08250	2NG08250	BUSH 8	5
	302NG08280	2NG08280	PIN FEED ROLLER	5
	302NG08310	2NG08310	MOUNT SEPARATION	5
	302NG08320	2NG08320	SPRING MPF ROLLER	5
	302NG08330	2NG08330	SPRING ACTUATOR MPF	5
	302NG09010	2NG09010	CASSETTE	4
⊙	302NG09020	2NG09020	COVER CASSETTE	4
	302NG09030	2NG09030	BASE CASSETTE	4
	302NG09040	2NG09040	CURSOR CASSETTE FRONT	4
	302NG09050	2NG09050	CURSOR CASSETTE REAR	4
	302NG09060	2NG09060	CURSOR END	4
	302NG09070	2NG09070	SPRING BOTTOM F	4
	302NG09080	2NG09080	SPRING BOTTOM R	4
	302NG09090	2NG09090	PLATE BOTTOM	4
	302NG09100	2NG09100	ARM SIZE DETECTION	4
	302NG09120	2NG09120	CASSETTE HANDLE SIL	4
	302NG09130	2NG09130	ACTUATOR PAPER EMPTY	2
	302NG09140	2NG09140	PLATE SIZE DETECTION	2

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302NG09160	2NG09160	LEVER RELEASE BASE	4
	302NG09170	2NG09170	LEVER RELEASE CURSOR	4
	302NG09180	2NG09180	SPRING RELEASE CURSOR	4
	302NG09190	2NG09190	PLATE SIDE SWITCH	4
	302NG09210	2NG09210	SPRING RELEASE BASE	4
	302NG12320	2NG12320	COVER CONNECTOR	1
	302NG14400	2NG14400	RAIL DLP	2
	302NG14410	2NG14410	COVER RAIL DLP	2
	302NG14420	2NG14420	HOLDER JOINT	2
⊙	302NG14430	2NG14430	GEAR Z24L RAIL	2
⊙	302NG14440	2NG14440	GEAR Z52R RAIL	2
⊙	302NG14450	2NG14450	GEAR Z25R RAIL	2
⊙	302NG14460	2NG14460	GEAR JOINT Z24L	2
	302NG14470	2NG14470	PIN RAIL	2
	302NG14480	2NG14480	SHAFT RAIL PIVOT	2
	302NG14490	2NG14490	PLATE BIAS RAIL	2
	302NG14500	2NG14500	SPRING JOINT GEAR	2
	302NG14600	2NG14600	LEVER RAIL REMOVENT	2
	302NG14610	2NG14610	SLIDER RAIL FRONT	2
	302NG14620	2NG14620	SLIDER RAIL REAR	2
	302NG14650	2NG14650	SPRING BOTTOM	2
	302NG15010	2NG15010	BASE HOPPER	3
	302NG15020	2NG15020	SHUTTER HOPPER LOW	3
	302NG15030	2NG15030	SPRING SHUTTER HOPPER	3
	302NG15040	2NG15040	SEAL HOPPER	3
	302NG15050	2NG15050	COVER CONT DRIVE	3
⊙	302NG15060	2NG15060	GEAR Z48L Z19S	3
⊙	302NG15070	2NG15070	JOINT CONTAINER PADDLE Z49S	3
⊙	302NG15080	2NG15080	GEAR Z25S Z36S	3
⊙	302NG15090	2NG15090	JOINT CONTAINER SCREW Z19S	3
	302NG15100	2NG15100	SPRING JOINT SCREW	3
	302NG15110	2NG15110	JOINT CONTAINER PADDLE	3
	302NG15120	2NG15120	SPRING JOINT PADDLE	3
⊙	302NG17230	2NG17230	COVER DP CONNECTOR	9
	302NG17510	2NG17510	HINGE PLATEN	17
	302NG17521	2NG17521	SHEET ORIGINAL HOLDER	17
	302NG17540	2NG17540	COVER PLATEN B	17
	302NG24010	2NG24010	BASE CONVEYING	8
	302NG24030	2NG24030	LEVER CONVEYING F	8
	302NG24040	2NG24040	LEVER CONVEYING R	8
	302NG24050	2NG24050	GUIDE CONVEYING	8
	302NG24080	2NG24080	SPRING REGIST C	8
	302NG24090	2NG24090	SPRING EARTH CONVEYING	8
	302NG24100	2NG24100	BUSH REGIST C	8
⊙	302NG24110	2NG24110	GEAR REGIST R Z17R	8
	302NG24120	2NG24120	SHEET REGIST RIGHT F	8
	302NG24130	2NG24130	TERMINAL SEPARATION	8
	302NG24140	2NG24140	SHEET REGIST RIGHT R	8
	302NG24150	2NG24150	TERMINAL TRANSFER	8
	302NG24160	2NG24160	SHEET DU	8

	Part.No.	Alternative.	Description	Fig.No.
	302NG24320	2NG24320	GUIDE TRANSFER RIGHT	8
	302NG24330	2NG24330	HOLDER SEPARATION	8
	302NG24340	2NG24340	PLATE SEPARATION	8
	302NG24350	2NG24350	COLLAR ROLLER	8
	302NG24370	2NG24370	SPRING TRANSFER R	8
	302NG24380	2NG24380	SPRING TRANSFER F	8
	302NG24390	2NG24390	ARM TRANSFER F	8
	302NG24400	2NG24400	ARM TRANSFER R	8
	302NG24600	2NG24600	GUIDE FEED REGIST	6
	302NG24610	2NG24610	SHEET REGIST L	6
	302NG24620	2NG24620	ACTUATOR REGIST	6
	302NG24630	2NG24630	SPRING ACTUATOR REGIST	6
⊙	302NG24710	2NG24710	GEAR REGIST L Z17L	6
	302NG24730	2NG24730	GUIDE TRANSFER LEFT	6
	302NG24740	2NG24740	HOLDER CONVEYING F	6
	302NG24770	2NG24770	SPRING EARTH REGIST A	6
	302NG24780	2NG24780	SPRING EARTH REGIST B	6
	302NG24790	2NG24790	SPRING EARTH REGIST C	6
	302NG24800	2NG24800	RAIL CLEANER REGIST	6
	302NG24830	2NG24830	SPRING EARTH REGIST D	6
	302NG28010	2NG28010	FRAME EXIT UPPER	13
⊙	302NG28030	2NG28030	GEAR Z74R-Z21S EXIT	14
	302NG28040	2NG28040	GUIDE EXIT PUSH	13
⊙	302NG28050	2NG28050	GEAR Z23S EXIT	13
	302NG28060	2NG28060	MOUNT EXIT MOTOR	14
	302NG28070	2NG28070	PLATE EXIT GUIDE	13
	302NG28080	2NG28080	BUSH EXIT SHAFT	13
	302NG28090	2NG28090	STATIC ELIMINATOR EXIT	13
	302NG29010	2NG29010	GUIDE DU	8
	302NG31010	2NG31010	HOLDER DRIVE	14
	302NG31020	2NG31020	HOLDER CL	14
⊙	302NG31030	2NG31030	GEAR Z91L Z54L	14
⊙	302NG31040	2NG31040	GEAR INPUT DRUM Z141R	14
⊙	302NG31050	2NG31050	GEAR Z91L Z27L	14
⊙	302NG31060	2NG31060	GEAR INPUT DLP Z40R	14
⊙	302NG31070	2NG31070	GEAR Z46R IDLE	14
⊙	302NG31080	2NG31080	GEAR Z40L Z40R	14
⊙	302NG31090	2NG31090	GEAR Z39L	14
⊙	302NG31100	2NG31100	GEAR INPUT FUSER Z26S	14
⊙	302NG31110	2NG31110	GEAR Z92R	14
⊙	302NG31120	2NG31120	GEAR Z100L Z30L	14
⊙	302NG31130	2NG31130	GEAR Z40L	14
⊙	302NG31140	2NG31140	GEAR Z37L Z28L	14
⊙	302NG31150	2NG31150	GEAR Z48R Z20S	14
⊙	302NG31160	2NG31160	GEAR Z45S INPUT MPF A	14
⊙	302NG31170	2NG31170	GEAR Z45S INPUT MPF B	14
⊙	302NG31180	2NG31180	GEAR Z40L Z26L	14
	302NG31190	2NG31190	CAM MPF	14
	302NG31200	2NG31200	SHAFT CL FEED	14
	302NG31210	2NG31210	JOINT SHAFT CASSETTE	14

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302NG31220	2NG31220	HOLDER GEAR	14
	302NG31230	2NG31230	SPRING FEED	14
	302NG31240	2NG31240	SPRING FUSER	14
	302NG33010	2NG33010	BRACKET FAN	3
	302NG34080	2NG34080	LABEL COVER	18
	302NG34090	2NG34090	LABEL A2	8
	302NG34100	2NG34100	SHEET EMBLEM	9
	302NG34110	2NG34110	LABEL OPERATION MPF	7
	302NG34170	2NG34170	LABEL HIGH TEMP	7
	302NG39010	2NG39010	MOUNT HVU UPPER	15
	302NG39020	2NG39020	LID FAX BOARD	15
	302NG39030	2NG39030	LID NETWORK BOARD	15
	302NG39040	2NG39040	LID WIFI	15
	302NG39060	2NG39060	TERMINAL DLP	14
	302NG39070	2NG39070	TERMINAL TRANSFER	14
	302NG39080	2NG39080	TERMINAL DRUM	14
	302NG39090	2NG39090	TERMINAL SEPARATION	14
	302NG44040	2NG44040	SENSOR ORIGINAL	9
	302NG46020	2NG46020	WIRE HVU CONNECT	3
	302NG46030	2NG46030	WIRE HVU	3
	302NG46040	2NG46040	WIRE MAIN MOTOR	15
	302NG46050	2NG46050	WIRE PAPER	15
	302NG46060	2NG46060	WIRE FUSER	3
	302NG46110	2NG46110	WIRE POLYGON MOTOR	3
	302NG46120	2NG46120	WIRE CONTAINER DRIVE	3
	302NG46130	2NG46130	WIRE HUMIDITY SENSOR	15
	302NG46140	2NG46140	WIRE INLET	2
	302NG46150	2NG46150	WIRE FAN	15
	302NG46160	2NG46160	WIRE PF	15
	302NG46170	2NG46170	WIRE HEATER CONT	15
	302NG46180	2NG46180	WIRE FUSER HEATER	3
	302NG46190	2NG46190	WIRE INTERLOCK	3
	302NG46200	2NG46200	WIRE DP	15
	302NG46220	2NG46220	WIRE APC	3
	302NG46250	2NG46250	WIRE DRUM CONNECT	1
	302NG46260	2NG46260	WIRE MPF	5,6
⊙	302NG93010	2NG93010	DV-4105	11
⊙	302NG93020	2NG93020	FK-4105	13
⊙	302NG93030	2NG93030	FK-4107	13
⊙	302NG93041	2NG93041	LK-4105	10
⊙	302NG93050	2NG93050	MC-4105	12
⊙	302NG93060	2NG93060	CT-4105	4
⊙	302NG93070	2NG93070	PARTS CIS ASSY SP	9
	302NG93080	2NG93080	WT-4105	12
⊙	302NG94011	2NG94011	PARTS COVER FRONT ASSY SP	1
⊙	302NG94021	2NG94021	PARTS PRIMARY FEED ASSY SP	5
⊙	302NG94030	2NG94030	PARTS RIGHT COVER ASSY SP	7
⊙	302NG94040	2NG94040	PARTS MPF TABLE ASSY SP	7
⊙	302NG94050	2NG94050	PARTS DC MOTOR ASSY SP	3
⊙	302NG94060	2NG94060	PARTS EXIT UNIT SP	13

	Part.No.	Alternative.	Description	Fig.No.
⊙	302NG94070	2NG94070	PARTS OPERATION UNIT SP	16
⊙	302NG94100	2NG94100	PARTS COVER CASSETTE ASSY SP	4
⊙	302NG94110	2NG94110	PARTS ROLLER RETARD ASSY SP	5
⊙	302NG94120	2NG94120	PARTS PULLEY PICKUP ASSY SP	5
⊙	302NG94130	2NG94130	PARTS ROLLER MPF SP	5
⊙	302NG94140	2NG94140	PARTS ROLLER REGIST RIGHT SP	8
⊙	302NG94150	2NG94150	PARTS ROLLER TRANSFER SP	8
⊙	302NG94160	2NG94160	PARTS ROLLER TRANSFER U SP	8
⊙	302NG94170	2NG94170	PARTS ROLLER REGIST LEFT SP	6
⊙	302NG94180	2NG94180	PARTS ROLLER EXIT SP	13
⊙	302NG94190	2NG94190	PARTS MOTOR-BL W20 SP	14
⊙	302NG94200	2NG94200	PARTS CLUTCH 50 Z35R SP	14
⊙	302NG94211	2NG94211	PARTS MOTOR ISU SP	9
⊙	302NG94220	2NG94220	PARTS FAN MOTOR SP	3
⊙	302NG94230	2NG94230	PARTS UNIT POWER SOURCE 120 SP	15
⊙	302NG94240	2NG94240	PARTS UNIT POWER SOURCE 230 SP	15
⊙	302NG94250	2NG94250	PARTS HIGH VOLTAGE UNIT SP	15
⊙	302NG94270	2NG94270	PARTS PWB PANEL MAIN ASSY SP	16
⊙	302NG94280	2NG94280	PARTS PWB HUMIDITY SENSOR ASSY SP	2
⊙	302NG94290	2NG94290	PARTS PWB DRUM CONNECT ASSY SP	1
⊙	302NG94300	2NG94300	PARTS PWB SWITCH ASSY SP	1
⊙	302NG94320	2NG94320	PARTS PWB MAIN ENGINE ASSY EU SP	15
⊙	302NG94350	2NG94350	PARTS CONTACT GLASS ASSY E SP	9
⊙	302NG94370	2NG94370	PARTS CLEANER REGIST ASSY SP	1
⊙	302NG94380	2NG94380	PARTS PAD SEPARATION ASSY SP	5
	302NN05010	2NN05010	COVER OPERATION	16
⊙	302NN05020	2NN05020	COVER PANEL	16
	302NN05040	2NN05040	KEY OK	16
	302NN05050	2NN05050	KEY CONTROL	16
	302NN05060	2NN05060	KEY FUNCTION	16
	302NN05070	2NN05070	KEY FUNCTION L	16
	302NN05080	2NN05080	SHEET OPERATION	16
	302NN05100	2NN05100	SHEET SHIELD	16
	302NN05160	2NN05160	SHEET OPERATION DE	16
	302NN05170	2NN05170	SHEET OPERATION FR	16
	302NN05180	2NN05180	SHEET OPERATION IT	16
	302NN05190	2NN05190	SHEET OPERATION ES	16
	302NN05200	2NN05200	SHEET OPERATION PT	16
	302NN05210	2NN05210	SHEET OPERATION NL	16
	302NN05220	2NN05220	SHEET OPERATION RU	16
	302NN34010	2NN34010	SHEET EMBLEM	9
⊙	302NN94010	2NN94010	PARTS OPERATION UNIT SP	16
⊙	302NN94030	2NN94030	PARTS PWB PANEL MAIN ASSY SP	16
⊙	302NN94040	2NN94040	PARTS PWB MAIN ENGINE ASSY SP	15
⊙	303M894260	3M894260	PARTS SENSOR OPT SP	2,5,6,9
⊙	5ESP03090001+01	SP000360	PUSH SWITCH 03 SN /SW-192 N	2
	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	7,8
	7AAACCAS+10H001	AA063380	AC CORD ASSY AS	3
	7RHA2H10701+H01	RH043740	M.GLAZE R. 100MJ 1/2W	6
⊙	7SM010202+++H01	SM044270	SW.MICRO	3

• Parts with "⊙" indicate regular maintenance parts.

[illegible][illegible]

- Parts with "⊙" indicate regular maintenance parts.

KYOCERA Document Solutions America, Inc.**Headquarters**

225 Sand Road,
Fairfield, New Jersey 07004-0008, USA
Phone: +1-973-808-8444
Fax: +1-973-882-6000

Latin America

8240 NW 52nd Terrace Dawson Building, Suite 100
Miami, Florida 33166, USA
Phone: +1-305-421-6640
Fax: +1-305-421-6666

KYOCERA Document Solutions Canada, Ltd.

6120 Kestrel Rd., Mississauga, ON L5T 1S8,
Canada
Phone: +1-905-670-4425
Fax: +1-905-670-8116

**KYOCERA Document Solutions
Mexico, S.A. de C.V.**

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco
Chapultepec, Delegacion Miguel Hidalgo,
Distrito Federal, C.P. 11560, México
Phone: +52-555-383-2741
Fax: +52-555-383-7804

KYOCERA Document Solutions Brazil, Ltda.

Alameda África, 545, Pólo Empresarial Consbrás,
Tamboré, Santana de Parnaíba-SP, CEP 06543-306,
Brazil
Phone: +55-11-4195-8496
Fax: +55-11-4195-6167

**KYOCERA Document Solutions
Australia Pty. Ltd.**

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,
Australia
Phone: +61-2-9888-9999
Fax: +61-2-9888-9588

**KYOCERA Document Solutions
New Zealand Ltd.**

Ground Floor, 19 Byron Avenue, Takapuna, Auckland,
New Zealand
Phone: +64-9-415-4517
Fax: +64-9-415-4597

KYOCERA Document Solutions Asia Limited

16/F., Mita Centre, 552-566, Castle Peak Road
Tsuenwan, NT, Hong Kong
Phone: +852-2610-2181
Fax: +852-2610-2063

**KYOCERA Document Solutions
(China) Corporation**

8F, No. 288 Nanjing Road West, Huangpu District,
Shanghai, 200003, China
Phone: +86-21-5301-1777
Fax: +86-21-5302-8300

**KYOCERA Document Solutions
(Thailand) Corp., Ltd.**

335 Ratchadapisek Road, Bangsue, Bangkok 10800,
Thailand
Phone: +66-2-586-0333
Fax: +66-2-586-0278

**KYOCERA Document Solutions
Singapore Pte. Ltd.**

12 Tai Seng Street #04-01A,
Luxasia Building, Singapore 534118
Phone: +65-6741-8733
Fax: +65-6748-3788

**KYOCERA Document Solutions
Hong Kong Limited**

16/F., Mita Centre, 552-566, Castle Peak Road
Tsuenwan, NT, Hong Kong
Phone: +852-3582-4000
Fax: +852-3185-1399

**KYOCERA Document Solutions
Taiwan Corporation**

6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: +886-2-2507-6709
Fax: +886-2-2507-8432

KYOCERA Document Solutions Korea Co., Ltd.

18F, Kangnam bldg, 1321-1,
Seocho-Dong, Seocho-Gu, Seoul, Korea
Phone: +822-6933-4050
Fax: +822-747-0084

**KYOCERA Document Solutions
India Private Limited**

First Floor, ORCHID CENTRE
Sector-53, Golf Course Road, Gurgaon 122 002,
India
Phone: +91-0124-4671000
Fax: +91-0124-4671001

KYOCERA Document Solutions Europe B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31-20-654-0000
Fax: +31-20-653-1256

KYOCERA Document Solutions Nederland B.V.

Beechavenue 25, 1119 RA Schiphol-Rijk,
The Netherlands
Phone: +31-20-5877200
Fax: +31-20-5877260

KYOCERA Document Solutions (U.K.) Limited

Eldon Court, 75-77 London Road,
Reading, Berkshire RG1 5BS,
United Kingdom
Phone: +44-118-931-1500
Fax: +44-118-931-1108

KYOCERA Document Solutions Italia S.p.A.

Via Verdi, 89/91 20063 Cernusco s/N.(MI),
Italy
Phone: +39-02-921791
Fax: +39-02-92179-600

KYOCERA Document Solutions Belgium N.V.

Sint-Martinusweg 199-201 1930 Zaventem,
Belgium
Phone: +32-2-7209270
Fax: +32-2-7208748

KYOCERA Document Solutions France S.A.S.

Espace Technologique de St Aubin
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,
France
Phone: +33-1-69852600
Fax: +33-1-69853409

KYOCERA Document Solutions Espana, S.A.

Edificio Kyocera, Avda. de Manacor No.2,
28290 Las Matas (Madrid), Spain
Phone: +34-91-6318392
Fax: +34-91-6318219

KYOCERA Document Solutions Finland Oy

Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358-9-47805200
Fax: +358-9-47805390

**KYOCERA Document Solutions
Europe B.V., Amsterdam (NL) Zürich Branch**

Hohlstrasse 614, 8048 Zürich,
Switzerland
Phone: +41-44-9084949
Fax: +41-44-9084950

**KYOCERA Document Solutions
Deutschland GmbH**

Otto-Hahn-Strasse 12, 40670 Meerbusch,
Germany
Phone: +49-2159-9180
Fax: +49-2159-918100

KYOCERA Document Solutions Austria GmbH

Eduard-Kittenberger-Gasse 95, 1230 Vienna,
Austria
Phone: +43-1-863380
Fax: +43-1-86338-400

KYOCERA Document Solutions Nordic AB

Esbogatan 16B 164 75 Kista, Sweden
Phone: +46-8-546-550-00
Fax: +46-8-546-550-10

KYOCERA Document Solutions Norge Nuf

Postboks 150 Oppsal, 0619 Oslo,
Norway
Phone: +47-22-62-73-00
Fax: +47-22-62-72-00

KYOCERA Document Solutions Danmark A/S

Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45-70223880
Fax: +45-45765850

KYOCERA Document Solutions Portugal Lda.

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351-21-843-6780
Fax: +351-21-849-3312

**KYOCERA Document Solutions
South Africa (Pty) Ltd.**

KYOCERA House, Hertford Office Park,
90 Bekker Road (Cnr. Allandale), Midrand, South Africa.
Phone: +27-11-540-2600
Fax: +27-11-466-3050

KYOCERA Document Solutions Russia LLC

Botanichesky pereulok 5, Moscow, 129090,
Russia
Phone: +7(495)741-0004
Fax: +7(495)741-0018

KYOCERA Document Solutions Middle East

Dubai Internet City, Bldg. 17,
Office 157 P.O. Box 500817, Dubai,
United Arab Emirates
Phone: +971-04-433-0412

KYOCERA Document Solutions Inc.

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: +81-6-6764-3555
<http://www.kyoceradocumentsolutions.com>