



TASKalfa 3010i

TASKalfa 3510i

PARTS LIST

Published in October 2015

2NLPL075

842NL125

Rev.5

— CONTENTS —

FIG. 1	Covers 1	2
FIG. 2	Covers 2	4
FIG. 3	Frames 1	6
FIG. 4	Frames 2	8
FIG. 5	Frames 3	10
FIG. 6	Frames 4	12
FIG. 7	Frames 5	14
FIG. 8	Paper Cassette	16
FIG. 9	Paper Feed Section 1	18
FIG. 10	Paper Feed Section 2	20
FIG. 11	Paper Feed Section 3	22
FIG. 12	Paper Feed Section 4	24
FIG. 13	Paper Conveying Section 1	26
FIG. 14	Paper Conveying Section 2	28
FIG. 15	Paper Conveying Section 3	30
FIG. 16	Paper Conveying Section 4	32
FIG. 17	Scanner Section 1	34
FIG. 18	Scanner Section 2	36
FIG. 19	Laser Scanner Section	38
FIG. 20	Developer Section	40
FIG. 21	Image Formation Section	42
FIG. 22	Fuser Section	44
FIG. 23	Drive Section 1	46
FIG. 24	Drive Section 2	48
FIG. 25	Cooling Section	50
FIG. 26	Exit Section	52
FIG. 27	Inner Section	54
FIG. 28	Electrical Components 1	56
FIG. 29	Electrical Components 2	58
FIG. 30	Electrical Components 3	60
FIG. 31	Operation Section	62
FIG. 32	Options 1	64
FIG. 33	Options 2	66
FIG. 34	Accessories	68
FIG. 35	Maintenance Kits	70
	• INDEX	71

<Notation of products>


For the purpose of this parts list, products are identified as following.


TASKalfa 3010i : 30ppm

TASKalfa 3510i : 35ppm

FIG. 1 Covers 1

2P8/2NL-2






2P8/2NL-2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 5 -

FIG. 3 Frames 1

2P8/2NL



2P8/2NL

- Parts with "• •" are component parts or sub-assembly with "•" appearing immediately above them.





FIG. 4 Frames 2


2P8/2NL-5

	Ref. No.	Part.No.	Alternative.	Description	Notes	Quantity		
						120	230	240
	1	302K339060	2K339060	BASE TERMINAL		1	1	1
	2	302K339070	2K339070	TERMINAL DRUM A		1	1	1
	3	302K339080	2K339080	TERMINAL DLP A		1	1	1
	4	302K339090	2K339090	TERMINAL TRANSFER A		1	1	1
	5	302K339100	2K339100	TERMINAL SEPARATION A		1	1	1
	6	302K302170	2K302170	FRAME REAR UPPER		1	1	1
	7	302K302A10	2K302A10	LEVER RIGHT SW		1	1	1
	8	302GR02240	2GR02240	PIN FRONT CASSETTE RAIL		4	4	4
	9	2FB06710	2FB06710	PIN CASSETTE RAIL		4	4	4
⊙	10	302NL09030	2NL09030	PULLEY CASSETTE RAIL		4	4	4
	11	302NL02090	2NL02090	RAIL CASSETTE LEFT		2	2	2
	12	302NL02210	2NL02210	RAIL CASSETTE RIGHT		2	2	2
	13	303MH06010	3MH06010	PAD RAIL		2	2	2
	14	302MV02310	2MV02310	SPRING LEVER LIFT CASSETTE		2	2	2
	15	302K302760	2K302760	LEVER LIFT CASSETTE		2	2	2
	16	303NN02370	3NN02370	RAIL FEED		2	2	2
	17	302K302640	2K302640	GUIDE DRUM COVER		2	2	2
	18	302K302120	2K302120	RAIL DRUM		1	1	1
	19	302K302690	2K302690	RAIL HOLDER FRONT		1	1	1
	20	302K302700	2K302700	RAIL HOLDER REAR		1	1	1
	21	302K302960	2K302960	STOPPER CONTAINER		1	1	1
	22	302K302071	2K302071	BASE LSU		1	1	1
	23	7YZM610009++H01	YZ042980	ACCESS.SADDLE		4	4	4
	24	302NL46370	2NL46370	WIRE LIMIT SENSOR		1	1	1
⊙	25	7NXGP1S173LCH01	NX116910	SENSOR OPT.		2	2	2
	26	302NL06010	2NL06010	HOLDER SENSOR		1	1	1
	27	303NN02450	3NN02450	GUIDE PRIMARY FEED		1	1	1
	28	303NN02143	3NN02143	STAY UPPER FEED		1	1	1
	29	302K302811	2K302811	ACTUATOR PAPER EMPTY		1	1	1
	30	302MV02040	2MV02040	STAY FRONT FRAME		1	1	1
	31	302NL46270	2NL46270	WIRE MAIN SWITCH		1	1	1
	32	7YZM610010++H01	YZ042990	ACCESS.SADDLE		1	1	1
	33	7YZM390002++H01	YZ012140	ACCESS.CLAMP		2	2	2
	34	302NL46150	2NL46150	WIRE FUSER HEATER		1	1	1
	35	302NL02070	2NL02070	GUIDE FUSER		1	1	1
	36	302K325340	2K325340	MOUNT FUSER FRONT		1	1	1
	37	302K325350	2K325350	ADJUSTER FUSER		1	1	1
	38	302K302161	2K302161	FRAME FRONT UPPER		1	1	1
	39	302NL02100	2NL02100	JOINT FUSER		1	1	1
	40	302NL39050	2NL39050	GUIDE WIRE REAR		1	1	1
⊙	41	302NL09130	2NL09130	PULLEY CASSETTE RAIL		4	4	4
	42	7YZM210003++H01	YZ037970	ACCESS.EDGING		1	1	1
	43	302NL46120	2NL46120	WIRE BRIDGE JOINT		1	1	1
	44	302NL02080	2NL02080	BRACKET DRAWER		1	1	1
	45	302NL02060	2NL02060	STAY REAR FRAME		1	1	1
⊙	46	7SC020403+++H01	SC136170	SW.SEE SAW		1	1	1
	101	7BB702308H	BB107060	+TP-FLAT T.T S SCREW 3X8 SR				
	102	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR				

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.





2P8/2NL-4

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 13 -




FIG. 7 Frames 5

2P8/2NL-4

[illegible]

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- Parts with "• •" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 8 Paper Cassette

2P8/2NL




FIG. 8 Paper Cassette

2P8/2NL

	Ref. No.	Part.No.	Alternative.	Description	Notes	Quantity		
						120	230	240
	1	2BL04310	2BL04310	PLATE NUMBER		1	1	1
	2	2BL04370	2BL04370	PLATE NUMBER 2		1	1	1
	3	302MV34300	2MV34300	SHEET CASSETTE C			2	2
	3	302MV34430	2MV34430	SHEET CASSETTE I		2		
⊙	A01	302NP93010	2NP93010	CT-8325		2	2	2
	4	*302MV34330	2MV34330	LABEL OPERATION L		2	2	2
	5	*302NL09070	2NL09070	EMBLEM CASSETTE		2	2	2
⊙	6	*302NL09050	2NL09050	COVER CASSETTE		2	2	2
	7	*302NL09080	2NL09080	HANDLE CASSETTE		2	2	2
	8	*302NL09010	2NL09010	CASSETTE		2	2	2
	9	*302MV34340	2MV34340	LABEL OPERATION S		2	2	2
	10	*302MV34310	2MV34310	LABEL CASSETTE SIZE A		2	2	2
	11	*302MV34360	2MV34360	LABEL CASSETTE SIZE B		2	2	2
	12	*302MV34320	2MV34320	LABEL OPERATION CURSOR		2	2	2
	13	*302MV09050	2MV09050	PLATE SIDE SWITCH		2	2	2
	14	*302K309220	2K309220	SPRING SIDE SWITCH		2	2	2
	15	*302MV09040	2MV09040	ARM SIZE DETECTION		2	2	2
	16	*302K309270	2K309270	CURSOR END		2	2	2
	17	*2C907360	2C907360	SPRING CURSOR R		4	4	4
	18	*302K309141	2K309141	SLIDER CURSOR END		2	2	2
	19	*302K309360	2K309360	SPRING SIZE SET		2	2	2
	20	*302K309350	2K309350	STOPPER SIZE SET		2	2	2
	21	*302MV09080	2MV09080	CURSOR CASSETTE REAR		2	2	2
	22	*302K309190	2K309190	LEVER CURSOR SET		4	4	4
	23	*302K309370	2K309370	SPRING CURSOR SET		4	4	4
	24	*302MV34370	2MV34370	LABEL PAPER LIMIT		2	2	2
	25	*302MV09090	2MV09090	CURSOR CASSETTE FRONT		2	2	2
	26	*302K309200	2K309200	LEVER RELEASE CURSOR F		2	2	2
	27	*302K309210	2K309210	SPRING RELEASE CURSOR F		2	2	2
	28	*302K309380	2K309380	SPRING SIZE SET F		2	2	2
	29	*302HN09240	2HN09240	SIZE FIX		2	2	2
⊙	30	*302K394380	2K394380	PARTS GEAR Z18 SP		2	2	2
	31	*302K309180	2K309180	SHAFT DRIVE LIFT		2	2	2
	32	*302K309170	2K309170	PLATE LIFT BASE CASSETTE		2	2	2
	33	*2BC06910	2BC06910	STOPPER 6		2	2	2
	34	*302K309300	2K309300	SPRING CASSETTE LIFT EARTH		2	2	2
	35	*302MV09021	2MV09021	BASE CASSETTE		2	2	2
	36	*2C907140	2C907140	PAD CASSETTE		2	2	2
	37	*302MV34350	2MV34350	LABEL PAPER SET		2	2	2
	38	*302K309150	2K309150	LIFT BASE CASSETTE SUB		4	4	4
	39	*302K309160	2K309160	SPRING LEVER LIFT CASSETTE SUB		4	4	4
	40	*302NL09090	2NL09090	PLATE CASSETTE LEFT		2	2	2
	41	*302NL09100	2NL09100	PLATE CASSETTE RIGHT		2	2	2
	42	*302FZ07020	2FZ07020	PULLEY MPT BYPASS		2	2	2
	43	*302FG07020	2FG07020	PULLEY,CASSETTE RAIL		6	6	6
	44	*5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4		2	2	2
	101	7BB202410H	BB106850	+TP-FLAT T.T P SCREW 4X10				
	102	5MBP2514WXSP	E0025250	SPRING PIN				
	103	7BB203308H	BB106950	+FLAT HEAD T.T P SCREW 3X8				

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.





FIG. 9 Paper Feed Section 1

2P8/2NL-2

[illegible]

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- Parts with ".•" are component parts or sub-assembly with ".•" appearing immediately above them.



2P8/2NL

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 21 -



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 23 -



2P8/2NL-3

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 25 -



2P8/2NL-5

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 27 -



2P8/2NL-2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 29 -



2P8/2NL-2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 31 -



2P8/2NL-5

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 33 -



2P8/2NL-3

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 35 -



2P8/2NL-2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 37 -



2P8/2NL

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 39 -



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 41 -



2P8/2NL

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 43 -



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 45 -



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 47 -



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 49 -





2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 51 -

FIG. 26 Exit Section



A01

2P8/2NL-4

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 53 -





FIG. 27 Inner Section

2P8/2NL-2

[illegible]

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- 57 -



2P8/2NL-4

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 59 -



2P8/2NL-2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 61 -




FIG. 31 Operation Section

2P8/2NL-2

	Ref. No.	Part.No.	Alternative.	Description	Notes	Quantity		
						120	230	240
⊙	A01	302NL94031	2NL94031	PARTS OPERATION UNIT SP		1	1	1
	1	•302N405210	2N405210	FILM LCD WIRE		1	1	1
	2	•302N405241	2N405241	SPONGE LCD A		2	2	2
	3	•302N405251	2N405251	SPONGE LCD B		2	2	2
⊙	4	•302N494180	2N494180	PARTS PWB OPERATION ASSY SP		1	1	1
	5	•302N405080	2N405080	KEY MENU		1	1	1
⊙	6	•302N494090	2N494090	PARTS LCD OPERATION SP		1	1	1
⊙	7	•302N494150	2N494150	PARTS PWB PANEL MAIN ASSY SP		1	1	1
	8	•302NL05010	2NL05010	COVER OPERATION A		1	1	1
⊙	9	•302LC05050	2LC05050	KEY 10		1	1	1
	10	•303LL02330	3LL02330	HOLDER WIRE D		1	1	1
	11	•302N405070	2N405070	KEY FUNCTION		1	1	1
	12	•302H722690	2H722690	SHEET WIRE CONV E		1	1	1
	13	•302N205190	2N205190	KEY START B		1	1	1
	14	•302LC05100	2LC05100	KEY STOP		1	1	1
	15	•302LC05110	2LC05110	KEY RESET		1	1	1
	16	•302N405090	2N405090	KEY POWER		1	1	1
⊙	17	•302N405140	2N405140	LID OPERATION SHEET A		1	1	1
⊙	18	•302N405150	2N405150	LID OPERATION SHEET B		1	1	1
⊙	19	•302N494100	2N494100	PARTS TABLET OPERATION SP		1	1	1
	20	•302LC05420	2LC05420	FILM FFC		1	1	1
	21	•302N405100	2N405100	KEY HOME		1	1	1
	22	•302N405110	2N405110	KEY DISPLAY		1	1	1
	23	•302N405120	2N405120	KEY RIGHT SIDE		1	1	1
	24	•302LC05270	2LC05270	HOLDER LCD		1	1	1
⊙	25	•302LC94370	2LC94370	PARTS SPEAKER SP		1	1	1
	26	•302N446050	2N446050	WIRE FFC KEY PWB		1	1	1
	27	•302N405200	2N405200	LENS LED		4	4	4
	28	•302NL05030	2NL05030	MOUNT MAIN PWB		1	1	1
	29	•302NL05040	2NL05040	GUIDE WIRE OPERATION		1	1	1
	30	•302NP46450	2NP46450	WIRE PANEL JOINT		1	1	1
	31	•302N405260	2N405260	SPACER LCD A		1	1	1
	32	•302N405270	2N405270	SPACER LCD B		2	2	2
⊙	33	302NL05020	2NL05020	COVER OPERATION B		1	1	1
	34	302NL46200	2NL46200	WIRE MAIN-OPERATION		1	1	1
	35	302NL05050	2NL05050	MOUNT OPERATION		1	1	1
	36	302MV05050	2MV05050	MOUNT USB		1	1	1
	37	302K905900	2K905900	SPRING USB HOLD		1	1	1
	38	302NL46210	2NL46210	WIRE USB HOST		1	1	1
	39	7YZM390011++H01	YZ050250	ACCESS.CLAMP		1	1	1
	40	M7005010	M7005010	CLAMP,EMT-3N(TAKEUCHI)		1	1	1
⊙	41	302N905010	2N905010	PANEL OPERATION		1	1	1
	42	302N905510	2N905510	SHEET OPERATION EN			1	1
	42	302N905630	2N905630	SHEET OPERATION KDA EN		1		
	43	302NL46190	2NL46190	WIRE PANEL DATA		1	1	1
	44	302MV05090	2MV05090	FILM COVER LOW		1	1	1
	101	7BB782308H	BB111300	+TP-FLAT T.T S SCREW 3X8 SR(BLACK)				
	102	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR				
	103	7BB200308H	BB105660	+BIND T.T P SCREW 3X8				
	104	7BB000306H	BB106880	+BIND M SCREW 3X6				
	105	7BB702308H	BB107060	+TP-FLAT T.T S SCREW 3X8 SR				

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.





FIG. 32 Options 1

2P8/2NL

Ref. No.	Part.No.	Alternative.	Description	Notes	Quantity		
					120	230	240
A01	1202H70UN0	022H70UN	PLATEN COVER TYPE(E)		1	1	1
1	•302H717500	2H717500	COVER PLATEN		1	1	1
2	•302H717510	2H717510	COVER POCKET		1	1	1
3	•302H717520	2H717520	STOPPER RELEASE SWITCH		2	2	2
4	•302H717600	2H717600	HINGI ORIGINAL HOLDER		2	2	2
5	•303JC04201	3JC04200	PLATE ORIGINAL		1	1	1
6	•303K502080	3K502080	SPONGE ORIGINAL MAT		4	4	4
7	•303MX02021	3MX02021	CUSHION ORIGINAL MAT A		4	4	4
8	•303MX02031	3MX02031	CUSHION ORIGINAL MAT B		4	4	4
9	•303PH34070	3PH34070	LABEL ISU REAR		1	1	1
101	7BB280410H	BB111250	+BIND T.T P SCREW 4X10(BLACK)				

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.


- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.



2P8/2NL

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 67 -



2P8/2NL

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 69 -

2P8/2NL-1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicate regular maintenance parts.

- 70 -

INDEX

2P8/2NL-5

	Part.No.	Alternative.	Description	Fig.No.
	1702NL7US0	1702NL7US0	MK-7107/MAINTENANCE KIT	35
	1702NL8AS0	1702NL8AS0	MK-7109/MAINTENANCE KIT	35
	1702NL8NL0	1702NL8NL0	MK-7105/MAINTENANCE KIT	35
	1902LC0UN2	092LC0U2	DT-730(B)DOCUMENT TRAY	33
	2BC06910	2BC06910	STOPPER 6	8,10
	2BC06980	2BC06980	STOPPER 5	6,13,17
	2BC06910	2BC06910	STOPPER 6	10
	2BG06480	2BG06480	BAND B	12
	2BC06980	2BC06980	STOPPER 5	13
	2BL04310	2BL04310	PLATE NUMBER	8
	2BL04370	2BL04370	PLATE NUMBER 2	8
	2C902590	2C902590	SPRING DEV PUSH F	5
	2C906080	2C906080	GEAR 18 BYPASS	16
	2C906090	2C906090	TERMINAL PAPER SIZE	16
	2C907140	2C907140	PAD CASSETTE	8
	2C907360	2C907360	SPRING CURSOR R	8
	302C994030	2C994030	PARTS PWB MPF SIZE ASSY SP	16
	2FB06710	2FB06710	PIN CASSETTE RAIL	4
	2FB20860	2FB20860	PIN FUSER COVER	7,17
	2FB27160	2FB27160	INTER LOCK SWITCH	3,6
	2FB20860	2FB20860	PIN FUSER COVER	17
	2FM04150	2FM04150	CAP SPRING /B-11 ENCLOSURE A4	12,26
	2FB27160	2FB27160	INTER LOCK SWITCH	6
	3019527401	19527401	POWER CORD(120)	3
	2FM04150	5MVM163DN005	CAP SPRING /B-11 ENCLOSURE A4	26
	3025418011	25418011	KEY COUNTER	33
	3029236241	29236241	SOCKET ASS'Y.KEY COUNTER	33
	302A369709	2A369709	SET PARTS KEYCOUNTER NEW COLOR	33
	302AR94050	2AR94050	PARTS AC CORD EU SP	3
	302BG06152	2BG06152	SHAFT FEED B	12
	302F906230	2F906230	PULLEY FEED ASSY	9
	302F909171	2F909171	RETARD ROLLER ASSY	9
	302F928170	2F928170	SPRING PULLEY	26
	302F929260	2F929260	PULLEY DU LOW	26
	302F944090	2F944090	SOLENOID ASSY	26
	302FB23340	2FB23340	FILM UPPER REAR DUCT	25
	302FB26290	2FB26290	LID VENDOR	7
	302FG07020	2FG07020	PULLEY,CASSETTE RAIL	8
	302FZ02580	2FZ02580	CAP HANDLE	3
	302FZ03110	2FZ03110	SEAL HANDLE	3
	302FZ04240	2FZ04240	LID COVER LEFT	1
	302FZ07020	2FZ07020	PULLEY MPT BYPASS	8
	302FZ20021	2FZ20021	SPRING LID	12
	302FZ25740	2FZ25740	STOPPER 4	3
	302FZ44040	2FZ44040	FAN BOX COOLING	29
	302FZ94420	2FZ94420	PARTS,FAN COOLING CONVEYING SP	30
	302GR02240	2GR02240	PIN FRONT CASSETTE RAIL	4
	302GR03010	2GR03010	RETAINER KEY COUNTER COVER	33
	302GR03020	2GR03020	RETAINER KEY COUNTER	33
	302GR04370	2GR04370	MAGNET CLIP DISH	18

	Part.No.	Alternative.	Description	Fig.No.
	302GR04380	2GR04380	SEAL MAGNET	18
	302H004560	2H004560	STOPPER PAPER	1
	302H004652	2H004652	HOLDER SWITCH	2
	302H004660	2H004660	MAGNET CATCH	27
	302H005340	2H005340	BUSH SLIDE OPE	18
	302H008140	2H008140	SPRING BYPASSFFED	7
	302H024360	2H024360	BUSH 8 EW	10,13
	302H024370	2H024370	BUSH 6 EW	10,26
	302H024360	2H024360	BUSH 8 EW	13
	302H024830	2H024830	BUSH 8	10
	302H024370	2H024370	BUSH 6 EW	26
	302H044110	2H044110	SENSOR ORIGINAL	17
	302H704170	2H704170	COVER MAIN SW	1
	302H708150	2H708150	SPONGE WIRE MPT	16
	302H717500	2H717500	COVER PLATEN	32
	302H717510	2H717510	COVER POCKET	32
	302H717520	2H717520	STOPPER RELEASE SWITCH	32
	302H717600	2H717600	HINGI ORIGINAL HOLDER	32
	302H722470	2H722470	COLLAR TRANS ROLLER	14,15
	302H722690	2H722690	SHEET WIRE CONV E	31
	302H722470	2H722470	COLLAR TRANS ROLLER	15
	302HG12440	2HG12440	SEAL BLADE SIDE B	5
	302HN06080	2HN06080	PULLEY PICKUP ASSY	9
	302HN09240	2HN09240	SIZE FIX	8
	302HN24400	2HN24400	PULLEY PA	10
	302HN31200	2HN31200	GEAR Z35L	5
	302HN31410	2HN31410	SPRING FEED	23,24
	302HN31590	2HN31590	BUSH DRIVE	23,24
	302HN31410	2HN31410	SPRING FEED	24
	302HN31650	2HN31650	SPRING INPUT MPF	24
	302HN31590	2HN31590	BUSH DRIVE	24
	302HN31660	2HN31660	JOINT SHAFT CASSETTE	23,24
	302HN44100	2HN44100	MOTOR REVERSE	17,26
	302HN31660	2HN31660	JOINT SHAFT CASSETTE	24
	302HN44160	2HN44160	SOLENOID MPF	24
	302HN44100	2HN44100	MOTOR REVERSE	26
	302JD19140	2JD19140	BUSHING FAN	29
	302JF02160	2JF02160	HANDLE	3
	302K002750	2K002750	STAY SHIELD POWER	3
	302K302071	2K302071	BASE LSU	4
	302K302120	2K302120	RAIL DRUM	4
	302K302140	2K302140	STAY RIGHT HANDLE	11
	302K302161	2K302161	FRAME FRONT UPPER	4
	302K302170	2K302170	FRAME REAR UPPER	4
	302K302191	2K302191	MOUNT CONTAINER	5
	302K302200	2K302200	SPACER SCANNER ADJUST	7
	302K302210	2K302210	MOUNT SCANNER ADJUST	7
	302K302220	2K302220	MOUNT JUNCTION PWB	6
	302K302240	2K302240	SHEET MOUNT CONTAINER	5
	302K302260	2K302260	COVER INNER BASE	2

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302K302320	2K302320	SHAFT REMOVAL DLP	6
	302K302330	2K302330	CAM REMOVAL DLP	6
	302K302361	2K302361	STOPPER REMOVAL DLP	27
⊙	302K302430	2K302430	HEATER DEHUMIDIFIER 120	3
⊙	302K302440	2K302440	HEATER DEHUMIDIFIER 240	3
	302K302540	2K302540	JOINT CONTAINER PADDLE A	5
	302K302580	2K302580	PLATE DLP BIAS	5
	302K302590	2K302590	SPRING DLP GROUND	5
	302K302600	2K302600	MOUNT DLP PWB	5
	302K302610	2K302610	HOLDER DRUM COVER RIGHT	10
	302K302620	2K302620	HOLDER DRUM COVER LEFT	10
	302K302630	2K302630	SHEET DRUM COVER	10
	302K302640	2K302640	GUIDE DRUM COVER	4
	302K302660	2K302660	SPRING EARTH DRUM PWB	6
	302K302670	2K302670	ARM DRUM COVER FRONT	10
	302K302680	2K302680	ARM DRUM COVER REAR	10
	302K302690	2K302690	RAIL HOLDER FRONT	4
	302K302700	2K302700	RAIL HOLDER REAR	4
	302K302710	2K302710	RAIL LINK ARM F	10
	302K302720	2K302720	RAIL LINK ARM R	10
⊙	302K302730	2K302730	COVER CONNECTOR	6
	302K302740	2K302740	SPRING EARTH CONNECTOR	6
	302K302760	2K302760	LEVER LIFT CASSETTE	4
	302K302771	2K302771	PLATE STOPPER REMOVAL	27
	302K302780	2K302780	SPRING JOINT PADDLE	5
	302K302811	2K302811	ACTUATOR PAPER EMPTY	4
	302K302831	2K302831	ACTUATOR DECK FEED	10
	302K302840	2K302840	MOUNT DECK PI	3
	302K302850	2K302850	PIN JOINT CONTAINER B	5
	302K302860	2K302860	PIN JOINT CONTAINER C	5
	302K302890	2K302890	LID DEHUMIDIFIER SW	7
	302K302910	2K302910	MOUNT DECK DRAWER	3
	302K302920	2K302920	CAP DECK PIN	3
	302K302940	2K302940	MOUNT RIGHT INTERLOCK	7
	302K302960	2K302960	STOPPER CONTAINER	4
	302K302990	2K302990	SPRING STOPPER DLP B	27
	302K302A10	2K302A10	LEVER RIGHT SW	4
	302K302A40	2K302A40	PLATE CONTAINER SWITCH	5
	302K302A50	2K302A50	PLATE EARTH ISU	7
	302K302A60	2K302A60	SPRING DLP PUSH	5
	302K302A70	2K302A70	SPONGE DLP LEVER	5
⊙	302K304030	2K304030	COVER TRAY	1
	302K304230	2K304230	STRAP COVER FRONT R	27
	302K304270	2K304270	LEVER CONTAINER	27
	302K304280	2K304280	STOPPER CONTAINER	27
	302K304300	2K304300	SPRING LEVER CONTAINER	27
	302K304320	2K304320	STRAP COVER FRONT L	27
	302K304350	2K304350	COVER INNER FRONT SUB	6
	302K304360	2K304360	SPRING STOPPER CONTAINER	27
	302K304370	2K304370	STOPPER PAPER B	1

	Part.No.	Alternative.	Description	Fig.No.
	302K304520	2K304520	HOOK RIGHT COVER	13
	302K304531	2K304531	GUIDE RIGHT COVER	13
	302K304540	2K304540	SPRING HOOK	13
	302K304550	2K304550	SHAFT RIGHT COVER F	14
	302K304560	2K304560	SHAFT RIGHT COVER R	14
	302K304571	2K304571	JOINT JUNCTION HOOK	13
	302K304591	2K304591	STRAP RIGHT COVER	13
	302K304630	2K304630	FILM CONVEYING SHAFT	14
	302K306140	2K306140	ACTUATOR REGIST	10
	302K306150	2K306150	SPRING ACTUATOR REGIST	10
	302K306140	2K306140	ACTUATOR REGIST	10
	302K306160	2K306160	SHEET REGIST LEFT	10
	302K306150	2K306150	SPRING ACTUATOR REGIST	10
	302K308020	2K308020	ACTUATOR MPF	11
	302K308030	2K308030	GUIDE UPPER MPF	11
	302K308070	2K308070	BUSH 10	11
	302K308080	2K308080	SHAFT MPF	11
	302K308101	2K308101	LIFT PLATE	11
	302K308110	2K308110	PAD LIFT	11
	302K308120	2K308120	SPRING LIFT R	11
	302K308130	2K308130	SPRING LIFT F	11
	302K308140	2K308140	ARM LIFT	11
⊙	302K308150	2K308150	ROLLER MPF	11
	302K308240	2K308240	SPRING EARTH	11
	302K308250	2K308250	SPRING ACTUATOR	11
	302K308260	2K308260	WIRE EARTH MPF	11
	302K308270	2K308270	SPRING MPF ROLL	11
	302K308340	2K308340	SEAL GUIDE PAD	11
	302K308470	2K308470	STOPPER STRAP	16
	302K308480	2K308480	SEAL SIDE MPF	11
	302K309070	2K309070	PULLEY CASSETTE	5
	302K309141	2K309141	SLIDER CURSOR END	8
	302K309150	2K309150	LIFT BASE CASSETTE SUB	8
	302K309160	2K309160	SPRING LEVER LIFT CASSETTE SUB	8
	302K309170	2K309170	PLATE LIFT BASE CASSETTE	8
	302K309180	2K309180	SHAFT DRIVE LIFT	8
	302K309190	2K309190	LEVER CURSOR SET	8
	302K309200	2K309200	LEVER RELEASE CURSOR F	8
	302K309210	2K309210	SPRING RELEASE CURSOR F	8
	302K309220	2K309220	SPRING SIDE SWITCH	8
	302K309270	2K309270	CURSOR END	8
	302K309300	2K309300	SPRING CASSETTE LIFT EARTH	8
	302K309350	2K309350	STOPPER SIZE SET	8
	302K309360	2K309360	SPRING SIZE SET	8
	302K309370	2K309370	SPRING CURSOR SET	8
	302K309380	2K309380	SPRING SIZE SET F	8
	302K309410	2K309410	PLATE SIZE DETECTION	3
	302K312080	2K312080	STOPPER DRUM	10
	302K317140	2K317140	WIRE SCANNER BLACK	17
	302K317150	2K317150	WIRE SCANNER GRAY	17

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
⊙	302K317172	2K317172	GUIDE FFC LED C	17
	302K317350	2K317350	GEAR Z54	17
	302K317470	2K317470	MOUNT LED	17
	302K317791	2K317791	SHEET FFC LED	17
	302K324011	2K324011	BASE CONVEYING	14
	302K324020	2K324020	ROLLER TRANSFER	15
	302K324030	2K324030	HOLDER TRANSFER	15
	302K324060	2K324060	LEVER CONVEYING F	14
	302K324070	2K324070	LEVER CONVEYING R	14
	302K324080	2K324080	TERMINAL TRANSFER	14
	302K324090	2K324090	TERMINAL SEPARATION A	14
	302K324100	2K324100	HOLDER SEPARATION	15
	302K324110	2K324110	SPRING CONVEYING F	14
	302K324130	2K324130	SPRING EARTH CONVEYING	14
	302K324150	2K324150	PLATE SEPARATION	15
	302K324160	2K324160	GUIDE TRANS LEFT	10
⊙	302K324170	2K324170	GEAR TRANSFER Z18L	15
	302K324180	2K324180	BUSH REGIST F	14
	302K324200	2K324200	SPRING REGIST F	14
	302K324210	2K324210	SPRING TRANSFER F	15
	302K324230	2K324230	SPRING GUIDE TRANSFER	15
	302K324240	2K324240	BUSH TRANSFER ROLL F	15
	302K324250	2K324250	HOOK TRANSFER F	15
	302K324260	2K324260	HOOK TRANSFER R	15
	302K324270	2K324270	BUSH REGIST R	14
	302K324280	2K324280	LEVER TRANSFER	15
	302K324290	2K324290	FILM GUIDE REGIST	14
	302K324310	2K324310	SPRING EARTH REGIST A	10
	302K324322	2K324322	COVER HARNESS	14
	302K324340	2K324340	TERMINAL SEPARATION B	14
	302K324350	2K324350	SPRING EARTH REGIST B	10
	302K324360	2K324360	SPRING CONVEYING R	14
	302K324370	2K324370	SPRING TRANSFER R	15
	302K324380	2K324380	SPRING EARTH REGIST C	10
	302K324410	2K324410	SPRING EARTH REGIST D	10
	302K324430	2K324430	BUSH TRANSFER ROLL R	15
	302K324440	2K324440	SPRING REGIST R	14
	302K324460	2K324460	SHAFT FEED	26
	302K324470	2K324470	BUSH REGIST C	14
	302K324500	2K324500	SPRING REGIST C	14
	302K324510	2K324510	SPRING TRANSFER LIFT	14
	302K324520	2K324520	SHEET TRANSFER RIGHT	15
	302K325340	2K325340	MOUNT FUSER FRONT	4
	302K325350	2K325350	ADJUSTER FUSER	4
	302K328011	2K328011	BASE CONVEYING EXIT	26
	302K328020	2K328020	FRAME EXIT UPPER	26
	302K328030	2K328030	FRAME EXIT LOWER	26
	302K328050	2K328050	GUIDE CHANGE	26
	302K328090	2K328090	GUIDE EXIT PUSH	26
	302K328100	2K328100	GUIDE EXIT MIDDLE	26

	Part.No.	Alternative.	Description	Fig.No.
	302K328110	2K328110	PLATE EXIT MOTOR	26
	302K328150	2K328150	SPRING SOLENOID	26
	302K328160	2K328160	ARM ACTUATOR EXIT	26
	302K328170	2K328170	SPRING EXIT EARTH	26
	302K328181	2K328181	LID EXIT EMPTY SWITCH	26
	302K328200	2K328200	GUIDE EXIT RIGHT	13
	302K328210	2K328210	WIRE EXIT ROLLER EARTH	26
	302K328220	2K328220	CUSHION GUIDE CHANGE A	26
	302K328240	2K328240	CUSHION GUIDE CHANGE B	26
	302K328250	2K328250	STATIC-ELIMINATOR EXIT	26
	302K328260	2K328260	SPRING GUIDE EXIT PUSH	26
	302K328270	2K328270	SPRING EXIT FUSER SWITCH	26
	302K328290	2K328290	GUIDE EXIT PUSH JS	26
⊙	302K328300	2K328300	TRAY EJECT	1
	302K328321	2K328321	GUIDE EXIT OVERFLOW JS_A	26
	302K328330	2K328330	PULLEY FEED 6	26
⊙	302K329010	2K329010	FRAME DU	14
	302K329020	2K329020	PULLEY DU	13,14
	302K329030	2K329030	SPRING DU FEED	13,14
	302K329020	2K329020	PULLEY DU	14
	302K329040	2K329040	ACTUATOR DU	14
	302K329030	2K329030	SPRING DU FEED	14
	302K329060	2K329060	RETAINER ACTUATOR	14
	302K329220	2K329220	SHAFT DU	13
	302K329230	2K329230	WIRE EARTH DU	13
	302K329240	2K329240	BELT DU A	13
	302K329250	2K329250	BELT DU B	13
	302K329270	2K329270	BUSH DU	10,13
	302K329280	2K329280	PULLEY DU 26	13
	302K329270	2K329270	BUSH DU	13
⊙	302K331030	2K331030	PLATE DRIVE	24
⊙	302K331040	2K331040	GEAR Z191R	24
⊙	302K331050	2K331050	GEAR Z112R-Z37L	24
⊙	302K331060	2K331060	GEAR Z38R	24
⊙	302K331070	2K331070	GEAR Z29L INPUT DLP	24
⊙	302K331081	2K331081	GEAR Z40R IDLE	23,24
⊙	302K331090	2K331090	GEAR Z43L IDLE	24
⊙	302K331081	2K331081	GEAR Z40R IDLE	24
⊙	302K331100	2K331100	GEAR RATCHET Z28S	24
⊙	302K331110	2K331110	GEAR INPUT FUSER Z30S	24
⊙	302K331120	2K331120	GEAR Z101L-Z33L	24
⊙	302K331140	2K331140	GEAR Z30R IDLE	24
⊙	302K331150	2K331150	GEAR Z42R-Z36R	24
⊙	302K331160	2K331160	GEAR Z48R-Z22S	24
⊙	302K331170	2K331170	GEAR Z28S	24
⊙	302K331180	2K331180	GEAR Z45S INPUT MPF A	24
⊙	302K331190	2K331190	GEAR Z45S INPUT MPF B	24
	302K331200	2K331200	CAM MPF	24
	302K331210	2K331210	SPRING JOINT DLP	24
	302K331220	2K331220	SPRING RATCHET FUSER	24

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302K331230	2K331230	BUSH DRIVE 8	24
	302K331240	2K331240	SHAFT CLUTCH FEED	23,24
	302K331250	2K331250	SPRING EARTH MOTOR	24
	302K331240	2K331240	SHAFT CLUTCH FEED	24
	302K331260	2K331260	PIN DRIVE A	24
	302K333010	2K333010	DUCT MAIN UPPER	25
	302K333020	2K333020	DUCT MAIN LOWER	25
	302K333030	2K333030	DUCT SEPARATION	25
	302K333040	2K333040	DUCT REAR UPPER	25
	302K333050	2K333050	DUCT REAR LOWER	25
	302K334170	2K334170	LABEL TONER CONTAINER PULL	27
	302K339050	2K339050	PLATE OPTION	29
	302K339060	2K339060	BASE TERMINAL	4
	302K339070	2K339070	TERMINAL DRUM A	4
	302K339080	2K339080	TERMINAL DLP A	4
	302K339090	2K339090	TERMINAL TRANSFER A	4
	302K339100	2K339100	TERMINAL SEPARATION A	4
	302K345120	2K345120	VARISTOR TC	10
	302K346010	2K346010	WIRE SOL/CLT/MOT	24
	302K346020	2K346020	WIRE EJECT UNIT	26
	302K346030	2K346030	WIRE FUSER JAM SENS	28
	302K346040	2K346040	WIRE MAIN MOT	24
	302K346070	2K346070	WIRE RIGHT COVER SW	7
	302K346090	2K346090	WIRE DU	14
	302K346270	2K346270	WIRE REGIST	5
	302K346470	2K346470	WIRE PF DRAWER	3
	302K346480	2K346480	WIRE EJECT FAN	28
	302K346570	2K346570	WIRE SUB	28
	302K346660	2K346660	WIRE PF DRAWER 200	3
⊙	302K393130	2K393130	WT-475	21
⊙	302K394070	2K394070	PARTS PWB RFID ASSY SP	5
⊙	302K394080	2K394080	PARTS PWB DRUM CONNECT ASSY SP	6
⊙	302K394090	2K394090	PARTS PWB DEVE CONNECT ASSY SP	5
⊙	302K394180	2K394180	PARTS SWITCH EXIT PAPER EMPTY SP	26
⊙	302K394190	2K394190	PARTS MOTOR LIFT ASSY SP	23
⊙	302K394201	2K394201	PARTS MOTOR-BL W30 SP	24
⊙	302K394220	2K394220	PARTS ROLLER REGIST RIGHT SP	14
⊙	302K394230	2K394230	PARTS ROLLER REGIST LEFT SP	10
⊙	302K394240	2K394240	PARTS ROLLER EXIT SP	26
⊙	302K394250	2K394250	PARTS ROLLER DU SP	13
⊙	302K394270	2K394270	PARTS GEAR CONTAINER Z25L SP	5
⊙	302K394280	2K394280	PARTS GEAR CONTAINER Z35R SP	5
⊙	302K394310	2K394310	PARTS GEAR REGIST Z28L-Z18L SP	10
⊙	302K394320	2K394320	PARTS GEAR MPF Z28 SP	11
⊙	302K394330	2K394330	PARTS GEAR REGIST Z24R SP	14
⊙	302K394340	2K394340	PARTS GEAR Z74R-Z22S EXIT SP	26
⊙	302K394350	2K394350	PARTS GEAR Z22S EXIT SP	26
⊙	302K394360	2K394360	PARTS GEAR Z25S EXIT INPUT SP	26
⊙	302K394370	2K394370	PARTS GEAR Z18-Z63R SP	17
⊙	302K394380	2K394380	PARTS GEAR Z18 SP	8

	Part.No.	Alternative.	Description	Fig.No.
⊙	302K394400	2K394400	PARTS GEAR DU Z27L SP	13
⊙	302K394540	2K394540	PARTS FEED UNIT ASSY SP	10
	302K905900	2K905900	SPRING USB HOLD	18,31
⊙	302K906240	2K906240	GEAR FEED DRIVE Z20L	5
	302K905900	2K905900	SPRING USB HOLD	31
	302K906670	2K906670	HOOK FEED LOW	12
	302K908211	2K908211	ACTUATOR SIZE DETECTION	16
	302K908220	2K908220	SPRING-TORSION SIZE DETECTION	16
	302K908580	2K908580	HOLDER SIZE DETECTION	16
	302K909630	2K909630	SHAFT HOOK PULLEY	3
	302K909640	2K909640	LEVER CASSETTE HOOK	3
	302K933C10	2K933C10	SEAL TONER EXIT E	30
	302K939030	2K939030	RAIL PWB	29
	302K946750	2K946750	WIRE ORIGINAL SENSOR	17
⊙	302K994270	2K994270	PARTS PWB KUJO ASSY SP	29
⊙	302KK94070	2KK94070	PARTS CONT SENSOR ASSY SP	5
	302KP34220	2KP34220	LABEL HIGH TEMPERATURE CAUTION	3
⊙	302KV31320	2KV31320	GEAR Z32L	24
⊙	302KV44041	2KV44041	CLUTCH 50 Z35R	23,24
	302LC04272	2LC04272	EMBLEM	2
⊙	302KV44041	2KV44041	CLUTCH 50 Z35R	24
⊙	302LC04340	2LC04340	COVER ISU LEFT SUB	18
⊙	302LC04601	2LC04601	COVER TRAY	33
	302LC04611	2LC04611	STAY TRAY	33
	302LC04621	2LC04621	MOUNT TRAY	33
	302LC04660	2LC04660	SHEET TRAY	33
	302LC04670	2LC04670	PLATE TRAY	33
⊙	302LC04710	2LC04710	COVER TRAY LOWER	33
⊙	302LC05050	2LC05050	KEY 10	31
	302LC05100	2LC05100	KEY STOP	31
	302LC05110	2LC05110	KEY RESET	31
	302LC05270	2LC05270	HOLDER LCD	31
	302LC05420	2LC05420	FILM FFC	31
	302LC31511	2LC31511	SEAL MOTOR DC	25,29
	302LC34031	2LC34031	LABEL OPERATION CAUTION B	18
	302LC31511	2LC31511	SEAL MOTOR DC	29
	302LC34620	2LC34620	LABEL SW CAUTION EN	1
	302LC34630	2LC34630	LABEL SW CAUTION SET A	1
⊙	302LC94291	2LC94291	PARTS MOTOR-BL W10 SP	23
⊙	302LC94370	2LC94370	PARTS SPEAKER SP	31
	302LF33B10	2LF33B10	SPONGE LOWER RIGHT SP	3
	302LF39050	2LF39050	GUIDE WIRE FRONT PWB	29
⊙	302LH94230	2LH94230	PARTS MEMORY MODULE SP	29
	302MN04100	2MN04100	LID DF CONNECTOR	1
	302MV02040	2MV02040	STAY FRONT FRAME	4
	302MV02092	2MV02092	MOUNT SCANNER RIGHT	7
	302MV02110	2MV02110	MOUNT SCANNER REAR	7
	302MV02131	2MV02131	MOUNT OPTION	7
	302MV02160	2MV02160	HANDLE COVER LEFT	5
	302MV02190	2MV02190	FOOT	1

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302MV02220	2MV02220	SHAFT HANDLE	3
	302MV02231	2MV02231	MOUNT REAR HANDLE	3
	302MV02240	2MV02240	PIN FRONT HANDLE	3
	302MV02310	2MV02310	SPRING LEVER LIFT CASSETTE	4
⊙	302MV04230	2MV04230	COVER INNER FRONT LOWER	1
	302MV04290	2MV04290	COVER EXIT FRONT TOP	7
	302MV04300	2MV04300	COVER RIGHT HOOK	13
	302MV05050	2MV05050	MOUNT USB	31
	302MV05090	2MV05090	FILM COVER LOW	31
	302MV07020	2MV07020	GUIDE FEED LOW	10
	302MV07030	2MV07030	GUIDE FEED	10
	302MV07040	2MV07040	GUIDE FEED INNER	11
	302MV07051	2MV07051	GUIDE COVER INNER	12
	302MV07070	2MV07070	HOLDER SPRING	12
	302MV07080	2MV07080	COVER SW FEED	12
	302MV07110	2MV07110	BELT FEED	10
	302MV07120	2MV07120	SPRING EARTH FEED	10
	302MV08010	2MV08010	BASE MPF	11
	302MV08020	2MV08020	PIN FEED ROLL	11
⊙	302MV08030	2MV08030	PULLEY MPF	11
⊙	302MV08050	2MV08050	COVER MPF WIRE	11
⊙	302MV08400	2MV08400	COVER MPF	16
	302MV08410	2MV08410	TABLE MPF	16
	302MV08420	2MV08420	TABLE MPF A	16
	302MV08430	2MV08430	TABLE MPF B	16
	302MV08441	2MV08441	CURSOR FRONT MPF	16
	302MV08451	2MV08451	CURSOR REAR MPF	16
	302MV08460	2MV08460	GUIDE FRONT MPF WIRE	16
	302MV08470	2MV08470	GUIDE REAR MPF WIRE	16
	302MV08500	2MV08500	SPRING MPF	16
	302MV08520	2MV08520	SHEET MPF WIRE A	16
	302MV09021	2MV09021	BASE CASSETTE	8
	302MV09040	2MV09040	ARM SIZE DETECTION	8
	302MV09050	2MV09050	PLATE SIDE SWITCH	8
	302MV09080	2MV09080	CURSOR CASSETTE REAR	8
	302MV09090	2MV09090	CURSOR CASSETTE FRONT	8
	302MV17030	2MV17030	COVER LENS	17
	302MV17040	2MV17040	GUIDE FFC CCD	17
	302MV17110	2MV17110	FILM FFC CCD	17
	302MV24010	2MV24010	LEVER HOOK F	15
	302MV24020	2MV24020	LEVER HOOK R	15
	302MV31010	2MV31010	HOLDER DRIVE LOW A	23
	302MV31020	2MV31020	HOLDER DRIVE LOW B	23
	302MV31030	2MV31030	PLATE MOTOR LOW	23
	302MV31040	2MV31040	SPRING EARTH FEED LOW	23
	302MV34180	2MV34180	LABEL I	15
	302MV34190	2MV34190	LABEL J	11
	302MV34250	2MV34250	LABEL COVER CAUTION	13
	302MV34260	2MV34260	LABEL BYPASS CAUTION	13
	302MV34270	2MV34270	LABEL BYPASS TABLE	16

	Part.No.	Alternative.	Description	Fig.No.
	302MV34300	2MV34300	SHEET CASSETTE C	8
	302MV34310	2MV34310	LABEL CASSETTE SIZE A	8
	302MV34320	2MV34320	LABEL OPERATION CURSOR	8
	302MV34330	2MV34330	LABEL OPERATION L	8
	302MV34340	2MV34340	LABEL OPERATION S	8
	302MV34350	2MV34350	LABEL PAPER SET	8
	302MV34360	2MV34360	LABEL CASSETTE SIZE B	8
	302MV34370	2MV34370	LABEL PAPER LIMIT	8
	302MV34400	2MV34400	LABEL HIGH TEMP	13
	302MV34410	2MV34410	LABEL COVER CAUTION 9NATIONS	13
	302MV34430	2MV34430	SHEET CASSETTE I	8
	302MV39040	2MV39040	BRACKET HDD	29
	302MV39050	2MV39050	HOLDER FAN MAIN	29
	302MV39250	2MV39250	BRACKET FAN POWER	30
	302MV39340	2MV39340	PIN HDD	29
	302MV39350	2MV39350	SPRING EARTH HDD	29
	302MV46090	2MV46090	WIRE KEY COUNTER	33
	302MV46210	2MV46210	WIRE HDD POWER	29
	302MV46220	2MV46220	WIRE CCD DATA	29
	302MV46230	2MV46230	WIRE ISC-MAIN SIG	29
	302MV46450	2MV46450	WIRE MPF SIZE UNIT 1	11
	302MV46510	2MV46510	WIRE MPF SIZE UNIT 2	16
	302MV46520	2MV46520	WIRE RIGHT COVER SW	12
	302MV46580	2MV46580	WIRE MPF	11
	302MV46600	2MV46600	WIRE CCD POWER	17
	302MV46630	2MV46630	WIRE FFC LED	17
⊙	302MV93110	2MV93110	DR-8315D	23
⊙	302MV93130	2MV93130	PARTS STORAGE DEVICE SP	29
⊙	302MV94010	2MV94010	PARTS PAD SEPARATION ASSY SP	11
⊙	302MV94020	2MV94020	PARTS ROLLER MPF ASSY SP	11
⊙	302MV94061	2MV94061	PARTS PRIMARY FEED ASSY SP	9
⊙	302MV94070	2MV94070	PARTS MPF UNIT SP	11
⊙	302MV94100	2MV94100	PARTS CONTACT-GLASS ASSY(I) SP	17
⊙	302MV94110	2MV94110	PARTS CONTACT-GLASS ASSY(C) SP	17
⊙	302MV94310	2MV94310	PARTS ROLLER FEED UPPER SP	10
⊙	302MV94320	2MV94320	PARTS ROLLER FEED LOWER SP	10
	302MW31010	2MW31010	TORQUE LIMITER 4000	5
	302N205190	2N205190	KEY START B	31
⊙	302N404040	2N404040	LID CARD	18
⊙	302N404130	2N404130	CASE CLIP	18
⊙	302N404241	2N404241	LID USB FRONT	18
	302N405070	2N405070	KEY FUNCTION	31
	302N405080	2N405080	KEY MENU	31
	302N405090	2N405090	KEY POWER	31
	302N405100	2N405100	KEY HOME	31
	302N405110	2N405110	KEY DISPLAY	31
	302N405120	2N405120	KEY RIGHT SIDE	31
⊙	302N405140	2N405140	LID OPERATION SHEET A	31
⊙	302N405150	2N405150	LID OPERATION SHEET B	31
	302N405200	2N405200	LENS LED	31

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302N405210	2N405210	FILM LCD WIRE	31
	302N405241	2N405241	SPONGE LCD A	31
	302N405251	2N405251	SPONGE LCD B	31
	302N405260	2N405260	SPACER LCD A	31
	302N405270	2N405270	SPACER LCD B	31
	302N446050	2N446050	WIRE FFC KEY PWB	31
⊙	302N494090	2N494090	PARTS LCD OPERATION SP	31
⊙	302N494100	2N494100	PARTS TABLET OPERATION SP	31
⊙	302N494150	2N494150	PARTS PWB PANEL MAIN ASSY SP	31
⊙	302N494180	2N494180	PARTS PWB OPERATION ASSY SP	31
⊙	302N494220	2N494220	PARTS CURSOR SCREW SET SP	33
⊙	302N905010	2N905010	PANEL OPERATION	31
	302N905510	2N905510	SHEET OPERATION EN	31
	302N905530	2N905530	SHEET OPERATION DE	34
	302N905540	2N905540	SHEET OPERATION FR	34
	302N905550	2N905550	SHEET OPERATION TL	34
	302N905560	2N905560	SHEET OPERATION ES	34
	302N905570	2N905570	SHEET OPERATION PT	34
	302N905580	2N905580	SHEET OPERATION NL	34
	302N905590	2N905590	SHEET OPERATION RU	34
	302N905630	2N905630	SHEET OPERATION KDA EN	31
	302N905640	2N905640	SHEET OPERATION KDA FR	34
	302N905650	2N905650	SHEET OPERATION KDA ES	34
	302N905660	2N905660	SHEET OPERATION KDA PT	34
⊙	302NG94220	2NG94220	PARTS FAN MOTOR SP	25
	302NL02040	2NL02040	BASE MIDDLE	5
	302NL02060	2NL02060	STAY REAR FRAME	4
	302NL02070	2NL02070	GUIDE FUSER	4
	302NL02080	2NL02080	BRACKET DRAWER	4
	302NL02090	2NL02090	RAIL CASSETTE LEFT	4
	302NL02100	2NL02100	JOINT FUSER	4
	302NL02120	2NL02120	RAIL DLP	5
	302NL02140	2NL02140	SHEET RAIL	5
	302NL02150	2NL02150	COVER RAIL DRIVE	5
	302NL02160	2NL02160	COVER RAIL DLP	5
⊙	302NL02170	2NL02170	GEAR CONTAINER Z42R	5
⊙	302NL02180	2NL02180	GEAR Z22R 40R	5
	302NL02190	2NL02190	SLIDER REMOVAL DLP	5
	302NL02200	2NL02200	MOUNT INTERLOCK SW	6
	302NL02210	2NL02210	RAIL CASSETTE RIGHT	4
	302NL02220	2NL02220	HOLDER SENSOR	5
⊙	302NL02230	2NL02230	GEAR Z23L	5
	302NL02241	2NL02241	MOUNT SCANNER FRONT	7
	302NL02310	2NL02310	LEVER REMOVAL DLP	6
	302NL02320	2NL02320	LEVER HOOK REMOVAL	27
	302NL02340	2NL02340	SHEET BASE MIDDLE	5
	302NL02360	2NL02360	SHEET SCANNER FRONT	7
⊙	302NL04020	2NL04020	COVER FRONT TOP	1
⊙	302NL04040	2NL04040	COVER EXIT REAR	1
⊙	302NL04060	2NL04060	COVER RIGHT REAR	1

	Part.No.	Alternative.	Description	Fig.No.
⊙	302NL04090	2NL04090	COVER RIGHT TOP	1
⊙	302NL04100	2NL04100	COVER LEFT LOW	1
⊙	302NL04110	2NL04110	COVER LEFT TOP	1
⊙	302NL04120	2NL04120	COVER ISU FRONT	18
⊙	302NL04131	2NL04131	COVER ISU LEFT	18
⊙	302NL04140	2NL04140	COVER ISU RIGHT	18
⊙	302NL04150	2NL04150	COVER ISU REAR	18
⊙	302NL04180	2NL04180	COVER TRAY LEFT	1
⊙	302NL04190	2NL04190	COVER EXIT TOP	6
	302NL04200	2NL04200	LID CONTROLLER	1
⊙	302NL04210	2NL04210	LID DP	18
⊙	302NL04220	2NL04220	LID ISU FRONT	18
	302NL04230	2NL04230	MOUNT USB	18
	302NL04240	2NL04240	COVER INNER FRONT	27
	302NL04250	2NL04250	LID AK	1
	302NL04260	2NL04260	COVER HOLDER BOX	27
	302NL04270	2NL04270	PLATE MAGNET	2
	302NL04310	2NL04310	COVER FILTER REAR	1
	302NL04331	2NL04331	COVER RIGHT MIDDLE	13
⊙	302NL04340	2NL04340	COVER RIGHT LOW	12
⊙	302NL05010	2NL05010	COVER OPERATION A	31
⊙	302NL05020	2NL05020	COVER OPERATION B	31
	302NL05030	2NL05030	MOUNT MAIN PWB	31
	302NL05040	2NL05040	GUIDE WIRE OPERATION	31
	302NL05050	2NL05050	MOUNT OPERATION	31
	302NL06010	2NL06010	HOLDER SENSOR	4
	302NL06020	2NL06020	GUIDE FEED OUTER	10
	302NL06040	2NL06040	HOLDER HOOK F	12
	302NL06050	2NL06050	HOLDER HOOK R	12
	302NL06060	2NL06060	COVER HANDLE	12
	302NL06070	2NL06070	SHAFT FEED LOW HOOK	12
	302NL06080	2NL06080	SHEET FEED OUT A	10
	302NL09010	2NL09010	CASSETTE	8
	302NL09020	2NL09020	HOLDER CASSETTE HOOK	3
⊙	302NL09030	2NL09030	PULLEY CASSETTE RAIL	4
⊙	302NL09050	2NL09050	COVER CASSETTE	8
	302NL09060	2NL09060	SPRING CASSETTE HOOK	3
	302NL09070	2NL09070	EMBLEM CASSETTE	8
	302NL09080	2NL09080	HANDLE CASSETTE	8
	302NL09090	2NL09090	PLATE CASSETTE LEFT	8
	302NL09100	2NL09100	PLATE CASSETTE RIGHT	8
⊙	302NL09130	2NL09130	PULLEY CASSETTE RAIL	4
	302NL17010	2NL17010	MOUNT DRIVE	17
	302NL17020	2NL17020	SWITCH RELEASE	17
	302NL17030	2NL17030	HOLDER SWITCH	17
	302NL17040	2NL17040	MOUNT ISC	17
	302NL17050	2NL17050	MOUNT DP	17
	302NL17070	2NL17070	MOUNT JUNCTION PWB	17
	302NL24040	2NL24040	GUIDE FEED JUNCTION	14
	302NL24050	2NL24050	FILM GUIDE FEED JUNCTION	14

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
	302NL24090	2NL24090	GUIDE CONVEYING	14
	302NL24110	2NL24110	GUIDE TRANSFER RIGHT B	15
	302NL28020	2NL28020	ACTUATOR EXIT JS	26
	302NL28030	2NL28030	GUIDE EXIT OVERFLOW JS INCH	26
	302NL28040	2NL28040	CUSHION GUIDE CHANGE	26
	302NL28050	2NL28050	PLATE EXIT OVERFLOW	26
	302NL28060	2NL28060	ACTUATOR EXIT OVERFLOW	26
	302NL31010	2NL31010	HOLDER FEED DRIVE A	24
	302NL31020	2NL31020	HOLDER FEED DRIVE B	24
⊙	302NL31030	2NL31030	GEAR Z21L Z26R	24
	302NL31040	2NL31040	PIN DRIVE	24
	302NL31050	2NL31050	SHAFT DU	24
	302NL34010	2NL34010	SHEET EMBLEM	2
	302NL34050	2NL34050	SHEET COVER FRONT	2
	302NL34060	2NL34060	LABEL PUSH STOPPER	27
	302NL34070	2NL34070	LABEL ARROW STOPPER	27
	302NL34080	2NL34080	LABEL D	6
	302NL34090	2NL34090	LABEL DEHUMIDIFIER SWITCH	1
	302NL34100	2NL34100	LABEL BOTTLE WASTE	27
	302NL34110	2NL34110	LABEL W1	27
	302NL34140	2NL34140	LABEL MPF CAUTION	16
	302NL39010	2NL39010	BOX CONTROLLER	29
	302NL39020	2NL39020	BOX POWER	30
	302NL39030	2NL39030	LID POWER	30
	302NL39040	2NL39040	MOUNT INLET	7
	302NL39050	2NL39050	GUIDE WIRE REAR	4
	302NL39060	2NL39060	GUIDE WIRE MAIN SW	3
	302NL39070	2NL39070	MOUNT BOX	7
	302NL39080	2NL39080	MOUNT DF CONNECTOR	7
	302NL39090	2NL39090	BRACKET MAIN	29
	302NL39100	2NL39100	LID CONTROLLER	29
	302NL39110	2NL39110	LID DP	29
	302NL39120	2NL39120	LID FAX BOARD	29
	302NL46010	2NL46010	WIRE LSU	28
	302NL46020	2NL46020	WIRE CONVEYING JOINT	28
	302NL46030	2NL46030	WIRE FEED DRIVE	23
	302NL46040	2NL46040	WIRE CASSETTE SWITCH	28
	302NL46050	2NL46050	WIRE MAIN-LVU	29
	302NL46060	2NL46060	WIRE ENGINE-LVU	28
	302NL46070	2NL46070	WIRE CONTAINER RAIL	5
	302NL46080	2NL46080	WIRE CONTAINER SET	5
	302NL46090	2NL46090	WIRE FRONT SWITCH	28
	302NL46100	2NL46100	WIRE PF JOINT	28
	302NL46110	2NL46110	WIRE DF JOINT	7
	302NL46120	2NL46120	WIRE BRIDGE JOINT	4
	302NL46150	2NL46150	WIRE FUSER HEATER	4
	302NL46180	2NL46180	WIRE JOB SEPARATOR JOINT	28
	302NL46190	2NL46190	WIRE PANEL DATA	31
	302NL46200	2NL46200	WIRE MAIN-OPERATION	31
	302NL46210	2NL46210	WIRE USB HOST	31

	Part.No.	Alternative.	Description	Fig.No.
	302NL46230	2NL46230	WIRE USB KEYBOARD	18
	302NL46240	2NL46240	WIRE USB CARD READER	18
	302NL46250	2NL46250	WIRE FFC MAIN-ENGINE	28
	302NL46270	2NL46270	WIRE MAIN SWITCH	4
	302NL46280	2NL46280	WIRE CASSETTE HEATER JOINT	3
	302NL46290	2NL46290	WIRE HEATER SWITCH	7
	302NL46300	2NL46300	WIRE INLET ASSY	7
	302NL46360	2NL46360	WIRE FFC HVU	28
	302NL46370	2NL46370	WIRE LIMIT SENSOR	4
	302NL46380	2NL46380	WIRE FFC CCD	17
⊙	302NL93010	2NL93010	DR-7105	24
⊙	302NL93020	2NL93020	DK-7105	21
⊙	302NL93030	2NL93030	DV-7105	20
⊙	302NL93040	2NL93040	LK-7105	19
⊙	302NL93060	2NL93060	FK-7107	22
⊙	302NL93070	2NL93070	FK-7105	22
⊙	302NL93080	2NL93080	MC-7105	21
⊙	302NL93090	2NL93090	TR-7105	15
⊙	302NL94011	2NL94011	PARTS COVER FRONT ASSY 35 SP	2
⊙	302NL94020	2NL94020	PARTS COVER REAR ASSY SP	1
⊙	302NL94031	2NL94031	PARTS OPERATION UNIT SP	31
⊙	302NL94040	2NL94040	PARTS CLEANER REGIST ASSY SP	27
⊙	302NL94050	2NL94050	PARTS EXIT UNIT SP	26
⊙	302NL94060	2NL94060	PARTS EXIT UNIT J SP	26
⊙	302NL94070	2NL94070	PARTS CONVEYING UNIT SP	14
⊙	302NL94080	2NL94080	PARTS COVER RIGHT ASSY SP	13
⊙	302NL94090	2NL94090	PARTS LOW VOLTAGE 100 SP	30
⊙	302NL94100	2NL94100	PARTS LOW VOLTAGE 200 SP	30
⊙	302NL94110	2NL94110	PARTS HIGH VOLTAGE SP	28
⊙	302NL94120	2NL94120	PARTS PWB ENGINE ASSY SP	28
⊙	302NL94131	2NL94131	PARTS PWB MAIN ASSY SP	29
⊙	302NL94141	2NL94141	PARTS PWB MAIN ASSY EU SP	29
⊙	302NL94152	2NL94152	PARTS MPF TABLE ASSY SP	16
	302NP39150	2NP39150	MOUNT DP CONNECTOR	30
	302NP46360	2NP46360	WIRE DP	30
	302NP46420	2NP46420	WIRE DP JUNCTION	17
	302NP46450	2NP46450	WIRE PANEL JOINT	31
	302NP46460	2NP46460	WIRE KUIO POWER	29
	302NP46470	2NP46470	WIRE FFC KUIO	29
	302NP46480	2NP46480	WIRE OPEN SENSOR	17
	302NP46490	2NP46490	WIRE HP SENSOR	17
	302NP46500	2NP46500	WIRE SCANNER MOT	17
	302NP46530	2NP46530	WIRE HDD SIG	29
⊙	302NP93010	2NP93010	CT-8325	8
⊙	302NP93090	2NP93090	PARTS MOUNT LED ASSY SP	17
⊙	302NP93130	2NP93130	PARTS ISU	17
⊙	302NP94120	2NP94120	PARTS PWB THERMISTOR ASSY SP	7
⊙	302NP94160	2NP94160	PARTS PWB DP JUNCTION ASSY SP	17
⊙	302NP94170	2NP94170	PARTS PWB SCANNER LED ASSY SP	17
⊙	302NP94180	2NP94180	PARTS PWB ISC ASSY SP	17

• Parts with "⊙" indicate regular maintenance parts.

	Part.No.	Alternative.	Description	Fig.No.
⊙	302NP94200	2NP94200	PARTS COVER ISU FRONT A ASSY E SP	18
⊙	302NP94230	2NP94230	PARTS COVER RIGHT LOW ASSY SP	12
	302P834010	2P834010	SHEET EMBLEM	2
⊙	302P894011	2P894011	PARTS COVER FRONT ASSY 30 SP	2
	302R408220	2R408220	STOPPER BYPASS TABLE	16
	302R408230	2R408230	STRAP LINK MPF	16
	303JC04201	3JC04200	PLATE ORIGINAL	32
	303K502080	3K502080	SPONGE ORIGINAL MAT	32
	303LL02330	3LL02330	HOLDER WIRE D	29,31
	303LT02020	3LT02020	LID WIRE GUIDE	29
	303LL02330	3LL02330	HOLDER WIRE D	31
	303LW24060	3LW24060	PULLEY EJECT	3
	303M404180	3M404180	COVER INTERFACE B	1
	303M404190	3M404190	COVER INTERFACE C	1
	303MA16560	3MA16560	SHAFT GEAR BELT	26
	303MH06010	3MH06010	PAD RAIL	4
	303MR29040	3MR29040	PULLEY 26-6 DUPLEX	10
	303MX02021	3MX02021	CUSHION ORIGINAL MAT A	32
	303MX02031	3MX02031	CUSHION ORIGINAL MAT B	32
	303NF02280	3NF02280	SHAFT HOOK FULCRUM	3
	303NN02143	3NN02143	STAY UPPER FEED	4
	303NN02370	3NN02370	RAIL FEED	4
	303NN02450	3NN02450	GUIDE PRIMARY FEED	4
	303NN24110	3NN24110	JOINT PULLEY 26-6	10
	303NN24180	3NN24180	SPRING FEED LOW	12
	303NN24250	3NN24250	SPRING EARTH SW	12
⊙	303NN31040	3NN31040	GEAR Z77R Z23L	23
⊙	303NN31050	3NN31050	GEAR Z27L IDLE	23
	303NN31060	3NN31060	SHAFT GEAR	5,23
⊙	303NN31070	3NN31070	GEAR Z33R Z44R	23
	303NN31060	3NN31060	SHAFT GEAR	23
	303NN31080	3NN31080	SPRING JOINT SHAFT	23
	303NS24410	3NS24410	SCREW PLATE DF	33
	303PC06060	3PC06060	HANDLE FEED LOW	12
	303PH34070	3PH34070	LABEL ISU REAR	32
	3066060011	66060011	COVER,KEY COUNTER	33
	3066060041	66060041	MOUNT,KEY COUNTER	33
	3CY06030	3CY06030	RETAINER M4	33
⊙	3HY07120	3HY07120	PULLEY 15 DUPLEX	12
⊙	5ESP03090001+01	SP000360	PUSH SWITCH 03 SN /SW-192 N	7
	5MMS111SL002	2BY20050	NUT FUSER A /FS-1800/3800 A4	13
	5MMT263SN012++R	2D903100	SCREW OP / M3 X 8 CRFREE A4	29
	5MVM177XN007	2A814100	BUSH MIXER /A-49 DLP A4	5
	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	3,8,24,26
	5MVX111DN007	2BT11070	STOPPER 3 /2BT1107 A4	3,10,13
	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	8
⊙	76727010	76727010	ORIGINAL SIZE SWITCH	16
	5MVX111DN007	2BT11070	STOPPER 3 /2BT1107 A4	10
	7AAACCAS+10H001	AA063380	AC CORD ASSY AS	3

	Part.No.	Alternative.	Description	Fig.No.
⊙	7NXGP1S173LCH01	NX116910	SENSOR OPT.	3,4,5,11,12,14,16,17,26
⊙	7SC010105+++H01	SC125000	SW.SEE SAW	7
⊙	7NXGP1S173LCH01	NX116910	SENSOR OPT.	4
⊙	7SC020403+++H01	SC136170	SW.SEE SAW	4
⊙	7SM010202+++H01	SM044270	SW.MICRO	7
⊙	7SP01000001+H01	SP044290	SW.PUSH	3,5,12
	7YBFZZ65C001H01	YB110990	FERRITE CORE	17
⊙	7SP01000001+H01	SP044290	SW.PUSH	5
	7YCC02B1003+H01	YC013860	CONNECTOR 292254-2	24
	7YZM210002++H01	YZ004730	ACCESS.EDGING	7,29
	7YZM210003++H01	YZ037970	ACCESS.EDGING	4
	7YZM210002++H01	YZ004730	ACCESS.EDGING	29
	7YZM210005++H01	YZ037990	ACCESS.EDGING	7,29,30
	7YZM210006++H01	YZ038000	ACCESS.EDGING	7,33
	7YZM210005++H01	YZ037990	ACCESS.EDGING	29
	7YZM390002++H01	YZ012140	ACCESS.CLAMP	3,4,5,7,17
	7YZM210006++H01	YZ038000	ACCESS.EDGING	33
	7YZM390011++H01	YZ050250	ACCESS.CLAMP	29,31
	7YZM390002++H01	YZ012140	ACCESS.CLAMP	4
	7YZM510007++H01	YZ042780	ACCESS.SPACER	30
	7YZM390011++H01	YZ050250	ACCESS.CLAMP	31
	7YZM510021++H01	YZ127660	ACCESS.SPACER	30
	7YZM610002++H01	YZ010240	ACCESS.SADDLE	3
	7YZM610007++H01	YZ023340	ACCESS.SADDLE	3
	7YZM610009++H01	YZ042980	ACCESS.SADDLE	3,4,30
	7YZM610010++H01	YZ042990	ACCESS.SADDLE	4,7,29,30
	7YZM610009++H01	YZ042980	ACCESS.SADDLE	4
	7YZM610011++H01	YZ043000	ACCESS.SADDLE	3,29,30
	7YZM610010++H01	YZ042990	ACCESS.SADDLE	7
	7YZM610014++H01	YZ043030	ACCESS.SADDLE	3
	7YZM610011++H01	YZ043000	ACCESS.SADDLE	29
	7ZG65TSV+010H01	ZG111180	SHIELD GASKET	17
	M0208010	M0208010	SPACER,SFS-2.6S-B1WM(JST)	30
	M21AH010	M21AH010	BAND,RSG-130-V0(KITAGAWA)	33
	M7005010	M7005010	CLAMP,EMT-3N(TAKEUCHI)	31
	1202H70UN0	022H70UN	PLATEN COVER TYPE(E)	32

• Parts with "⊙" indicate regular maintenance parts.

KYOCERA Document Solutions America, Inc.**Headquarters**

225 Sand Road,
Fairfield, New Jersey 07004-0008, USA
Phone: +1-973-808-8444
Fax: +1-973-882-6000

Latin America

8240 NW 52nd Terrace Dawson Building, Suite 100
Miami, Florida 33166, USA
Phone: +1-305-421-6640
Fax: +1-305-421-6666

KYOCERA Document Solutions Canada, Ltd.

6120 Kestrel Rd., Mississauga, ON L5T 1S8,
Canada
Phone: +1-905-670-4425
Fax: +1-905-670-8116

**KYOCERA Document Solutions
Mexico, S.A. de C.V.**

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco
Chapultepec, Delegacion Miguel Hidalgo,
Distrito Federal, C.P. 11560, México
Phone: +52-555-383-2741
Fax: +52-555-383-7804

KYOCERA Document Solutions Brazil, Ltda.

Alameda África, 545, Pólo Empresarial Consbrás, Tamboré,
Santana de Parnaíba, State of São Paulo, CEP 06543-306,
Brazil
Phone: +55-11-2424-5353
Fax: +55-11-2424-5304

KYOCERA Document Solutions Chile SpA

Jose Ananias 505, Macul. Santiago, Chile
Phone: +562-2350-7000
Fax: +562-2350-7150

**KYOCERA Document Solutions
Australia Pty. Ltd.**

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,
Australia
Phone: +61-2-9888-9999
Fax: +61-2-9888-9588

**KYOCERA Document Solutions
New Zealand Ltd.**

Ground Floor, 19 Byron Avenue, Takapuna, Auckland,
New Zealand
Phone: +64-9-415-4517
Fax: +64-9-415-4597

KYOCERA Document Solutions Asia Limited

Unit 3 & 5, 16/F., Mita Centre, 552-566, Castle Peak Road
Tsuen Wan, New Territories, Hong Kong
Phone: +852-2496-5678
Fax: +852-2610-2063

**KYOCERA Document Solutions
(China) Corporation**

8F, No. 288 Nanjing Road West, Huangpu District,
Shanghai, 200003, China
Phone: +86-21-5301-1777
Fax: +86-21-5302-8300

**KYOCERA Document Solutions
(Thailand) Corp., Ltd.**

335 Ratchadapisek Road, Wongsawang, Bangsue, Bangkok
10800,
Thailand
Phone: +66-2-586-0333
Fax: +66-2-586-0278

**KYOCERA Document Solutions
Singapore Pte. Ltd.**

12 Tai Seng Street #04-01A,
Luxasia Building, Singapore 534118
Phone: +65-6741-8733
Fax: +65-6748-3788

**KYOCERA Document Solutions
Hong Kong Limited**

Unit 1,2,4,6,8 & 10, 16/F., Mita Centre, 552-566, Castle Peak
Road Tsuen Wan, New Territories, Hong Kong
Phone: +852-3582-4000
Fax: +852-3185-1399

**KYOCERA Document Solutions
Taiwan Corporation**

6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: +886-2-2507-6709
Fax: +886-2-2507-8432

KYOCERA Document Solutions Korea Co., Ltd.

18F Kang Nam Bldg, 396, Seocho-daero, Seocho-gu, Seoul,
Korea
Phone: +822-6933-4050
Fax: +822-747-0084

**KYOCERA Document Solutions
India Private Limited**

Second Floor, Centrum Plaza, Golf Course Road,
Sector-53, Gurgaon, Haryana 122002, India
Phone: +91-0124-4671000
Fax: +91-0124-4671001

KYOCERA Document Solutions Europe B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31-20-654-0000
Fax: +31-20-653-1256

KYOCERA Document Solutions Nederland B.V.

Beechavenue 25, 1119 RA Schiphol-Rijk,
The Netherlands
Phone: +31-20-5877200
Fax: +31-20-5877260

KYOCERA Document Solutions (U.K.) Limited

Eldon Court, 75-77 London Road,
Reading, Berkshire RG1 5BS,
United Kingdom
Phone: +44-118-931-1500
Fax: +44-118-931-1108

KYOCERA Document Solutions Italia S.p.A.

Via Monfalcone 15, 20132, Milano, Italy,
Phone: +39-02-921791
Fax: +39-02-92179-600

KYOCERA Document Solutions Belgium N.V.

Sint-Martinusweg 199-201 1930 Zaventem,
Belgium
Phone: +32-2-7209270
Fax: +32-2-7208748

KYOCERA Document Solutions France S.A.S.

Espace Technologique de St Aubin
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,
France
Phone: +33-1-69852600
Fax: +33-1-69853409

KYOCERA Document Solutions Espana, S.A.

Edificio Kyocera, Avda. de Manacor No.2,
28290 Las Matas (Madrid), Spain
Phone: +34-91-6318392
Fax: +34-91-6318219

KYOCERA Document Solutions Finland Oy

Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358-9-47805200
Fax: +358-9-47805390

KYOCERA Document Solutions**Europe B.V., Amsterdam (NL) Zürich Branch**

Hohlstrasse 614, 8048 Zürich,
Switzerland
Phone: +41-44-9084949
Fax: +41-44-9084950

KYOCERA Document Solutions**Deutschland GmbH**

Otto-Hahn-Strasse 12, 40670 Meerbusch,
Germany
Phone: +49-2159-9180
Fax: +49-2159-918100

KYOCERA Document Solutions Austria GmbH

Altmannsdorferstraße 91, Stiege 1, 2. OG, Top 1, 1120,
Wien, Austria
Phone: +43-1-863380
Fax: +43-1-86338-400

KYOCERA Document Solutions Nordic AB

Esbogatan 16B 164 75 Kista, Sweden
Phone: +46-8-546-550-00
Fax: +46-8-546-550-10

KYOCERA Document Solutions Norge Nuf

Olaf Helsetsv. 6, 0619 Oslo, Norway
Phone: +47-22-62-73-00
Fax: +47-22-62-72-00

KYOCERA Document Solutions Danmark A/S

Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45-70223880
Fax: +45-45765850

KYOCERA Document Solutions Portugal Lda.

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351-21-843-6780
Fax: +351-21-849-3312

KYOCERA Document Solutions**South Africa (Pty) Ltd.**

KYOCERA House, Hertford Office Park,
90 Bekker Road (Cnr. Allandale), Midrand, South Africa
Phone: +27-11-540-2600
Fax: +27-11-466-3050

KYOCERA Document Solutions Russia LLC.

Building 2, 51/4, Schepkina St., 129110, Moscow,
Russia
Phone: +7(495)741-0004
Fax: +7(495)741-0018

KYOCERA Document Solutions Middle East

Dubai Internet City, Bldg. 17,
Office 157 P.O. Box 500817, Dubai,
United Arab Emirates
Phone: +971-04-433-0412

KYOCERA Document Solutions Inc.

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: +81-6-6764-3555
<http://www.kyoceradocumentsolutions.com>