



TASKalfa 3500i 4500i 5500i

PARTS LIST

Published in March 2011
2LHPL070
842LH120
First Edition

— CONTENTS —

FIG. 1	Covers 1	2	FIG. 14	Drive Section 1	30
FIG. 2	Covers 2	4	FIG. 15	Drive Section 2	32
FIG. 3	Frames	6	FIG. 16	Cooling Section	34
FIG. 4	Paper Cassettes	8	FIG. 17	Exit Section	36
FIG. 5	Paper Feed Section 1 (55/45 ppm)	10	FIG. 18	Electrical Components 1	38
FIG. 5	Paper Feed Section 1 (35 ppm)	12	FIG. 19	Electrical Components 2	40
FIG. 6	Paper Feed Section 2	14	FIG. 20	Operation Section	42
FIG. 7	Paper Conveying Section 1	16	FIG. 21	Options 1	44
FIG. 8	Paper Conveying Section 2	18	FIG. 22	Options 2	46
FIG. 9	Paper Conveying Section 3	20	FIG. 23	Options 3 & Tools	48
FIG. 10	Scanner & Laser Scanner Section	22	FIG. 24	Maintenance Kits	50
FIG. 11	Image Formation & Developer Section	24			
FIG. 12	Inner Section	26		• INDEX	51
FIG. 13	Fuser Section	28			

FIG. 1 Covers 1

2LL/2LJ/2LH




FIG. 1 Covers 1

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302LC04030	2LC04030	COVER TOP TRAY	1	1	1
⊙	2	302LC04050	2LC04050	COVER RIGHT LOWER F	1	1	1
⊙	3	302LC04060	2LC04060	COVER RIGHT MIDDLE R	1	1	1
⊙	4	302LC04070	2LC04070	COVER RIGHT LOWER R	1	1	1
⊙	5	302LC04190	2LC04190	COVER EXIT	1	1	1
⊙	6	302LC04200	2LC04200	COVER TRAY REAR	1	1	1
⊙	7	302LC04210	2LC04210	COVER ISU BOTTOM	1	1	1
⊙	8	302LC04250	2LC04250	COVER INNER LEFT	1	1	1
⊙	9	302LC04260	2LC04260	COVER INNER FEED F	1	1	1
⊙	10	302LC04280	2LC04280	COVER HANDLE	1	1	1
⊙	11	302LC04290	2LC04290	COVER MAIN SWITCH	1	1	1
	12	302LC04410	2LC04410	MOUNT FRONT COVER LEFT	1	1	1
	13	302LC04720	2LC04720	STOPPER ORIGINAL	1	1	1
	14	302LC04650	2LC04650	STRAP FRONT COVER	2	2	2
	15	302LC34050	2LC34050	LABEL SW CAUTION EN	1	1	1
	16	302LC04270	2LC04270	EMBLEM	1	1	1
	17	302LH34010	2LH34010	SHEET EMBLEM 5500 (55 ppm)	1	1	1
	17	302LJ34010	2LJ34010	SHEET EMBLEM 4500 (45 ppm)	1	1	1
	17	302LL34010	2LL34010	SHEET EMBLEM 3500 (35 ppm)	1	1	1
	18	2FB04270	2FB04270	PLATE MAGNET	2	2	2
	19	302LC04730	2LC04730	SHEET COVER FRONT	2	2	2
⊙	20	302LC94520	2LC94520	PARTS COVER FRONT SP	1	1	1
⊙	21	302LC04020	2LC04020	COVER FRONT B	1	1	1
	22	302LC04460	2LC04460	STOPPER CONTAINER	1	1	1
	23	302LC04490	2LC04490	PLATE FRONT COVER	1	1	1
	24	302LC04750	2LC04750	SPONGE COVER FRONT B	1	1	1
⊙	25	302H094300	2H094300	PARTS,HUMIDITY SENSOR,SP	1	1	1
⊙	26	302LC02710	2LC02710	COVER HUMIDITY SENSOR	1	1	1
	27	302LC02720	2LC02720	SHEET HUMIDITY SENSOR A	1	1	1
	28	302LC02730	2LC02730	SHEET HUMIDITY SENSOR B	1	1	1
	29	302LC02760	2LC02760	SHEET COVER HUMIDITY SENSOR	1	1	1
⊙	30	302LC04240	2LC04240	COVER FRONT RIGHT LOWER	1	1	1
	31	302LC46230	2LC46230	WIRE FRONT LOW	1	1	1
	32	302LC34160	2LC34160	LABEL SW CAUTION SET A	1	1	
	101	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	102	7BB202308H	BB105690	+TP-FLAT T.T P SCREW 3X8			
	103	7BB180408H	BB111210	+BIND T.T S SCREW 4X8(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 2 Covers 2

2LL/2LJ/2LH




FIG. 2 Covers 2

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
	1	2C912430	2C912430	LID KMAS	2	2	2
	2	302GR04370	2GR04370	MAGNET CLIP DISH	1	1	1
	3	302GR04380	2GR04380	SEAL MAGNET	1	1	1
	4	302H004660	2H004660	MAGNET CATCH	1	1	1
	5	302K929201	2K929201	COVER RIGHT	1	1	1
⊙	6	302LC04090	2LC04090	COVER LEFT UPPER	1	1	1
⊙	7	302LC04150	2LC04150	COVER ISU REAR	1	1	1
⊙	8	302LC04160	2LC04160	COVER FRONT UPPER A	1	1	1
⊙	9	302LC04170	2LC04170	COVER FRONT UPPER B	1	1	1
⊙	10	302LC04180	2LC04180	COVER FRONT UPPER RIGHT	1	1	1
⊙	11	302LF04070	2LF04070	COVER REAR UPPER	1	1	1
⊙	12	302LF04080	2LF04080	COVER REAR LOWER	1	1	1
	13	302LC04300	2LC04300	LID CONTROLLER	1	1	1
	14	302LC04480	2LC04480	MOUNT COVER LEFT	1	1	1
⊙	15	302LC04320	2LC04320	COVER DP CONNECTOR	1	1	1
	16	302LC04330	2LC04330	LID DP CONNECTOR	1	1	1
⊙	17	302LC04340	2LC04340	COVER ISU LEFT SUB	1	1	1
	18	302LC04350	2LC04350	CASE CLIP	1	1	1
⊙	19	302LH04020	2LH04020	COVER INNER FAN	1	1	1
	20	302LC04440	2LC04440	HOLDER CLIP CASE	1	1	1
	21	302LC04470	2LC04470	LID FAX BOARD	1	1	1
	22	302LC29080	2LC29080	COVER RIGHT FRONT	1	1	1
	23	302LC34030	2LC34030	LABEL OPERATION CAUTION B	1	1	1
	24	302LC34070	2LC34070	LABEL MPF CAUTION B	1	1	1
	25	302LC34110	2LC34110	LABEL MPF PUSH	1	1	1
⊙	26	302K994100	2K994100	PARTS FILTER EXIT UNIT SP	2	2	2
⊙	27	302LC94130	2LC94130	PARTS FILTER BELT UNIT(V) SP	1	1	1
⊙	28	302LC94140	2LC94140	PARTS FILTER TONER UNIT(V) SP	1	1	1
⊙	29	302LC04040	2LC04040	COVER RIGHT UPPER	1	1	1
⊙	30	302LC04080	2LC04080	COVER RIGHT MIDDLE	1	1	1
⊙	31	302LH04030	2LH04030	COVER LEFT	1	1	1
	32	302LC34180	2LC34180	LABEL MPF SET A	1	1	
	101	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	102	7BB180408H	BB111210	+BIND T.T S SCREW 4X8(BLACK)			
	103	7BB780410H	BB111220	+BIND T.T S SCREW 4X10 SR(BLACK)			
	104	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	105	7BB782308H	BB111300	+TP-FLAT T.T S SCREW 3X8 SR(BLACK)			
	106	7BB282308H	BB111240	+TP-FLAT T.T P SCREW 3X8(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 3 Frames

2LL/2LJ/2LH




FIG. 3 Frames

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
	1	302K909530	2K909530	SLIDER CASSETTE	2	2	2
	2	302FZ02580	2FZ02580	CAP HANDLE	3	3	3
	3	302FZ03110	2FZ03110	SEAL HANDLE	3	3	3
	4	2FB16270	2FB16270	PIN DRAWER A	4	4	4
	5	302K909620	2K909620	PULLEY CASSETTE	4	4	4
	6	302K924300	2K924300	SLIDER CONVEYING	2	2	2
	101	7BB100306H1	BB105820	+BIND T.T S SCREW 3X6			
	102	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 4 Paper Cassettes

2LL/2LJ/2LH




FIG. 4 Paper Cassettes

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302K993010	2K993010	CT-8705	2	2	2
⊙	1	•302BM07410	2BM07410	GEAR GUIDE SIDE	2	2	2
	2	•302K909060	2K909060	RACK CURSOR	4	4	4
⊙	3	•302K994550	2K994550	PARTS GEAR CURSOR SP	8	8	8
	4	•302K909270	2K909270	ACTUATOR PAPER LEVEL DETECTION	2	2	2
	5	•302K934010	2K934010	LABEL PAPER SIZE A	2	2	2
	6	•302K934020	2K934020	LABEL PAPER SIZE B	2	2	2
	7	•302K934040	2K934040	LABEL SET PAPER	2	2	2
	8	•302K934090	2K934090	LABEL CASSETTE PAPER MAX	2	2	2
	9	•302K934100	2K934100	LABEL CASSETTE CURSOR LOCK	2	2	2
	10	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	2	2	2
	11	302K934050	2K934050	LABEL CASSETTE NUMBER 1	1	1	1
	12	302K934060	2K934060	LABEL CASSETTE NUMBER 2	1	1	1
⊙	13	302LC94490	2LC94490	PARTS COVER CASSETTE A ASSY SP	1	1	1
⊙	14	302LC94500	2LC94500	PARTS COVER CASSETTE B ASSY SP	1	1	1
	15	302K934120	2K934120	SHEET CASSETTE PAPER MEDIA EN	2	2	2
	16	302K934130	2K934130	CASSETTE PAPER SIZE	2	2	2
	17	302K934220	2K934220	SHEET CASSETTE PAPER SET A	2	2	
	18	302K934230	2K934230	SHEET CASSETTE PAPER SET B		2	
	101	7BP512525B0CH01	BP124910	PARALLEL PIN 2.5X25			
	102	7BP512008B0CH01	BP126150	PARALLEL PIN 2.0X8			
	103	7BB282308H	BB111240	+TP-FLAT T.T P SCREW 3X8(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 5 Paper Feed Section 1 (55/45 ppm)

2LL/2LJ/2LH




FIG. 5 Paper Feed Section 1 (55/45 ppm)

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302K994020	2K994020	PARTS PRIMARY FEED UNIT HI SP	2	2	2
	1	•2AR07230	2AR07230	PULLEY,SEPARATION	2	2	2
⊙	2	•302K994420	2K994420	PARTS ROLLER ASSIST SP	2	2	2
⊙	3	•302K994530	2K994530	PARTS GEAR Z30R FEED OW SP	2	2	2
⊙	4	•302K906230	2K906230	GEAR PRIMARY FEED IDLE Z20R Z16L	2	2	2
	5	•302K906320	2K906320	ACTUATOR PAPER EMPTY	2	2	2
⊙	6	•302K994380	2K994380	PARTS SOLENOID FEED SHIFT SP	2	2	2
	7	•303LL07521	3LL07521	TORQUE-LIMITER 400	2	2	2
	8	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	18	18	18
⊙	9	•302K994580	2K994580	PARTS SENSOR OPT. SP	2	2	2
⊙	10	•303M894260	3M894260	PARTS SENSOR OPT SP	4	4	4
	11	•302K906340	2K906340	PULLEY RETARD	4	4	4
	101	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	102	7BB600306H	BB105730	+BIND M SCREW 3X6 R			
	103	5MBP2010WXSP	E0020100	SPRING PIN / M2 X 10 S-BLK			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 5 Paper Feed Section 1 (35 ppm)

2LL/2LJ/2LH




FIG. 5 Paper Feed Section 1 (35 ppm)

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302LC94040	2LC94040	PARTS PRIMARY FEED UNIT LOW SP	2	2	2
	1	•302F906230	2F906230	PULLEY FEED ASSY	2	2	2
	2	•302F909171	2F909171	RETARD ROLLER ASSY	2	2	2
	3	•302HN06080	2HN06080	PULLEY PICKUP ASSY	2	2	2
	4	•302LC06060	2LC06060	ACTUATOR PAPER EMPTY	2	2	2
	5	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	8	8	8
	6	•302K994580	2K994580	PARTS SENSOR OPT. SP	2	2	2
	7	•303M894260	3M894260	PARTS SENSOR OPT SP	4	4	4
	101	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 6 Paper Feed Section 2

2LL/2LJ/2LH




FIG. 6 Paper Feed Section 2

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
	1	302K906600	2K906600	COVER FEED LOW	1	1	1
	2	302K906690	2K906690	LID SIDE FEED	1	1	1
⊙	A01	302K994130	2K994130	PARTS GUIDE FEED MIDDLE ASSY SP	1	1	1
	3	•2BC06910	2BC06910	STOPPER 6	2	2	2
⊙	4	•302K994430	2K994430	PARTS ROLLER FEED LOW SP	1	1	1
	5	•302K906560	2K906560	ACTUATOR FEED LOW	1	1	1
⊙	6	•303M894260	3M894260	PARTS SENSOR OPT SP	1	1	1
⊙	7	•7SP01000006+H01	SP121020	SW.PUSH	1	1	1
⊙	8	302LC31750	2LC31750	GEAR Z60L (55/45 ppm)	1	1	1
⊙	9	302KV44041	2KV44041	CLUTCH 50 Z35R (55/45 ppm)	1	1	1
⊙	9	302KV44041	2KV44041	CLUTCH 50 Z35R (35 ppm)	2	2	2
	10	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4 (55/45 ppm)	3	3	3
	10	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4 (35 ppm)	4	4	4
	11	7BE006124431H01	BE119720	BEARING MR126ZZ	2	2	2
⊙	A02	302LH94090	2LH94090	PARTS GUIDE FEED REGIST ASSY SP (55/45 ppm)	1	1	1
⊙	A02	302LL94040	2LL94040	PARTS GUIDE FEED REGIST ASSY SP (35 ppm)	1	1	1
⊙	12	•2FG27110	2FG27110	SWITCH REGISTRATION	1	1	1
⊙	13	•302K994210	2K994210	PARTS PWB EDGE SENSOR ASSY SP	1	1	1
⊙	14	•302K994460	2K994460	PARTS ROLLER MIDDLE L SP	1	1	1
	15	•302K924560	2K924560	SHEET REGIST L A	2	2	2
	16	•302K924580	2K924580	ACTUATOR LOOP	1	1	1
⊙	17	•302K994310	2K994310	PARTS MOTOR HB MID SP (55/45 ppm)	1	1	1
⊙	18	•302KV44041	2KV44041	CLUTCH 50 Z35R (35 ppm)	1	1	1
⊙	19	•3H327410	3H327410	SENSOR,CONVEYING	1	1	1
	20	•5MMW261LD055	2A820350	SPRING SEPARATOR /FS-1000 A4	1	1	1
	21	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	3	3	3
	22	•302K924880	2K924880	SHEET REGIST L C	1	1	1
	23	•302K924890	2K924890	SHEET COVER SENSOR	1	1	1
⊙	24	302LF94160	2LF94160	PARTS CLEANER REGIST ASSY SP	1	1	1
	25	302K921120	2K921120	STOPPER 8	1	1	1
⊙	26	302K994450	2K994450	PARTS ROLLER REGIST L SP	1	1	1
⊙	27	302K924510	2K924510	GEAR Z24L	1	1	1
	101	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	102	7BP512014B0CH01	BP126450	PARALLEL PIN 2.0X14			
	103	7BB600306H	BB105730	+BIND M SCREW 3X6 R			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 7 Paper Conveying Section 1

2LL/2LJ/2LH




FIG. 7 Paper Conveying Section 1

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302LH94040	2LH94040	PARTS CONVEYING H UNIT(GAIA) SP (55/45 ppm)	1	1	1
⊙	A01	302LL94010	2LL94010	PARTS CONVEYING H UNIT(GAIA) SP (35 ppm)	1	1	1
	1	•2BC06510	2BC06510	BUSHING 8	6	6	6
	2	•2BC06910	2BC06910	STOPPER 6	1	1	1
	3	•2BL07950	2BL07950	UNDER CLEANER REGIST	1	1	1
⊙	4	•302FZ94420	2FZ94420	PARTS,FAN COOLING CONVEYING SP	2	2	2
⊙	5	•302K994201	2K994201	PARTS PWB JUNCTION ASSY SP	1	1	1
⊙	6	•302K994470	2K994470	PARTS ROLLER DU LOW SP (55/45 ppm)	1	1	1
⊙	6	•302LK94060	2LK94060	PARTS ROLLER DU LOW SP (35 ppm)	1	1	1
⊙	7	•302K994480	2K994480	PARTS ROLLER DU MID SP	1	1	1
⊙	8	•302K994490	2K994490	PARTS ROLLER DU UP SP (55/45 ppm)	1	1	1
⊙	8	•302LK94070	2LK94070	PARTS ROLLER DU UP SP (35 ppm)	1	1	1
	9	•302K929330	2K929330	ACTUATOR DU	1	1	1
⊙	10	•302K994980	2K994980	PARTS MOTOR PM REGIST SP (55/45 ppm)	2	2	2
⊙	11	•302KV44041	2KV44041	CLUTCH 50 Z35R (35 ppm)	2	2	2
	12	•302LC29050	2LC29050	ACTUATOR DU B	1	1	1
⊙	13	•302LF24150	2LF24150	ROLLER REGIST R	1	1	1
	14	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4 (35 ppm)	2	2	2
⊙	15	•66127010	66127010	SWITCH,COVER OPEN	1	1	1
	16	•7BE006103431H01	BE122720	BEARING MR106ZZ	2	2	2
⊙	17	•7NXGP1A173LCH01	NX115300	SENSOR OPT.	2	2	2
⊙	18	•302LC94410	2LC94410	PARTS SENSOR OPT. SP	1	1	1
⊙	A02	•302LF94070	2LF94070	PARTS ID SENSOR ASSY SP	1	1	1
⊙	19	••302K994160	2K994160	PARTS ID SENSOR ASSY SP	1	1	1
⊙	20	••302K994390	2K994390	PARTS SOLENOID ID SENSOR SP	1	1	1
⊙	A03	•302LF94060	2LF94060	PARTS BELT ASSY SP	1	1	1
	21	••302FZ01310	2FZ01310	VARISTOR TC ASS'Y	1	1	1
⊙	22	••302LC94290	2LC94290	PARTS MOTOR-BL W10 SP	1	1	1
	101	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	102	7BB700306H	BB105590	+BIND T.T S SCREW 3X6 SR			
	103	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	104	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	105	7BB300323H	BB105800	+BIND T.T B SCREW 3X23			
	106	7BB000303H	BB107000	+BIND M SCREW 3X3			
	107	7BB000304H	BB105720	+BIND M SCREW 3X4			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 8 Paper Conveying Section 2

2LL/2LJ/2LH




FIG. 8 Paper Conveying Section 2

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302K994010	2K994010	PARTS MPT ASSY SP (55/45 ppm)	1	1	1
⊙	A01	302LC94020	2LC94020	PARTS MPT ASSY SP (35 ppm)	1	1	1
⊙	1	•2AR07220	2AR07220	PULLEY,PAPER FEED	1	1	1
⊙	2	•2AR07230	2AR07230	PULLEY,SEPARATION	2	2	2
⊙	3	•302LC94200	2LC94200	PARTS MPT LIFT MOTOR ASSY SP	1	1	1
	4	•302K908280	2K908280	ACTUATOR FEED MPF	1	1	1
	5	•302K908290	2K908290	ACTUATOR PAPER SET	1	1	1
⊙	6	•302K994540	2K994540	PARTS GEAR Z30R ONE-WAY SP	1	1	1
⊙	7	•302KV44041	2KV44041	CLUTCH 50 Z35R	1	1	1
	8	•303LL07521	3LL07521	TORQUE-LIMITER 400 (55/45 ppm)	1	1	1
	8	•302GR06110	2GR06110	TORQUE LIMITER 360 (35 ppm)	1	1	1
⊙	9	•7NXGP1A173LCH01	NX115300	SENSOR OPT.	3	3	3
⊙	10	•303M894260	3M894260	PARTS SENSOR OPT SP	1	1	1
⊙	A02	302LC94470	2LC94470	PARTS COVER GUIDE DU L ASSY SP	1	1	1
	11	•302K929070	2K929070	COVER DU	1	1	1
	101	7BB180408H	BB111210	+BIND T.T S SCREW 4X8(BLACK)			
	102	7BB280410H	BB111250	+BIND T.T P SCREW 4X10(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 9 Paper Conveying Section 3

2LL/2LJ/2LH




FIG. 9 Paper Conveying Section 3

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302K994050	2K994050	PARTS MPT TRAY UNIT SP	1	1	1
	1	•2FB07330	2FB07330	STOPPER BYPASS TABLE	2	2	2
⊙	2	•302K994620	2K994620	PARTS PWB MPF SIZE ASSY SP	1	1	1
	3	•302K908030	2K908030	TRAY MPF A	1	1	1
	4	•302K908040	2K908040	TRAY MPF B	1	1	1
	5	•302K908050	2K908050	TRAY MPF C	1	1	1
	6	•302K908060	2K908060	TRAY MPF D	1	1	1
	7	•302K908120	2K908120	RACK CURSOR MPF	2	2	2
	8	•302K908211	2K908211	ACTUATOR SIZE DETECTION	1	1	1
	9	•3HL06110	3HL06110	TERMINAL PAPER SIZE	1	1	1
⊙	10	•7NXGP1A173LCH01	NX115300	SENSOR OPT.	1	1	1
⊙	11	•7SP01000006+H01	SP121020	SW.PUSH	1	1	1
	12	302LC34060	2LC34060	LABEL MPF CAUTION A	1	1	1
	13	302LC34080	2LC34080	LABEL MPF PAPER LIMIT	1	1	1
	14	302LC34100	2LC34100	LABEL MPF SIZE INDICATOR IN	1		
	14	302LC34090	2LC34090	LABEL MPF SIZE INDICATOR ME		1	1
	101	7BB282308H	BB111240	+TP-FLAT T.T P SCREW 3X8(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 10 Scanner & Laser Scanner Section

2LL/2LJ/2LH




FIG. 10 Scanner & Laser Scanner Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302LK93080	2LK93080	PARTS IMAGE SCANNER L SP	1	1	1
⊙	2	302H044110	2H044110	SENSOR ORIGINAL	1	1	1
⊙	3	302K993040	2K993040	PARTS MOUNT LED ASSY SP	1	1	1
⊙	4	302K994030	2K994030	PARTS CONTACT-GLASS ASSY(I) SP	1		
⊙	4	302K994040	2K994040	PARTS CONTACT-GLASS ASSY(C) SP		1	1
⊙	5	302K994230	2K994230	PARTS PWB ISC ASSY SP	1	1	1
	6	302K946670	2K946670	WIRE FFC CCD	1	1	1
	7	302K946710	2K946710	WIRE FFC LED	1	1	1
	8	302LC04120	2LC04120	COVER ISU FRONT	1	1	1
	9	302LC04130	2LC04130	COVER ISU LEFT	1	1	1
	10	302LC04140	2LC04140	COVER ISU RIGHT	1	1	1
⊙	11	7NXGP1S173LCH01	NX116910	SENSOR OPT.	2	2	2
⊙	12	302LG93010	2LG93010	LK-6706	1	1	1
	101	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	102	7BB606308H	BB105280	+PAN M SCREW WITH SW W 3X8 R			
	103	7BB180408H	BB111210	+BIND T.T S SCREW 4X8(BLACK)			
	104	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 11 Image Formation & Developer Section

2LL/2LJ/2LH




FIG. 11 Image Formation & Developer Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302LH93010	2LH93010	DK-6305	1	1	1
⊙	1	•302LF93020	2LF93020	MC-6705	1	1	1
⊙	2	302LH93030	2LH93030	DV-6305	1	1	1
	3	302H703100	2H703100	SHUTTER PIPE UP	1	1	1
	4	302H703130	2H703130	SEAL PIPE DLP UP	1	1	1
	5	302H703240	2H703240	SPRING PIPE UP	1	1	1
	6	302H703570	2H703570	SEAL CONT SHUTTER	1	1	1
	7	302K914370	2K914370	SPRING SHUTTER	2	2	2
	8	302K915240	2K915240	SHUTTER HOPPER UP	1	1	1
	9	302K915320	2K915320	SEAL SHUTTER	1	1	1
	101	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 12 Inner Section

2LL/2LJ/2LH




FIG. 12 Inner Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302LH94030	2LH94030	PARTS INNER UNIT SP	1	1	1
⊙	1	•302LC94380	2LC94380	PARTS FAN COOLING LSU 60 SP	2	2	2
⊙	2	•302K994150	2K994150	PARTS TONER FULL DETECT ASSY SP	1	1	1
⊙	3	•302LC94190	2LC94190	PARTS CONV RELEASE MOTOR ASSY SP	1	1	1
	4	•3033915181	33915181	TONER EMPTY DETECTION SENSOR	1	1	1
	5	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	2	2	2
	6	•7NXGP1A173LCH01	NX115300	SENSOR OPT.	1	1	1
⊙	A02	302LC94480	2LC94480	PARTS WASTE TRAY UNIT SP	1	1	1
	7	•302GR06110	2GR06110	TORQUE LIMITER 360	1	1	1
⊙	8	302LH94130	2LH94130	PARTS WASTE BOTTLE CASE ASSY SP	1	1	1
	9	1902LH0UN0	092LH0UN	WT-862/WASTE TONER BOTTLE (OPTION)	1	1	1
	101	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	102	7BP512008B0CH01	BP126150	PARALLEL PIN 2.0X8			
	103	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	104	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	105	7BB100406H	BB106920	+BIND T.T S SCREW 4X6			
	106	7BB700330H	BB106840	+BIND T.T S SCREW 3X30 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.




FIG. 13 Fuser Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302LH93050	2LH93050	FK-6306	1		
⊙	1	302LH93060	2LH93060	FK-6307		1	1
	101	7BB700412H	BB106830	+BIND T.T S SCREW 4X12 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 14 Drive Section 1

2LL/2LJ/2LH




FIG. 14 Drive Section 1

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302LF93070	2LF93070	DR-6705	1	1	1
⊙	1	•302LC94460	2LC94460	PARTS MOTOR-BL W20 DRUM Z11 SP	1	1	1
⊙	A02	302LH94100	2LH94100	PARTS FUSER DRIVE UNIT SP	1	1	1
⊙	2	•302LC94290	2LC94290	PARTS MOTOR-BL W10 SP	1	1	1
⊙	A03	302LH94110	2LH94110	PARTS DLP MOTOR ASSY(G) SP	1	1	1
⊙	3	•302K994320	2K994320	PARTS MOTOR-BL W20 SP	1	1	1
⊙	4	302K994980	2K994980	PARTS MOTOR PM REGIST SP (55/45 ppm)	1	1	1
⊙	5	302LH31010	2LH31010	PLATE REGIST DRIVE (55/45 ppm)	1	1	1
	101	7BB000304H	BB105720	+BIND M SCREW 3X4			
	102	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	103	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 15 Drive Section 2

2LL/2LJ/2LH




FIG. 15 Drive Section 2

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302K993020	2K993020	PARTS FEED DRIVE H UNIT SP (55/45 ppm)	1	1	1
⊙	A01	302LC93120	2LC93120	PARTS FEED DRIVE L SP (35 ppm)	1	1	1
⊙	1	•302K994190	2K994190	PARTS PWB FEED 2 ASSY SP (55/45 ppm)	1	1	1
⊙	1	•302LN94050	2LN94050	PARTS PWB FEED 2 ASSY SP (35 ppm)	1	1	1
⊙	2	•302K994330	2K994330	PARTS MOTOR-BL W30 SP (55/45 ppm)	1	1	1
⊙	2	•302K994320	2K994320	PARTS MOTOR-BL W20 SP (35 ppm)	1	1	1
⊙	3	•302KV44041	2KV44041	CLUTCH 50 Z35R (55/45 ppm)	4	4	4
⊙	3	•302KV44041	2KV44041	CLUTCH 50 Z35R (35 ppm)	2	2	2
	4	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4 (55/45 ppm)	11	11	11
	4	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4 (35 ppm)	7	7	7
⊙	5	302K903130	2K903130	GEAR Z35S	1	1	1
⊙	A02	302LF94080	2LF94080	PARTS CONT DRIVE UNIT K SP	1	1	1
⊙	6	•302K301140	2K301140	PWB RFID ASSY WITH SOFTWARE	1	1	1
⊙	7	302LC03140	2LC03140	GEAR Z30S COUPLING	1	1	1
⊙	8	302H006120	2H006120	GEAR Z20S JOINT FEED B	3	3	3
⊙	9	302K903140	2K903140	GEAR Z18S	1	1	1
⊙	10	302LC03130	2LC03130	GEAR Z20S	1	1	1
	101	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	102	7BB000304H	BB105720	+BIND M SCREW 3X4			
	103	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 16 Cooling Section

2LL/2LJ/2LH




FIG. 16 Cooling Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302K994090	2K994090	PARTS FAN FUSER FRONT UNIT SP	1	1	1
⊙	2	302GR44080	2GR44080	FAN LSU 60-25	1	1	1
	3	302K933580	2K933580	SEAL DUCT EXIT	2	2	2
⊙	4	302HN44010	2HN44010	FAN MOTOR	1	1	1
	5	302HG02450	2HG02450	SEAL FRAME MIDDLE A	1	1	1
⊙	6	302K994350	2K994350	PARTS FAN COOLING DLP 70 SP	1	1	1
⊙	7	302FZ94420	2FZ94420	PARTS,FAN COOLING CONVEYING SP	1	1	1
⊙	8	302FZ94660	2FZ94660	PARTS,FAN IMAGE SP	2	2	2
	101	7BB200320H	BB113430	+BIND T.T P SCREW 3X20			
	102	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 17 Exit Section

2LL/2LJ/2LH




FIG. 17 Exit Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302LC94030	2LC94030	PARTS EXIT UNIT B SP	1	1	1
	1	•2FM02210	5MVM274DN002	PULLEY MID /B-11 FRAME A4	4	4	4
⊙	2	•2FM02320	5MVG144DN003	GEAR FD Z31 /B-11 FRAME A4	1	1	1
	3	•2FM04150	5MVM163DN005	CAP SPRING /B-11 ENCLOSURE A4	8	8	8
	4	•302F929260	2F929260	PULLEY DU LOW	4	4	4
	5	•302FZ28270	2FZ28270	SPRING EXIT PUSH	3	3	3
	6	•302H024370	2H024370	BUSH 6 EW	4	4	4
⊙	7	•302H728080	2H728080	GEAR Z23S EXIT	2	2	2
	8	•302HN28120	2HN28120	SPRING PULLEY A	4	4	4
	9	•302JF22010	2JF22010	PULLEY MIDDLE	4	4	4
	10	•302K928190	2K928190	SPRING-TORSION SWITCHBACK	1	1	1
⊙	11	•302K994300	2K994300	PARTS MOTOR PM FEED SP	1	1	1
⊙	12	•302K994370	2K994370	PARTS SOLENOID FEED SHIFT SP	1	1	1
⊙	13	•302LC94350	2LC94350	PARTS ROLLER EXIT SP	2	2	2
⊙	14	•302LC94360	2LC94360	PARTS GEAR Z40R Z14S IDLE SP	1	1	1
	15	•302LC28090	2LC28090	ACTUATOR EXIT SENSOR	1	1	1
	16	•302LC28100	2LC28100	SPRING-COMPRESSION	1	1	1
	17	•302LC28110	2LC28110	SPRING-EXTENSION	1	1	1
	18	•302LC28150	2LC28150	SPRING-COMPRESSION	8	8	8
	19	•302LC28210	2LC28210	ACTUATOR SWITCHBACK	1	1	1
	20	•302LC46360	2LC46360	WIRE EXIT	1	1	1
	21	•5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	4	4	4
	22	•63212210	63212210	STATIC ELIMINATOR,EJECT	1	1	1
⊙	23	•7NXGP1A173LCH01	NX115300	SENSOR OPT.	2	2	2
	101	E0130240	E0130240	SPRING PIN 3X24(SUS)			
	102	7BB000304H	BB105720	+BIND M SCREW 3X4			
	103	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	104	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	105	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 18 Electrical Components 1

2LL/2LJ/2LH




FIG. 18 Electrical Components 1

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302K939360	2K939360	SPRING HV	1	1	1
	2	302LF39010	2LF39010	TERMINAL HV SEPARATION	1	1	1
	3	302LF94140	2LF94140	PARTS MOUNT LED UNIT SP	2	2	2
	4	2FB27160	2FB27160	INTER LOCK SWITCH	1	1	1
	5	302K994360	2K994360	PARTS FAN COOLING LSU 60 SP	1	1	1
	6	7SC010202+++H01	SC122390	SW.SEESAW	1	1	1
	7	302LH94180	2LH94180	PARTS PWB HEATER 100 ASSY SP	1		
	7	302LH94190	2LH94190	PARTS PWB HEATER 200 ASSY SP		1	1
	8	302K394190	2K394190	PARTS MOTOR LIFT ASSY SP	2	2	2
	9	302LH94260	2LH94260	PARTS PWB FRONT MONO ASSY SP	1	1	1
	10	302LF94220	2LF94220	PARTS PWB LSU JUNC MONO ASSY SP	1	1	1
	11	302LF46010	2LF46010	WIRE FFC LSU	1	1	1
	12	303M894260	3M894260	PARTS SENSOR OPT SP	4	4	4
	13	302K994120	2K994120	PARTS SIZE DETECTION ASSY SP	2	2	2
	14	302LF39020	2LF39020	TERMINAL HV DRUM	1	1	1
	15	302LF39080	2LF39080	SPRING HV DRUM	1	1	1
	16	302LH94120	2LH94120	PARTS HUMIDITY ASSY (G) SP	1	1	1
	17	3019527401	19527401	POWER CORD(120)	1		
	18	2AR27800	2AR27800	POWER CORD(230)		1	
	19	7AAACCAS+10H001	AA063380	AC CORD ASSY AS			1
	101	7BB700408H	BB105640	+BIND T.T S SCREW 4X8 SR			
	102	7BB700330H	BB106840	+BIND T.T S SCREW 3X30 SR			
	103	7BB607320H	BB106890	+TP-CUP M SCREW 3X20 R			
	104	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.




FIG. 19 Electrical Components 2

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302K994340	2K994340	PARTS FAN BOX COOLING 60 SP	1	1	1
⊙	2	302K994270	2K994270	PARTS PWB KUIO ASSY SP	1	1	1
	3	302K946990	2K946990	WIRE FFC KUIO	1	1	1
⊙	4	302LH94140	2LH94140	PARTS PWB MAIN ASSY SP	1		1
⊙	4	302LH94150	2LH94150	PARTS PWB MAIN ASSY SP EU		1	
⊙	5	302LH94210	2LH94210	PARTS PWB CODE DIMM ASSY SP	1	1	1
⊙	6	302LH94230	2LH94230	PARTS MEMORY MODULE SP	2	2	2
⊙	7	302LK93070	2LK93070	PARTS STORAGE DEVICE SP	1	1	1
⊙	8	302LH94010	2LH94010	PARTS UNIT LOW VOLTAGE 100 SP	1		
⊙	8	302LH94020	2LH94020	PARTS UNIT LOW VOLTAGE 200 SP		1	1
	9	302K946A00	2K946A00	WIRE FFC MAIN-ENGINE	1	1	1
⊙	10	302LH94170	2LH94170	PARTS PWB ENGINE ASSY SP	1	1	1
⊙	11	302LF94260	2LF94260	PARTS UNIT HIGH VOLTAGE MAIN SP (55 ppm)	1	1	1
⊙	11	302LJ94010	2LJ94010	PARTS UNIT HIGH VOLTAGE MAIN SP (45/35 ppm)	1	1	1
	12	302K946050	2K946050	WIRE FFC FEED1	1	1	1
	13	302K946060	2K946060	WIRE FFC FEED2	1	1	1
	14	302K946070	2K946070	WIRE FFC FEED 3	1	1	1
⊙	15	302K994181	2K994181	PARTS PWB FEED 1 ASSY SP (55/45 ppm)	1	1	1
⊙	15	302LN94040	2LN94040	PARTS PWB FEED 1 ASSY SP (35 ppm)	1	1	1
	101	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	102	7BB200320H	BB113430	+BIND T.T P SCREW 3X20			
	103	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	104	7BB000303H	BB107000	+BIND M SCREW 3X3			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 20 Operation Section

2LL/2LJ/2LH




FIG. 20 Operation Section

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	1	302LC05020	2LC05020	COVER OPERATION B	1	1	1
	A01	302LH94070	2LH94070	PARTS OPERATION UNIT SP	1	1	1
⊙	2	•302H705610	2H705610	CUSHION LCD	2	2	2
	3	•302K505280	2K505280	SPONGE LCD B	2	2	2
⊙	4	•302K994240	2K994240	PARTS PWB OPERATION ASSY SP	1	1	1
	5	•302K994250	2K994250	PARTS PWB OPERATION LED ASSY SP	1	1	1
⊙	6	•302KY94150	2KY94150	PARTS LCD OPERATION SP	1	1	1
	7	•302LC94250	2LC94250	PARTS PWB PANEL MAIN ASSY SP	1	1	1
⊙	8	•302LC05010	2LC05010	COVER OPERATION A	1	1	1
	9	•302LC05050	2LC05050	KEY 10	1	1	1
⊙	10	•302LC94340	2LC94340	PARTS TABLET OPERATION SP	1	1	1
	11	•302LC05070	2LC05070	KEY FUNCTION	1	1	1
⊙	12	•302LC05080	2LC05080	KEY UNIVERSAL	1	1	1
	13	•302LC05090	2LC05090	KEY START	1	1	1
⊙	14	•302LC05100	2LC05100	KEY STOP	1	1	1
	15	•302LC05110	2LC05110	KEY RESET	1	1	1
⊙	16	•302LC05120	2LC05120	KEY POWER SUPPLY	1	1	1
	17	•302LC05150	2LC05150	LID OPERATION SHEET A	1	1	1
⊙	18	•302LC05160	2LC05160	LID OPERATION SHEET B	1	1	1
	19	302LF05010	2LF05010	PANEL OPERATION	1	1	1
⊙	20	302LH05020	2LH05020	LABEL OPERATION EN	1	1	1
	21	75018250	75018250	SPRING CLEANING SOLENOID	2	2	2
⊙	22	302GR05120	2GR05120	MOUNT SLIDE	1	1	1
	23	302H005340	2H005340	BUSH SLIDE OPE	2	2	2
⊙	24	302H005690	2H005690	PIN HINGE OPE C	4	4	4
	25	302H705350	2H705350	BUSH PIN OPE	2	2	2
⊙	26	302LC05370	2LC05370	HANDLE OPERATION	1	1	1
	27	302LC94370	2LC94370	PARTS SPEAKER SP	1	1	1
⊙	28	302LH05040	2LH05040	LABEL OPERATION DE		1	
	29	302LH05050	2LH05050	LABEL OPERATION FR	1	1	
⊙	30	302LH05060	2LH05060	LABEL OPERATION TL		1	
	31	302LH05070	2LH05070	LABEL OPERATION ES	1	1	
⊙	32	302LH05080	2LH05080	LABEL OPERATION PT	1	1	
	33	302LH05090	2LH05090	LABEL OPERATION NL		1	
⊙	34	302LH05100	2LH05100	LABEL OPERATION RU		1	
	101	7BB700312H	BB106820	+BIND T.T S SCREW 3X12 SR			
⊙	102	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			
	103	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
⊙	104	7BB180306H	BB111190	+BIND T.T S SCREW 3X6(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.




FIG. 21 Options 1

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
	A01	1202H70UN0	022H70UN	PLATEN COVER TYPE(E) (OPTION)	1	1	1
	1	•302H717500	2H717500	COVER PLATEN	1	1	1
	2	•302H717510	2H717510	COVER POCKET	1	1	1
	3	•302H717520	2H717520	STOPPER RELEASE SWITCH	2	2	2
	4	•302H717600	2H717600	HINGI ORIGINAL HOLDER	2	2	2
	5	•303JC04200	3JC04200	PLATE ORIGINAL	1	1	1
	6	•303K502080	3K502080	SPONGE ORIGINAL MAT	4	4	4
	7	•303MX02021	3MX02021	CUSHION ORIGINAL MAT A	4	4	4
	8	•303MX02031	3MX02031	CUSHION ORIGINAL MAT B	4	4	4
	101	7BB280410H	BB111250	+BIND T.T P SCREW 4X10(BLACK)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.






FIG. 22 Options 2


2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
• • • • • • • • • • • • • •	A01	1902LC0UN1	092LC0U1	DT-730/DOCUMENT TRAY (OPTION)	1	1	1
	1	•302LC04600	2LC04600	COVER TRAY	1	1	1
	2	•302LC04660	2LC04660	SHEET TRAY	2	2	2
	3	•302LC04710	2LC04710	COVER TRAY LOWER	1	1	1
	4	•303NS24410	3NS24410	SCREW PLATE DF	2	2	2
	5	302LC94530	2LC94530	PARTS DUCT OPTION REAR SET SP	1	1	1
	A02	302K994930	2K994930	PARTS DEHUMIDIFINR 120 SET SP	1		
	A02	302K994940	2K994940	PARTS DEHUMIDIFINR 240 SET SP		1	1
	6	•302H794620	2H794620	PARTS HEATER DEHUMIDIFIER 120	1		
	6	•302H794610	2H794610	PARTS HEATER DEHUMIDIFIER 240		1	1
	7	•7YZM610001++H01	YZ010230	ACCESS SADDLE	3	3	3
	101	3CY06030	3CY06030	RETAINER M4			
	102	7BB607414H	BB107160	+TP-CUP M SCREW 4X14 R			
	103	7BB180408H	BB111210	+BIND T.T S SCREW 4X8(BLACK)			
	104	7BB200308H	BB105660	+BIND T.T P SCREW 3X8			
	105	7BB282308H	BB111240	+TP-FLAT T.T P SCREW 3X8(BLACK)			
	106	7BB782308H	BB111300	+TP-FLAT T.T S SCREW 3X8 SR(BLACK)			
	107	7BB700308H	BB105600	+BIND T.T S SCREW 3X8 SR			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.



Tools




FIG. 23 Options 3 & Tools

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
⊙	A01	302A369709	2A369708	SET PARTS KEYCOUNTER NEW COLOR	1	1	1
	1	•3029236241	29236241	SOCKET ASS'Y,KEY COUNTER	1	1	1
	2	•302GR03010	2GR03010	RETAINER KEY COUNTER COVER	1	1	1
	3	•302GR03020	2GR03020	RETAINER KEY COUNTER	1	1	1
	4	•3066060011	66060011	COVER,KEY COUNTER	1	1	1
	5	•3066060041	66060041	MOUNT,KEY COUNTER	1	1	1
	6	•7YZM210006++H01	YZ038000	ACCESS.EDGING	2	2	2
	7	•M21AH010	M21AH010	BAND,RSG-130-V0(KITAGAWA)	1	1	1
	8	3025418011	25418011	KEY COUNTER	1	1	1
	9	302FZ17100	2FZ17100	PIN POSITIONING SP	2	2	2
	10	35968110	35968110	STOPPER WIRE ASS'Y SP	2	2	2
	11	302K946AJ0	2K946AJ0	WIRE KEY COUNTER	1	1	1
⊙	101	5MBTPB3008PW++R	B1A63080	BIND T.T SCREW(+) / M3 X 8 CRFREE P-T			
	102	5MBTPB4010PW++R	B1A64100	BIND T.T SCREW(+) / M4 X 10 CRFREE P-T			
	103	5MBTPB4010TW++R	B1A54100	BIND T.T SCREW(+) / M4 X 10 CRFREE S-T			
	104	7BB003306H	BB040750	+COUNTER-SUNK HEAD SCREW M3X6 CRFREE			
	105	7BB100420H	BB040740	+BIND TAP-TITE S SCREW M4X20 CRFREE			
	106	7BC1003055++H01	BC018230	HEXA NUT M3			
	107	B1B03080	B1B03080	+BIND SCREW M3X08			
	108	B1B54300	B1B54300	+BIND TAP-TITE S SCREW M4X30(TRIVALENT C			
	109	B4A04060	B4A04060	+TP-A SCREW M4X06(TRIVALENT CHROMATING)			
	110	B4A04100	B4A04100	+TP-A SCREW M4X10(TRIVALENT CHROMATING)			

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assemblies with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

FIG. 24 Maintenance Kits

2LL/2LJ/2LH

	Ref. No.	Part.No.	Alternative Part.No.	Description	Quantity		
					120	230	240
		1702LH7US1	072LH7U1	MK-6305A/MAINTENANCE KIT (OPTION) PARTS FILTER EXIT UNIT SP PARTS FILTER TONER UNIT(V) SP PARTS BELT ASSY SP DK-6305 DV-6305 FK-6306	1 1 1 1 1 1 1		
		1702LH8KL0	072LH8KL	MK-6305A/MAINTENANCE KIT (OPTION) PARTS FILTER EXIT UNIT SP PARTS FILTER TONER UNIT(V) SP PARTS BELT ASSY SP DK-6305 DV-6305 FK-6307		1 1 1 1 1 1 1	1 1 1 1 1 1 1

Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

Parts with "⊙" indicate regular maintenance parts.

INDEX

2LL/2LJ/2LH

	Part.No.	Alternative	Description	Fig.No.
	1202H70UN0	022H70UN	PLATEN COVER TYPE(E)	21
	1702LH7US1	072LH7U1	MK-6305A/MAINTENANCE KIT	24
	1702LH8KL0	072LH8KL	MK-6305A/MAINTENANCE KIT	24
	1902LC0UN1	092LC0U1	DT-730/DOCUMENT TRAY	22
	1902LH0UN0	092LH0UN	WT-862/WASTE TONER BOTTLE	12
⊙	2AR07220	2AR07220	PULLEY,PAPER FEED	8
	2AR07230	2AR07230	PULLEY,SEPARATION	5,8
	2AR27800	2AR27800	POWER CORD(230)	18
	2BC06510	2BC06510	BUSHING 8	7
	2BC06910	2BC06910	STOPPER 6	6,7
	2BL07950	2BL07950	UNDER CLEANER REGIST	7
	2C912430	2C912430	LID KMAS	2
	2FB04270	2FB04270	PLATE MAGNET	1
	2FB07330	2FB07330	STOPPER BYPASS TABLE	9
	2FB16270	2FB16270	PIN DRAWER A	3
	2FB27160	2FB27160	INTER LOCK SWITCH	18
⊙	2FG27110	2FG27110	SWITCH REGISTRATION	6
	2FM02210	5MVM274DN002	PULLEY MID /B-11 FRAME A4	17
⊙	2FM02320	5MVG144DN003	GEAR FD Z31 /B-11 FRAME A4	17
	2FM04150	5MVM163DN005	CAP SPRING /B-11 ENCLOSURE A4	17
	3019527401	19527401	POWER CORD(120)	18
⊙	3025418011	25418011	KEY COUNTER	23
	3029236241	29236241	SOCKET ASS'Y,KEY COUNTER	23
⊙	302A369709	2A369708	SET PARTS KEYCOUNTER NEW COLOR	23
⊙	302BM07410	2BM07410	GEAR GUIDE SIDE	4
	302F906230	2F906230	PULLEY FEED ASSY	5
	302F909171	2F909171	RETARD ROLLER ASSY	5
	302F929260	2F929260	PULLEY DU LOW	17
	302FZ01310	2FZ01310	VARIATOR TC ASS'Y	7
	302FZ02580	2FZ02580	CAP HANDLE	3
	302FZ03110	2FZ03110	SEAL HANDLE	3
	302FZ17100	2FZ17100	PIN POSITIONING SP	23
	302FZ28270	2FZ28270	SPRING EXIT PUSH	17
⊙	302FZ94420	2FZ94420	PARTS,FAN COOLING CONVEYING SP	7,16
⊙	302FZ94660	2FZ94660	PARTS,FAN IMAGE SP	16
	302GR03010	2GR03010	RETAINER KEY COUNTER COVER	23
	302GR03020	2GR03020	RETAINER KEY COUNTER	23
	302GR04370	2GR04370	MAGNET CLIP DISH	2
	302GR04380	2GR04380	SEAL MAGNET	2
	302GR05120	2GR05120	MOUNT SLIDE	20

	Part.No.	Alternative	Description	Fig.No.
◉	302GR06110	2GR06110	TORQUE LIMITER 360	8,12
◉	302GR44080	2GR44080	FAN LSU 60-25	16
	302H004660	2H004660	MAGNET CATCH	2
	302H005340	2H005340	BUSH SLIDE OPE	20
	302H005690	2H005690	PIN HINGE OPE C	20
◉	302H006120	2H006120	GEAR Z20S JOINT FEED B	15
	302H024370	2H024370	BUSH 6 EW	17
◉	302H044110	2H044110	SENSOR ORIGINAL	10
◉	302H094300	2H094300	PARTS,HUMIDITY SENSOR,SP	1
	302H703100	2H703100	SHUTTER PIPE UP	11
	302H703130	2H703130	SEAL PIPE DLP UP	11
	302H703240	2H703240	SPRING PIPE UP	11
	302H703570	2H703570	SEAL CONT SHUTTER	11
	302H705350	2H705350	BUSH PIN OPE	20
	302H705610	2H705610	CUSHION LCD	20
	302H717500	2H717500	COVER PLATEN	21
	302H717510	2H717510	COVER POCKET	21
	302H717520	2H717520	STOPPER RELEASE SWITCH	21
	302H717600	2H717600	HINGI ORIGINAL HOLDER	21
◉	302H728080	2H728080	GEAR Z23S EXIT	17
◉	302H794610	2H794610	PARTS HEATER DEHUMIDIFIER 240	22
◉	302H794620	2H794620	PARTS HEATER DEHUMIDIFIER 120	22
	302HG02450	2HG02450	SEAL FRAME MIDDLE A	16
	302HN06080	2HN06080	PULLEY PICKUP ASSY	5
	302HN28120	2HN28120	SPRING PULLEY A	17
◉	302HN44010	2HN44010	FAN MOTOR	16
	302JF22010	2JF22010	PULLEY MIDDLE	17
◉	302K301140	2K301140	PWB RFID ASSY WITH SOFTWARE	15
◉	302K394190	2K394190	PARTS MOTOR LIFT ASSY SP	18
	302K505280	2K505280	SPONGE LCD B	20
◉	302K903130	2K903130	GEAR Z35S	15
◉	302K903140	2K903140	GEAR Z18S	15
◉	302K906230	2K906230	GEAR PRIMARY FEED IDLE Z20R Z16L	5
	302K906320	2K906320	ACTUATOR PAPER EMPTY	5
	302K906340	2K906340	PULLEY RETARD	5
	302K906560	2K906560	ACTUATOR FEED LOW	6
	302K906600	2K906600	COVER FEED LOW	6
	302K906690	2K906690	LID SIDE FEED	6
	302K908030	2K908030	TRAY MPF A	9
	302K908040	2K908040	TRAY MPF B	9

	Part.No.	Alternative	Description	Fig.No.
⊙	302K908050	2K908050	TRAY MPF C	9
	302K908060	2K908060	TRAY MPF D	9
	302K908120	2K908120	RACK CURSOR MPF	9
	302K908211	2K908211	ACTUATOR SIZE DETECTION	9
	302K908280	2K908280	ACTUATOR FEED MPF	8
	302K908290	2K908290	ACTUATOR PAPER SET	8
	302K909060	2K909060	RACK CURSOR	4
	302K909270	2K909270	ACTUATOR PAPER LEVEL DETECTION	4
	302K909530	2K909530	SLIDER CASSETTE	3
	302K909620	2K909620	PULLEY CASSETTE	3
	302K914370	2K914370	SPRING SHUTTER	11
	302K915240	2K915240	SHUTTER HOPPER UP	11
	302K915320	2K915320	SEAL SHUTTER	11
	302K921120	2K921120	STOPPER 8	6
	302K924300	2K924300	SLIDER CONVEYING	3
	302K924510	2K924510	GEAR Z24L	6
	302K924560	2K924560	SHEET REGIST L A	6
	302K924580	2K924580	ACTUATOR LOOP	6
	302K924880	2K924880	SHEET REGIST L C	6
	302K924890	2K924890	SHEET COVER SENSOR	6
	302K928190	2K928190	SPRING-TORSION SWITCHBACK	17
	302K929070	2K929070	COVER DU	8
	302K929201	2K929201	COVER RIGHT	2
	302K929330	2K929330	ACTUATOR DU	7
	302K933580	2K933580	SEAL DUCT EXIT	16
	302K934010	2K934010	LABEL PAPER SIZE A	4
	302K934020	2K934020	LABEL PAPER SIZE B	4
	302K934040	2K934040	LABEL SET PAPER	4
	302K934050	2K934050	LABEL CASSETTE NUMBER 1	4
	302K934060	2K934060	LABEL CASSETTE NUMBER 2	4
	302K934090	2K934090	LABEL CASSETTE PAPER MAX	4
	302K934100	2K934100	LABEL CASSETTE CURSOR LOCK	4
	302K934120	2K934120	SHEET CASSETTE PAPER MEDIA EN	4
	302K934130	2K934130	CASSETTE PAPER SIZE	4
	302K934220	2K934220	SHEET CASSETTE PAPER SET A	4
	302K934230	2K934230	SHEET CASSETTE PAPER SET B	4
	302K939360	2K939360	SPRING HV	18
	302K946050	2K946050	WIRE FFC FEED1	19
	302K946060	2K946060	WIRE FFC FEED2	19
	302K946070	2K946070	WIRE FFC FEED 3	19

	Part.No.	Alternative	Description	Fig.No.
	302K946670	2K946670	WIRE FFC CCD	10
	302K946710	2K946710	WIRE FFC LED	10
	302K946990	2K946990	WIRE FFC KUO	19
	302K946A00	2K946A00	WIRE FFC MAIN-ENGINE	19
	302K946AJ0	2K946AJ0	WIRE KEY COUNTER	23
⊙	302K993010	2K993010	CT-8705	4
⊙	302K993020	2K993020	PARTS FEED DRIVE H UNIT SP	15
⊙	302K993040	2K993040	PARTS MOUNT LED ASSY SP	10
⊙	302K994010	2K994010	PARTS MPT ASSY SP	8
⊙	302K994020	2K994020	PARTS PRIMARY FEED UNIT HI SP	5
⊙	302K994030	2K994030	PARTS CONTACT-GLASS ASSY(I) SP	10
⊙	302K994040	2K994040	PARTS CONTACT-GLASS ASSY(C) SP	10
⊙	302K994050	2K994050	PARTS MPT TRAY UNIT SP	9
⊙	302K994090	2K994090	PARTS FAN FUSER FRONT UNIT SP	16
⊙	302K994100	2K994100	PARTS FILTER EXIT UNIT SP	2
⊙	302K994120	2K994120	PARTS SIZE DETECTION ASSY SP	18
⊙	302K994130	2K994130	PARTS GUIDE FEED MIDDLE ASSY SP	6
⊙	302K994150	2K994150	PARTS TONER FULL DETECT ASSY SP	12
⊙	302K994160	2K994160	PARTS ID SENSOR ASSY SP	7
⊙	302K994181	2K994181	PARTS PWB FEED 1 ASSY SP	19
⊙	302K994190	2K994190	PARTS PWB FEED 2 ASSY SP	15
⊙	302K994201	2K994201	PARTS PWB JUNCTION ASSY SP	7
⊙	302K994210	2K994210	PARTS PWB EDGE SENSOR ASSY SP	6
⊙	302K994230	2K994230	PARTS PWB ISC ASSY SP	10
⊙	302K994240	2K994240	PARTS PWB OPERATION ASSY SP	20
⊙	302K994250	2K994250	PARTS PWB OPERATION LED ASSY SP	20
⊙	302K994270	2K994270	PARTS PWB KUO ASSY SP	19
⊙	302K994300	2K994300	PARTS MOTOR PM FEED SP	17
⊙	302K994310	2K994310	PARTS MOTOR HB MID SP	6
⊙	302K994320	2K994320	PARTS MOTOR-BL W20 SP	14,15
⊙	302K994330	2K994330	PARTS MOTOR-BL W30 SP	15
⊙	302K994340	2K994340	PARTS FAN BOX COOLING 60 SP	19
⊙	302K994350	2K994350	PARTS FAN COOLING DLP 70 SP	16
⊙	302K994360	2K994360	PARTS FAN COOLING LSU 60 SP	18
⊙	302K994370	2K994370	PARTS SOLENOID FEED SHIFT SP	17
⊙	302K994380	2K994380	PARTS SOLENOID FEED SHIFT SP	5
⊙	302K994390	2K994390	PARTS SOLENOID ID SENSOR SP	7
⊙	302K994420	2K994420	PARTS ROLLER ASSIST SP	5
⊙	302K994430	2K994430	PARTS ROLLER FEED LOW SP	6
⊙	302K994450	2K994450	PARTS ROLLER REGIST L SP	6

	Part.No.	Alternative	Description	Fig.No.
⊙	302K994460	2K994460	PARTS ROLLER MIDDLE L SP	6
⊙	302K994470	2K994470	PARTS ROLLER DU LOW SP	7
⊙	302K994480	2K994480	PARTS ROLLER DU MID SP	7
⊙	302K994490	2K994490	PARTS ROLLER DU UP SP	7
⊙	302K994530	2K994530	PARTS GEAR Z30R FEED OW SP	5
⊙	302K994540	2K994540	PARTS GEAR Z30R ONE-WAY SP	8
⊙	302K994550	2K994550	PARTS GEAR CURSOR SP	4
⊙	302K994580	2K994580	PARTS SENSOR OPT. SP	5
⊙	302K994620	2K994620	PARTS PWB MPF SIZE ASSY SP	9
⊙	302K994930	2K994930	PARTS DEHUMIDIFINR 120 SET SP	22
⊙	302K994940	2K994940	PARTS DEHUMIDIFINR 240 SET SP	22
⊙	302K994980	2K994980	PARTS MOTOR PM REGIST SP	7,14
⊙	302KV44041	2KV44041	CLUTCH 50 Z35R	6,7,8,15
⊙	302KY94150	2KY94150	PARTS LCD OPERATION SP	20
⊙	302LC02710	2LC02710	COVER HUMIDITY SENSOR	1
	302LC02720	2LC02720	SHEET HUMIDITY SENSOR A	1
	302LC02730	2LC02730	SHEET HUMIDITY SENSOR B	1
	302LC02760	2LC02760	SHEET COVER HUMIDITY SENSOR	1
⊙	302LC03130	2LC03130	GEAR Z20S	15
⊙	302LC03140	2LC03140	GEAR Z30S COUPLING	15
⊙	302LC04020	2LC04020	COVER FRONT B	1
⊙	302LC04030	2LC04030	COVER TOP TRAY	1
⊙	302LC04040	2LC04040	COVER RIGHT UPPER	2
⊙	302LC04050	2LC04050	COVER RIGHT LOWER F	1
⊙	302LC04060	2LC04060	COVER RIGHT MIDDLE R	1
⊙	302LC04070	2LC04070	COVER RIGHT LOWER R	1
⊙	302LC04080	2LC04080	COVER RIGHT MIDDLE	2
⊙	302LC04090	2LC04090	COVER LEFT UPPER	2
	302LC04120	2LC04120	COVER ISU FRONT	10
	302LC04130	2LC04130	COVER ISU LEFT	10
	302LC04140	2LC04140	COVER ISU RIGHT	10
⊙	302LC04150	2LC04150	COVER ISU REAR	2
⊙	302LC04160	2LC04160	COVER FRONT UPPER A	2
⊙	302LC04170	2LC04170	COVER FRONT UPPER B	2
⊙	302LC04180	2LC04180	COVER FRONT UPPER RIGHT	2
⊙	302LC04190	2LC04190	COVER EXIT	1
⊙	302LC04200	2LC04200	COVER TRAY REAR	1
⊙	302LC04210	2LC04210	COVER ISU BOTTOM	1
⊙	302LC04240	2LC04240	COVER FRONT RIGHT LOWER	1
⊙	302LC04250	2LC04250	COVER INNER LEFT	1

	Part.No.	Alternative	Description	Fig.No.
⊙	302LC04260	2LC04260	COVER INNER FEED F	1
	302LC04270	2LC04270	EMBLEM	1
⊙	302LC04280	2LC04280	COVER HANDLE	1
⊙	302LC04290	2LC04290	COVER MAIN SWITCH	1
	302LC04300	2LC04300	LID CONTROLLER	2
⊙	302LC04320	2LC04320	COVER DP CONNECTOR	2
	302LC04330	2LC04330	LID DP CONNECTOR	2
⊙	302LC04340	2LC04340	COVER ISU LEFT SUB	2
	302LC04350	2LC04350	CASE CLIP	2
	302LC04410	2LC04410	MOUNT FRONT COVER LEFT	1
	302LC04440	2LC04440	HOLDER CLIP CASE	2
	302LC04460	2LC04460	STOPPER CONTAINER	1
	302LC04470	2LC04470	LID FAX BOARD	2
	302LC04480	2LC04480	MOUNT COVER LEFT	2
	302LC04490	2LC04490	PLATE FRONT COVER	1
⊙	302LC04600	2LC04600	COVER TRAY	22
	302LC04650	2LC04650	STRAP FRONT COVER	1
	302LC04660	2LC04660	SHEET TRAY	22
⊙	302LC04710	2LC04710	COVER TRAY LOWER	22
	302LC04720	2LC04720	STOPPER ORIGINAL	1
	302LC04730	2LC04730	SHEET COVER FRONT	1
	302LC04750	2LC04750	SPONGE COVER FRONT B	1
	302LC05010	2LC05010	COVER OPERATION A	20
	302LC05020	2LC05020	COVER OPERATION B	20
	302LC05050	2LC05050	KEY 10	20
	302LC05070	2LC05070	KEY FUNCTION	20
	302LC05080	2LC05080	KEY UNIVERSAL	20
	302LC05090	2LC05090	KEY START	20
	302LC05100	2LC05100	KEY STOP	20
	302LC05110	2LC05110	KEY RESET	20
	302LC05120	2LC05120	KEY POWER SUPPLY	20
	302LC05150	2LC05150	LID OPERATION SHEET A	20
	302LC05160	2LC05160	LID OPERATION SHEET B	20
	302LC05370	2LC05370	HANDLE OPERATION	20
	302LC06060	2LC06060	ACTUATOR PAPER EMPTY	5
	302LC28090	2LC28090	ACTUATOR EXIT SENSOR	17
	302LC28100	2LC28100	SPRING-COMPRESSION	17
	302LC28110	2LC28110	SPRING-EXTENSION	17
	302LC28150	2LC28150	SPRING-COMPRESSION	17
	302LC28210	2LC28210	ACTUATOR SWITCHBACK	17

	Part.No.	Alternative	Description	Fig.No.
⊙	302LC29050	2LC29050	ACTUATOR DU B	7
	302LC29080	2LC29080	COVER RIGHT FRONT	2
	302LC31750	2LC31750	GEAR Z60L	6
	302LC34030	2LC34030	LABEL OPERATION CAUTION B	2
	302LC34050	2LC34050	LABEL SW CAUTION EN	1
	302LC34060	2LC34060	LABEL MPF CAUTION A	9
	302LC34070	2LC34070	LABEL MPF CAUTION B	2
	302LC34080	2LC34080	LABEL MPF PAPER LIMIT	9
	302LC34090	2LC34090	LABEL MPF SIZE INDICATOR ME	9
	302LC34100	2LC34100	LABEL MPF SIZE INDICATOR IN	9
	302LC34110	2LC34110	LABEL MPF PUSH	2
	302LC34160	2LC34160	LABEL SW CAUTION SET A	1
	302LC34180	2LC34180	LABEL MPF SET A	2
	302LC46230	2LC46230	WIRE FRONT LOW	1
	302LC46360	2LC46360	WIRE EXIT	17
	302LC93120	2LC93120	PARTS FEED DRIVE L SP	15
	302LC94020	2LC94020	PARTS MPT ASSY SP	8
	302LC94030	2LC94030	PARTS EXIT UNIT B SP	17
	302LC94040	2LC94040	PARTS PRIMARY FEED UNIT LOW SP	5
	302LC94130	2LC94130	PARTS FILTER BELT UNIT(V) SP	2
	302LC94140	2LC94140	PARTS FILTER TONER UNIT(V) SP	2
	302LC94190	2LC94190	PARTS CONV RELEASE MOTOR ASSY SP	12
	302LC94200	2LC94200	PARTS MPT LIFT MOTOR ASSY SP	8
	302LC94250	2LC94250	PARTS PWB PANEL MAIN ASSY SP	20
	302LC94290	2LC94290	PARTS MOTOR-BL W10 SP	7,14
	302LC94340	2LC94340	PARTS TABLET OPERATION SP	20
	302LC94350	2LC94350	PARTS ROLLER EXIT SP	17
	302LC94360	2LC94360	PARTS GEAR Z40R Z14S IDLE SP	17
	302LC94370	2LC94370	PARTS SPEAKER SP	20
	302LC94380	2LC94380	PARTS FAN COOLING LSU 60 SP	12
	302LC94410	2LC94410	PARTS SENSOR OPT. SP	7
	302LC94460	2LC94460	PARTS MOTOR-BL W20 DRUM Z11 SP	14
	302LC94470	2LC94470	PARTS COVER GUIDE DU L ASSY SP	8
	302LC94480	2LC94480	PARTS WASTE TRAY UNIT SP	12
	302LC94490	2LC94490	PARTS COVER CASSETTE A ASSY SP	4
	302LC94500	2LC94500	PARTS COVER CASSETTE B ASSY SP	4
	302LC94520	2LC94520	PARTS COVER FRONT SP	1
	302LC94530	2LC94530	PARTS DUCT OPTION REAR SET SP	22
	302LF04070	2LF04070	COVER REAR UPPER	2
	302LF04080	2LF04080	COVER REAR LOWER	2

	Part.No.	Alternative	Description	Fig.No.
⊙	302LF05010	2LF05010	PANEL OPERATION	20
⊙	302LF24150	2LF24150	ROLLER REGIST R	7
⊙	302LF39010	2LF39010	TERMINAL HV SEPARATION	18
⊙	302LF39020	2LF39020	TERMINAL HV DRUM	18
⊙	302LF39080	2LF39080	SPRING HV DRUM	18
⊙	302LF46010	2LF46010	WIRE FFC LSU	18
⊙	302LF93020	2LF93020	MC-6705	11
⊙	302LF93070	2LF93070	DR-6705	14
⊙	302LF94060	2LF94060	PARTS BELT ASSY SP	7
⊙	302LF94070	2LF94070	PARTS ID SENSOR ASSY SP	7
⊙	302LF94080	2LF94080	PARTS CONT DRIVE UNIT K SP	15
⊙	302LF94140	2LF94140	PARTS MOUNT LED UNIT SP	18
⊙	302LF94160	2LF94160	PARTS CLEANER REGIST ASSY SP	6
⊙	302LF94220	2LF94220	PARTS PWB LSU JUNC MONO ASSY SP	18
⊙	302LF94260	2LF94260	PARTS UNIT HIGH VOLTAGE MAIN SP	19
⊙	302LG93010	2LG93010	LK-6706	10
⊙	302LH04020	2LH04020	COVER INNER FAN	2
⊙	302LH04030	2LH04030	COVER LEFT	2
⊙	302LH05020	2LH05020	LABEL OPERATION EN	20
⊙	302LH05040	2LH05040	LABEL OPERATION DE	20
⊙	302LH05050	2LH05050	LABEL OPERATION FR	20
⊙	302LH05060	2LH05060	LABEL OPERATION TL	20
⊙	302LH05070	2LH05070	LABEL OPERATION ES	20
⊙	302LH05080	2LH05080	LABEL OPERATION PT	20
⊙	302LH05090	2LH05090	LABEL OPERATION NL	20
⊙	302LH05100	2LH05100	LABEL OPERATION RU	20
⊙	302LH31010	2LH31010	PLATE REGIST DRIVE	14
⊙	302LH34010	2LH34010	SHEET EMBLEM 5500	1
⊙	302LH93010	2LH93010	DK-6305	11
⊙	302LH93030	2LH93030	DV-6305	11
⊙	302LH93050	2LH93050	FK-6306	13
⊙	302LH93060	2LH93060	FK-6307	13
⊙	302LH94010	2LH94010	PARTS UNIT LOW VOLTAGE 100 SP	19
⊙	302LH94020	2LH94020	PARTS UNIT LOW VOLTAGE 200 SP	19
⊙	302LH94030	2LH94030	PARTS INNER UNIT SP	12
⊙	302LH94040	2LH94040	PARTS CONVEYING H UNIT(GAIA) SP	7
⊙	302LH94070	2LH94070	PARTS OPERATION UNIT SP	20
⊙	302LH94090	2LH94090	PARTS GUIDE FEED REGIST ASSY SP	6
⊙	302LH94100	2LH94100	PARTS FUSER DRIVE UNIT SP	14
⊙	302LH94110	2LH94110	PARTS DLP MOTOR ASSY(G) SP	14

	Part.No.	Alternative	Description	Fig.No.
⊙	302LH94120	2LH94120	PARTS HUMIDITY ASSY (G) SP	18
⊙	302LH94130	2LH94130	PARTS WASTE BOTTLE CASE ASSY SP	12
⊙	302LH94140	2LH94140	PARTS PWB MAIN ASSY SP	19
⊙	302LH94150	2LH94150	PARTS PWB MAIN ASSY SP EU	19
⊙	302LH94170	2LH94170	PARTS PWB ENGINE ASSY SP	19
⊙	302LH94180	2LH94180	PARTS PWB HEATER 100 ASSY SP	18
⊙	302LH94190	2LH94190	PARTS PWB HEATER 200 ASSY SP	18
⊙	302LH94210	2LH94210	PARTS PWB CODE DIMM ASSY SP	19
⊙	302LH94230	2LH94230	PARTS MEMORY MODULE SP	19
⊙	302LH94260	2LH94260	PARTS PWB FRONT MONO ASSY SP	18
	302LJ34010	2LJ34010	SHEET EMBLEM 4500	1
⊙	302LJ94010	2LJ94010	PARTS UNIT HIGH VOLTAGE MAIN SP	19
⊙	302LK93070	2LK93070	PARTS STORAGE DEVICE SP	19
⊙	302LK93080	2LK93080	PARTS IMAGE SCANNER L SP	10
⊙	302LK94060	2LK94060	PARTS ROLLER DU LOW SP	7
⊙	302LK94070	2LK94070	PARTS ROLLER DU UP SP	7
	302LL34010	2LL34010	SHEET EMBLEM 3500	1
⊙	302LL94010	2LL94010	PARTS CONVEYING H UNIT(GAIA) SP	7
⊙	302LL94040	2LL94040	PARTS GUIDE FEED REGIST ASSY SP	6
⊙	302LN94040	2LN94040	PARTS PWB FEED 1 ASSY SP	19
⊙	302LN94050	2LN94050	PARTS PWB FEED 2 ASSY SP	15
	3033915181	33915181	TONER EMPTY DETECTION SENSOR	12
	303JC04200	3JC04200	PLATE ORIGINAL	21
	303K502080	3K502080	SPONGE ORIGINAL MAT	21
	303LL07521	3LL07521	TORQUE-LIMITER 400	5,8
⊙	303M894260	3M894260	PARTS SENSOR OPT SP	5,6,8,18
	303MX02021	3MX02021	CUSHION ORIGINAL MAT A	21
	303MX02031	3MX02031	CUSHION ORIGINAL MAT B	21
	303NS24410	3NS24410	SCREW PLATE DF	22
	3066060011	66060011	COVER,KEY COUNTER	23
	3066060041	66060041	MOUNT,KEY COUNTER	23
	35968110	35968110	STOPPER WIRE ASS'Y SP	23
⊙	3H327410	3H327410	SENSOR,CONVEYING	6
	3HL06110	3HL06110	TERMINAL PAPER SIZE	9
	5MMW261LD055	2A820350	SPRING SEPARATOR /FS-1000 A4	6
	5MVX111DN003	2A806250	RING STOPPER /A-49 FEED A4	4,5,6,7,12,15,17
	63212210	63212210	STATIC ELIMINATOR,EJECT	17
⊙	66127010	66127010	SWITCH,COVER OPEN	7
	75018250	75018250	SPRING CLEANING SOLENOID	20
	7AAACCAS+10H001	AA063380	AC CORD ASSY AS	18

	Part.No.	Alternative	Description	Fig.No.
⊙	7BE006103431H01	BE122720	BEARING MR106ZZ	7
⊙	7BE006124431H01	BE119720	BEARING MR126ZZ	6
⊙	7NXGP1A173LCH01	NX115300	SENSOR OPT.	7,8,9,12,17
⊙	7NXGP1S173LCH01	NX116910	SENSOR OPT.	10
⊙	7SC010202+++H01	SC122390	SW.SEESAW	18
⊙	7SP01000006+H01	SP121020	SW.PUSH	6,9
	7YZM210006++H01	YZ038000	ACCESS.EDGING	23
	7YZM610001++H01	YZ010230	ACCESS SADDLE	22
	M21AH010	M21AH010	BAND,RSG-130-V0(KITAGAWA)	23

KYOCERA MITA EUROPE B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31.20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Beechavenue 25, 1119RA Schiphol-Rijk
The Netherlands
Phone: +31.20.58.77.200

KYOCERA MITA (UK) LTD
8 Beacontree Plaza
Gillette Way Reading Berks RG2 0BS,
U.K.
Phone: +44.1189.311.500

KYOCERA MITA ITALIA S.p.A.
Via G. Verdi, 89 / 91, 20063 Cernusco s/N
Milano, Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Sint-Martinusweg 199-201, 1930 Zaventem,
Belgium
Phone: +32.2.720.9270

KYOCERA MITA FRANCE S.A.
Espace Technologique de St Aubin
Route de l' Orme
91195 Gif-sur-Yvette CEDEX, France
Phone: +33.1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor No. 2,
28290 Las Matas (Madrid),
Spain
Phone: +34.91.631.8392

KYOCERA MITA FINLAND OY
Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358.9.4780.5200

KYOCERA MITA (SCHWEIZ)
Hohlstrasse 614, 8048 Zürich
Switzerland
Phone: +41.44.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Otto-Hahn-Str. 12 D-40670 Meerbusch,
Germany
Phone: +49.2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger-Gasse 95,
1230 Wien,
Austria
Phone: +43.1.86338

KYOCERA MITA SVENSKA AB
Esbogatan 16B 164 75 Kista,
Sweden
Phone: +46.8.546.55000

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvei 6, NO 0694 Oslo,
Norway
Phone: +47.22.62.73.00

KYOCERA MITA DANMARK A/S
Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45.7022.3880

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351.21.843.6780

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
49 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA Asia Limited

16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories, Hong Kong
Phone: (852)-2610-2181

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

30-30 47th Avenue
Long Island City, NY 11101
TEL : (718) 289-2500
FAX : (718) 289-2501

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

3100 Breckinridge Blvd. NW Building 100,
Suite 105 Duluth, Georgia 30096
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804

KYOCERA MITA Brazil Ltda.

Av. Tambore, 1180 Mob.B-09 CEP 06460-000
Tambore-Barveri-SP,
Brazil
TEL : (55) 11-4195-8496
FAX : (55) 11-4195-6167

KYOCERA MITA Asia Limited

16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories, Hong Kong
Phone: (852)-2610-2181

KYOCERA MITA (Thailand) Corp., Ltd.
335 Ratchadapisek Road, Bangsue,
Bangkok, 10800, Thailand
Phone: (66)-2-586-0333

KYOCERA MITA Singapore Pte Ltd.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: (65)-6741-8733

KYOCERA MITA Hong Kong Limited
16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: (852)-2429-7422

KYOCERA MITA Taiwan Corporation
6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: (886)-2-2507-6709

KYOCERA MITA Korea Co., Ltd.
18F, Kangnam bldg, 1321-1,
Seocho-Dong, Seocho-Gu, Seoul, Korea
Phone: (822)-6933-4050

KYOCERA MITA India Private Limited
First Floor, ORCHID CENTRE
Sector-53, Golf Course Road, Gurgaon 122
002, India
Phone: (91)-0124-4671000